

## Media guide

The printer supports the following paper and other specialty media sizes. Select custom sizes up to the maximum specified for the Universal setting.

### Supported paper sizes

Measurements apply to simplex (one-sided) printing only. For duplex (two-sided) printing, the minimum size is 139.7 x 210 mm (5.50 x 8.27 in.).

Paper size	Dimensions	Standard 550-sheet tray (Tray 1)	Optional 550-sheet tray	Optional 2,000-sheet tray	Multipurpose tray	Optional 550-sheet specialty media drawer
<b>A4</b>	210 x 297 mm (8.27 x 11.7 in.)	✓	✓	✓	✓	✓
<b>A5</b>	148 x 210 mm (5.83 x 8.27 in.)	✓	✓	X	✓	✓
<b>A6</b>	105 x 148 mm (4.13 x 5.83 in.)	X	X	X	✓	✓
<b>JIS B5</b>	182 x 257 mm (7.17 x 10.1 in.)	✓	✓	X	✓	✓
<b>Letter</b>	215.9 x 279.4 mm (8.5 x 11 in.)	✓	✓	✓	✓	✓
<b>Legal</b>	215.9 x 355.6 mm (8.5 x 14 in.)	✓	✓	✓	✓	✓
<b>Executive</b>	184.2 x 266.7 mm (7.25 x 10.5 in.)	✓	✓	X	✓	✓
<b>Oficio (México)</b>	215.9 x 340.4 mm (8.5 x 13.4 in.)	✓	✓	X	✓	✓
<b>Folio</b>	215.9 x 330.2 mm (8.5 x 13 in.)	✓	✓	X	✓	✓
<b>Statement</b>	139.7 x 215.9 mm (5.5 x 8.5 in.)	X	X	X	✓	✓

\*This size setting formats the envelope for 215.9 x 355.6 mm (8.5 x 14 in.) unless the size is specified by the software application.

\*\*Supported by C734 model printers only.

\*\*\*Supported by C736 model printers only.

Paper size	Dimensions	Standard 550-sheet tray (Tray 1)	Optional 550-sheet tray	Optional 2,000-sheet tray	Multipurpose tray	Optional 550-sheet specialty media drawer
<b>Universal</b> <b>Note:</b> Turn size sensing off to support universal sizes that are close to standard media sizes.	148 x 210 mm to 215.9 x 355.6 mm (5.83 x 8.27 in. to 8.5 x 14 in.)	✓	✓	X	✓	✓
	76.2 x 127 mm (3 x 5 in.) to 215.9 x 355.6 mm (8.5 x 14 in.)	X	X	X	✓	✓
	76.2 x 127 mm (3 x 5 in.) to 215.9 x 914.4 mm (8.5 x 36 in.)**	X	X	X	✓	X
	76.2 x 127 mm (3 x 5 in.) to 215.9 x 1219.2 mm (8.5 x 48 in.)***	X	X	X	✓	X
<b>7 3/4 Envelope (Monarch)</b>	98.4 x 190.5 mm (3.875 x 7.5 in.)	X	X	X	✓	✓
<b>9 Envelope</b>	98.4 x 226.1 mm (3.875 x 8.9 in.)	X	X	X	✓	✓
<b>Com 10 Envelope</b>	104.8 x 241.3 mm (4.12 x 9.5 in.)	X	X	X	✓	✓
<b>DL Envelope</b>	110 x 220 mm (4.33 x 8.66 in.)	X	X	X	✓	✓
<b>C5 Envelope</b>	162 x 229 mm (6.38 x 9.01 in.)	X	X	X	✓	✓
<b>B5 Envelope</b>	176 x 250 mm (6.93 x 9.84 in.)	X	X	X	✓	✓
<b>Other Envelope*</b>	85.7 x 165 mm to 215.9 x 355.6 mm (3.375 x 6.50 in. to 8.5 x 14 in.)	X	X	X	✓	✓

\*This size setting formats the envelope for 215.9 x 355.6 mm (8.5 x 14 in.) unless the size is specified by the software application.

\*\*Supported by C734 model printers only.

\*\*\*Supported by C736 model printers only.

## Storing paper

Use these paper storage guidelines to help avoid jams and uneven print quality:

- For best results, store paper where the temperature is 21°C (70°F) and the relative humidity is 40%. Most label manufacturers recommend printing in a temperature range of 18 to 24°C (65 to 75°F) with relative humidity between 40 and 60%.
- Store paper in cartons when possible, on a pallet or shelf, rather than on the floor.

- Store individual packages on a flat surface.
- Do not store anything on top of individual paper packages.

## Avoiding jams

The following hints can help you avoid jams:

- Use only recommended paper or specialty media.  
For more information, see the *Card Stock & Label Guide* available on the Lexmark Web site at [www.lexmark.com/publications](http://www.lexmark.com/publications).
- Do not load too much paper. Make sure the stack height does not exceed the indicated maximum height.
- Do not load wrinkled, creased, damp, or curled paper.
- Flex, fan, and straighten paper before loading it.
- Do not use paper that has been cut or trimmed by hand.
- Do not mix paper sizes, weights, or types in the same stack.
- Store the paper in an appropriate environment.
- Do not remove trays while the printer is printing. Wait for **Load tray <x>** or **Ready** to appear before removing a tray.
- Do not load the multipurpose tray while the printer is printing. Load the tray prior to printing, or wait for **Load Multipurpose tray with <x>** to appear.
- Push all trays in firmly after loading paper.
- Make sure the guides in the trays are properly positioned.
- Make sure all paper sizes and paper types are set correctly in the printer control panel menu.
- Make sure all printer cables are attached correctly. For more information, see the setup documentation.