



Lexmark X203n and X204n Series

User's Guide

August 2011

www.lexmark.com

Machine type(s):

7011

Model(s):

200, 215, 300, 315

Contents

| | |
|--|-----------|
| Safety information..... | 9 |
| Learning about the printer..... | 11 |
| Thank you for choosing this printer!..... | 11 |
| Finding information about the printer..... | 11 |
| Selecting a location for the printer..... | 12 |
| Printer configurations..... | 13 |
| Basic functions of the scanner..... | 15 |
| Understanding the ADF and scanner glass..... | 16 |
| Understanding the printer control panel..... | 17 |
| Additional printer setup..... | 21 |
| Attaching cables..... | 21 |
| Installing printer software..... | 21 |
| Verifying printer setup..... | 22 |
| Printing a menu settings page | 22 |
| Printing a network setup page..... | 22 |
| Installing the printer on a wired network..... | 23 |
| Minimizing your printer's environmental impact..... | 25 |
| Saving paper and toner..... | 25 |
| Using recycled paper | 25 |
| Conserving supplies | 25 |
| Saving energy..... | 26 |
| Using Eco-Mode..... | 26 |
| Adjusting Power Saver | 27 |
| Recycling..... | 27 |
| Recycling Lexmark products | 27 |
| Recycling Lexmark packaging..... | 27 |
| Returning Lexmark cartridges for reuse or recycling..... | 28 |
| Reducing printer noise..... | 28 |
| Loading paper and specialty media..... | 30 |
| Setting the Paper Size and Paper Type..... | 30 |
| Configuring Universal paper settings..... | 30 |
| Loading the paper tray..... | 32 |
| Using the manual feeder..... | 35 |

| | |
|---|-----------|
| Paper capacities..... | 37 |
| Paper and specialty media guidelines..... | 38 |
| Paper guidelines..... | 38 |
| Paper characteristics..... | 38 |
| Unacceptable paper..... | 39 |
| Selecting paper | 39 |
| Selecting preprinted forms and letterhead | 39 |
| Using recycled paper and other office papers | 40 |
| Storing paper..... | 40 |
| Supported paper sizes, types, and weights..... | 41 |
| Paper types and weights supported by the printer | 41 |
| Paper sizes supported by the printer..... | 41 |
| Printing..... | 43 |
| Printing a document..... | 43 |
| Printing on both sides of the paper (duplexing)..... | 43 |
| Printing specialty documents..... | 44 |
| Tips on using letterhead | 44 |
| Tips on using transparencies | 44 |
| Tips on using envelopes..... | 45 |
| Tips on using labels..... | 46 |
| Tips on using card stock..... | 46 |
| Printing information pages..... | 47 |
| Printing a font sample list | 47 |
| Canceling a print job..... | 47 |
| Canceling a print job from the printer control panel..... | 47 |
| Canceling a print job from the computer | 47 |
| Copying..... | 49 |
| Making copies..... | 49 |
| Making a quick copy | 49 |
| Copying using the ADF | 49 |
| Copying using the scanner glass | 50 |
| Copying on both sides of the paper (duplexing)..... | 50 |
| Copying photos..... | 51 |
| Copying on specialty media..... | 52 |
| Copying to transparencies | 52 |
| Copying to letterhead | 52 |
| Customizing copy settings..... | 53 |
| Copying from one size to another | 53 |

| | |
|---|-----------|
| Reducing or enlarging copies..... | 53 |
| Making a copy lighter or darker..... | 54 |
| Adjusting copy quality | 54 |
| Collating copies..... | 55 |
| Copying multiple pages onto a single sheet | 55 |
| Pausing the current print job to make copies..... | 56 |
| Canceling a copy job..... | 56 |
| Improving copy quality..... | 56 |
| E-mailing..... | 58 |
| Getting ready to e-mail..... | 58 |
| Setting up the e-mail function | 58 |
| Setting up the address book | 58 |
| Creating an e-mail shortcut using the Embedded Web Server..... | 59 |
| E-mailing a document..... | 59 |
| Sending an e-mail using the keypad | 59 |
| Sending an e-mail using a shortcut number | 60 |
| Sending an e-mail using the address book | 61 |
| Canceling an e-mail..... | 61 |
| Faxing..... | 62 |
| Getting the printer ready to fax..... | 62 |
| Initial fax setup | 62 |
| Choosing a fax connection | 63 |
| Connecting to an analog telephone line | 64 |
| Connecting to a DSL service | 64 |
| Connecting to a PBX or ISDN system | 65 |
| Connecting to a distinctive ring service | 65 |
| Connecting the printer and a telephone or answering machine to the same telephone line..... | 66 |
| Connecting to an adapter for your country or region | 68 |
| Connecting to a computer with a modem..... | 72 |
| Setting the outgoing fax name and number | 73 |
| Setting the date and time | 73 |
| Sending a fax..... | 74 |
| Sending a fax using the printer control panel..... | 74 |
| Sending a fax using the computer | 74 |
| Sending a fax at a scheduled time | 75 |
| Creating shortcuts..... | 76 |
| Creating a fax destination shortcut using the Embedded Web Server..... | 76 |
| Creating a fax destination shortcut using the printer control panel..... | 76 |
| Using shortcuts and the address book..... | 77 |
| Using fax shortcuts | 77 |

| | |
|---|-----------|
| Using the address book | 77 |
| Customizing fax settings..... | 78 |
| Changing the fax resolution | 78 |
| Making a fax lighter or darker | 78 |
| Blocking junk faxes..... | 78 |
| Viewing a fax log | 79 |
| Canceling an outgoing fax..... | 79 |
| Understanding fax options..... | 79 |
| Original Size | 79 |
| Content | 79 |
| Resolution | 80 |
| Darkness | 80 |
| Improving fax quality..... | 80 |
| Forwarding a fax..... | 80 |
| Scanning to a computer..... | 82 |
| Scanning to a computer..... | 82 |
| Understanding scan profile options..... | 83 |
| Improving scan quality..... | 84 |
| Using the Scan Center software..... | 85 |
| Understanding the Scan Center features..... | 85 |
| Understanding printer menus..... | 86 |
| Menus list..... | 86 |
| Paper menu..... | 86 |
| Default Source menu | 86 |
| Size/Type menu | 87 |
| Paper Texture menu | 89 |
| Paper Weight menu | 90 |
| Custom Types menu | 90 |
| Custom Scan Sizes menu | 91 |
| Universal Setup menu..... | 92 |
| Reports menu..... | 93 |
| Reports menu | 93 |
| Settings menu..... | 94 |
| General Settings menu | 94 |
| Copy Settings menu | 96 |
| Fax Settings menu..... | 98 |
| Print Settings..... | 102 |
| Network/Ports menu..... | 106 |
| Standard Network or Network <x> menus | 106 |

| | |
|---|------------|
| Network Reports menu | 107 |
| Network Card menu..... | 108 |
| TCP/IP menu | 108 |
| IPv6 menu | 109 |
| USB menu | 110 |
| Set Date and Time..... | 111 |
| Maintaining the printer..... | 114 |
| Cleaning the exterior of the printer..... | 114 |
| Cleaning the scanner glass..... | 115 |
| Cleaning the ADF separator rollers..... | 116 |
| Storing supplies..... | 118 |
| Checking the status of supplies from a network computer..... | 118 |
| Ordering supplies..... | 119 |
| Ordering toner cartridges | 119 |
| Ordering a photoconductor kit | 119 |
| Replacing supplies..... | 120 |
| Replacing the toner cartridge | 120 |
| Replacing the photoconductor kit | 122 |
| Moving the printer to another location..... | 125 |
| Shipping the printer..... | 126 |
| Administrative support..... | 127 |
| Finding advanced networking and administrator information..... | 127 |
| Using the Embedded Web Server..... | 127 |
| Viewing reports..... | 127 |
| Checking the device status..... | 128 |
| Setting up e-mail alerts..... | 128 |
| Restoring the factory default settings..... | 128 |
| Troubleshooting..... | 129 |
| Checking an unresponsive printer..... | 129 |
| Printer control panel display is blank or displays only diamonds..... | 129 |
| Partial document or photo print, copies, or scans..... | 129 |
| Check the document placement..... | 129 |
| Check the paper size setting | 129 |
| Reinstall the toner cartridge | 129 |
| Understanding printer messages..... | 130 |
| Close front door | 130 |
| Invalid Engine Code | 130 |


| | |
|---|-----|
| Load <src> with <x> | 130 |
| Network/Network <x> | 130 |
| Programming Engine Code DO NOT POWER OFF | 130 |
| Programming System Code DO NOT POWER OFF | 130 |
| Cartridge is low | 130 |
| Waiting..... | 131 |
| 31.yy Replace defective or missing cartridge | 131 |
| 30 Invalid refill, change toner cartridge..... | 131 |
| 32 Replace unsupported cartridge | 131 |
| 34 Short paper | 131 |
| 37 Insufficient memory to collate job..... | 131 |
| 38 Memory full | 131 |
| 39 Complex page, some data may not have printed | 132 |
| 54 Standard network software error | 132 |
| 54 Network <x> software error | 132 |
| 56 Standard USB port disabled | 132 |
| 84 PC Kit life warning | 132 |
| 84 Replace PC Kit | 132 |
| 88.yy Cartridge is low..... | 132 |
| 200–250 paper jam..... | 133 |
| 290–294 paper jams | 133 |
| 840.01 Scanner Disabled | 135 |
| 840.02 Scanner Auto Disabled..... | 135 |
| Clearing jams..... | 136 |
| Avoiding jams..... | 136 |
| 200–201 paper jam..... | 137 |
| 202 paper jam..... | 139 |
| 241 paper jam..... | 141 |
| 251 paper jam..... | 142 |
| Solving printing problems..... | 143 |
| Jobs do not print | 143 |
| Multiple-language PDFs do not print..... | 144 |
| Job takes longer than expected to print..... | 144 |
| Incorrect characters print | 144 |
| Large jobs do not collate..... | 145 |
| Unexpected page breaks occur..... | 145 |
| Solving copy problems..... | 145 |
| Copier does not respond | 145 |
| Scanner unit does not close..... | 145 |
| Poor copy quality | 146 |
| Solving scanner problems..... | 147 |
| Checking an unresponsive scanner..... | 147 |
| Scan was not successful | 147 |
| Scanning takes too long or freezes the computer | 148 |

| | |
|---|------------|
| Poor scanned image quality..... | 148 |
| Cannot scan from a computer | 148 |
| Cannot create a Scan Profile | 149 |
| Solving fax problems..... | 149 |
| Caller ID is not shown | 149 |
| Cannot send or receive a fax | 149 |
| Can send but not receive faxes..... | 151 |
| Can receive but not send faxes..... | 151 |
| Received fax has poor print quality | 152 |
| Solving paper feed problems..... | 153 |
| Paper frequently jams..... | 153 |
| Paper jam message remains after jam is cleared | 153 |
| Solving print quality problems..... | 153 |
| Isolating print quality problems..... | 153 |
| Blank pages | 154 |
| Characters have jagged or uneven edges | 154 |
| Clipped images..... | 155 |
| Gray background..... | 155 |
| Ghost images | 155 |
| Incorrect margins..... | 156 |
| Paper curl..... | 157 |
| Print is too dark | 157 |
| Print is too light..... | 158 |
| Skewed print..... | 159 |
| Solid black or white streaks appear on transparencies or paper..... | 159 |
| Streaked horizontal lines | 160 |
| Streaked vertical lines..... | 161 |
| Toner fog or background shading appears on the page..... | 161 |
| Toner rubs off | 162 |
| Toner specks | 162 |
| Transparency print quality is poor | 163 |
| Embedded Web Server does not open..... | 163 |
| Check the network connections | 163 |
| Check the network settings | 163 |
| Contacting Customer Support..... | 163 |
| Notices..... | 164 |
| Product information..... | 164 |
| Edition notice..... | 164 |
| Power consumption..... | 167 |
| Index..... | 181 |


Safety information

Connect the power cord to a properly grounded electrical outlet that is near the product and easily accessible.

Do not place or use this product near water or wet locations.

 **CAUTION—POTENTIAL INJURY:** This product uses a laser. Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.


This product uses a printing process that heats the print media, and the heat may cause the media to release emissions. You must understand the section in your operating instructions that discusses the guidelines for selecting print media to avoid the possibility of harmful emissions.


 **CAUTION—HOT SURFACE:** The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching.

Use only the power cord provided with this product or the manufacturer's authorized replacement.


Use only the telecommunications (RJ-11) cord provided with this product or a 26 AWG or larger replacement when connecting this product to the public switched telephone network.

Use care when you replace a lithium battery.


 **CAUTION—POTENTIAL INJURY:** There is a danger of explosion if a lithium battery is incorrectly replaced. Replace it only with the same or an equivalent type of lithium battery. Do not recharge, disassemble, or incinerate a lithium battery. Discard used batteries according to the manufacturer's instructions and local regulations.

 **CAUTION—POTENTIAL INJURY:** Follow these guidelines to avoid personal injury or printer damage:


- Turn the printer off using the power switch, and then unplug the power cord from the wall outlet.
- Disconnect all cords and cables from the printer before moving it.
- Use the handholds located on both sides of the printer to lift it.
- Make sure your fingers are not under the printer when you set it down.
- Before setting up the printer, make sure there is adequate clearance around it.


 **CAUTION—SHOCK HAZARD:** Make sure that all external connections (such as Ethernet and telephone system connections) are properly installed in their marked plug-in ports.

This product is designed, tested, and approved to meet strict global safety standards with the use of specific manufacturer's components. The safety features of some parts may not always be obvious. The manufacturer is not responsible for the use of other replacement parts.

 **CAUTION—POTENTIAL INJURY:** Do not cut, twist, bind, crush, or place heavy objects on the power cord. Do not subject the power cord to abrasion or stress. Do not pinch the power cord between objects such as furniture and walls. If any of these things happen, a risk of fire or electrical shock results. Inspect the power cord regularly for signs of such problems. Remove the power cord from the electrical outlet before inspecting it.

Refer service or repairs, other than those described in the user documentation, to a professional service person.

 **CAUTION—SHOCK HAZARD:** To avoid the risk of electric shock when cleaning the exterior of the printer, unplug the power cord from the wall outlet and disconnect all cables from the printer before proceeding.

 **CAUTION—SHOCK HAZARD:** Do not use the fax feature during a lightning storm. Do not set up this product or make any electrical or cabling connections, such as the fax feature, power cord, or telephone, during a lightning storm.

SAVE THESE INSTRUCTIONS.

Learning about the printer


Thank you for choosing this printer!

We've worked hard to make sure it will meet your needs.

To start using your new printer right away, use the setup materials that came with the printer, and then skim the *User's Guide* to learn how to perform basic tasks. To get the most out of your printer, read the *User's Guide* carefully, and make sure you check the latest updates on our Web site.

We're committed to delivering performance and value with our printers, and we want to make sure you're satisfied. If you do encounter any problems along the way, one of our knowledgeable support representatives will be delighted to help you get back on track fast. And if you find something we could do better, please let us know. After all, you are the reason we do what we do, and your suggestions help us do it better.

Finding information about the printer


| What are you looking for? | Find it here |
|--|---|
| Initial setup instructions: <ul style="list-style-type: none">• Connecting the printer• Installing the printer software | Setup documentation—The setup documentation came with the printer and is also available on the Lexmark Web site at www.lexmark.com/publications/ . |
| Additional setup and instructions for using the printer: <ul style="list-style-type: none">• Selecting and storing paper and specialty media• Loading paper• Performing printing, copying, scanning, and faxing tasks, depending on your printer model• Configuring printer settings• Viewing and printing documents and photos• Setting up and using printer software• Setting up and configuring the printer on a network, depending on your printer model• Caring for and maintaining the printer• Troubleshooting and solving problems | <i>User's Guide</i> —The <i>User's Guide</i> is available on the <i>Software and Documentation CD</i> . For updates, check our Web site at www.lexmark.com/publications/ . |
| Help using the printer software | Windows or Mac Help—Open a printer software program or application, and then click Help . Click  to view context-sensitive information. Notes: <ul style="list-style-type: none">• The Help installs automatically with the printer software.• The printer software is located in the printer Program folder or on the desktop, depending on your operating system. |

| What are you looking for? | Find it here |
|---|---|
| <p>The latest supplemental information, updates, and technical support:</p> <ul style="list-style-type: none"> • Documentation • Driver downloads • Live chat support • E-mail support • Telephone support | <p>Lexmark Support Web site—support.lexmark.com</p> <p>Note: Select your region, and then select your product to view the appropriate support site.</p> <p>Support telephone numbers and hours of operation for your region or country can be found on the Support Web site or on the printed warranty that came with your printer.</p> <p>Record the following information (located on the store receipt and the back of the printer), and have it ready when you contact support so that they may serve you faster:</p> <ul style="list-style-type: none"> • Machine Type number • Serial number • Date purchased • Store where purchased |
| <p>Warranty information</p> | <p>Warranty information varies by country or region:</p> <ul style="list-style-type: none"> • In the US—See the Statement of Limited Warranty included with this printer, or at support.lexmark.com. • Rest of the world—See the printed warranty that came with your printer. |

Selecting a location for the printer

When selecting a location for the printer, leave enough room to open trays, covers, and doors. It is important to:

- Make sure airflow in the room meets the latest revision of the ASHRAE 62 standard.
- Provide a flat, sturdy, and stable surface.
- Keep the printer:
 - Away from the direct airflow of air conditioners, heaters, or ventilators
 - Free from direct sunlight, humidity extremes, or temperature fluctuations
 - Clean, dry, and free of dust
- Allow the following recommended amount of space around the printer for proper ventilation:




| | | |
|---|------------|----------------|
| 1 | Left Side | 31 cm (12 in.) |
| 2 | Right Side | 31 cm (12 in.) |
| 3 | Front | 41 cm (16 in.) |
| 4 | Rear | 15 cm (6 in.) |
| 5 | Top | 31 cm (12 in.) |

Printer configurations

Basic model


The following illustration shows the printer front with its basic features or parts:



| | |
|----------|---------------------------|
| 1 | Printer control panel |
| 2 | Standard exit bin |
| 3 | Paper stop |
| 4 | Manual feeder |
| 5 | Paper tray (250 sheets) |
| 6 | Front door |
| 7 | Front door release button |

Configured model

The following illustration shows the fully configured printer:



| | |
|---|---------------------------------|
| 1 | Automatic Document Feeder (ADF) |
| 2 | Printer control panel |
| 3 | Standard exit bin |
| 4 | Paper stop |
| 5 | Manual feeder |
| 6 | Paper tray (250 sheets) |
| 7 | Front door |
| 8 | Front door release button |

Basic functions of the scanner



The scanner provides copy, fax, and scan-to-network capability.

Note: Fax is supported on selected models only.

You can:

- Make quick copies, or change the settings on the printer control panel to perform specific copy jobs.
- Send a fax using the printer control panel.
- Send a fax to multiple fax destinations at the same time.
- Scan documents and send them to your computer or an e-mail address.

Understanding the ADF and scanner glass

| Automatic Document Feeder (ADF) | Scanner glass |
|---|---|
|  <p>Use the ADF for multiple-page documents.</p> <p>Note: The ADF is available on selected models only.</p> |  <p>Use the scanner glass for single pages, small items (such as postcards or photos), transparencies, photo paper, or thin media (such as magazine clippings).</p> |

You can use the ADF or the scanner glass to copy or scan documents.

Using the ADF

Note: The ADF is available on selected models only.

The ADF can copy or scan multiple pages. When using the ADF:


- Load the document into the ADF faceup, short edge first.
- Load up to 30 sheets of 75 g/m² (20 lb) plain paper in the ADF input tray.
- Scan sizes from 139.7 mm x 210 mm (5.5 x 8.3 in.) to 215.9 x 355.6 mm (8.5 x 14 in.).
- Scan documents with mixed page sizes (letter and legal).
- Scan media weights from 60 to 105 g/m² (16 to 28 lb).
- Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.

Using the scanner glass


The scanner glass can be used to scan or copy single pages or book pages. When using the scanner glass:

- Place a document facedown on the scanner glass in the upper left corner.
- Scan or copy documents from 114.3 x 139.7 mm (4.5 x 5.5 in.) to 215.9 x 297.2 mm (8.5 x 11.7 in.).
- Copy books up to 25.4-mm (1.0 in.) thick.


Understanding the printer control panel









| Item | | Description |
|------|-------------------------|--|
| 1 | Selections and settings | Select a function such as Copy, Scan/Email, Fax, or Options. Use the address book when scanning to e-mail. Note: Fax mode is not available on selected printer models. |
| 2 | Display area | View scanning, copying, faxing, and printing options as well as status and error messages. Access the administration menus; start, stop, or cancel a print job. |
| 3 | Keypad area | Enter numbers, letters, or symbols on the display. Access the Address Book or change the default fax settings on printer models that support fax. |








| Item | | Description |
|------|------------|---|
| 1 | Copy | Enters the copy function |
| 2 | Scan/Email | Enters the scan or scan to e-mail function |
| 3 | Fax | Enters the fax function Note: Fax mode is not available on selected printer models. |
| 4 | Options | Temporarily changes settings such as Original Size, Paper Source, and Scale |





| Item | | Description |
|------|--|--|
| 1 | Menu  | Enters the administration menus |
| 2 | Display | View scanning, copying, faxing, and printing options as well as status and error messages |
| 3 | Stop/Cancel  | <ul style="list-style-type: none"> Stops printing Exits a menu and returns to Ready |
| 4 | Start  | Starts a copy, scan, or fax job |
| 5 | Right arrow  | Scrolls right |
| 6 | Select  | Accepts menu selections and settings |
| 7 | Left arrow  | Scrolls left |

| Item | Description | |
|------|-----------------|---|
| 8 | Indicator light | <ul style="list-style-type: none"> • Off—The power is off. • Blinking green—The printer is warming up, processing data, or printing. • Solid green—The printer is on, but idle. • Blinking red—Operator intervention is needed. |
| 9 | Back | Returns to the previous menu |




| Item | Description | |
|------|-------------|---|
| 1 | Hook | <p>Press  to take the line off-hook (like picking up a telephone receiver) when faxing. Press  a second time to hang up the line.</p> <p>Note: Fax mode is not available on selected printer models.</p> |
| 2 | Keypad | <p>Enter numbers, letters, or symbols on the display.</p>  |
| 3 | Shortcuts | <p>Enters the shortcut screen</p>  |

| Item | | Description |
|------|---|---|
| 4 | Address Book  | Access any of the programmed shortcuts (1-99) for fax and e-mail. Note: Fax mode is not available on selected printer models. |
| 5 | Redial/Pause  | <ul style="list-style-type: none"> • Press the Redial/Pause button to cause a two- or three-second dial pause in a fax number. In the Fax To: field, a Dial Pause is represented by a comma (,). • Press the Redial/Pause button to redial a fax number. • The button functions only within the Fax menu or with fax functions. When outside of the Fax menu, fax function, or home screen, pressing the Redial/Pause button causes an error beep. Note: Fax mode is not available on selected printer models. |

Additional printer setup

Attaching cables

- 1 Connect the power cord to the printer first and then to a wall outlet.
- 2 Connect the printer to a computer or a network.
 - For a local connection, make sure to install the printer CD before connecting a USB cable.
 - For a network connection, connect an Ethernet cable before installing the printer CD.



| | |
|---|---------------------------|
| 1 | Ethernet port |
| 2 | USB port |
| 3 | Printer power cord socket |

Installing printer software

A printer driver is software that lets the computer communicate with the printer. The printer software is typically installed during the initial printer setup. If you need to install the software after setup, follow these instructions:

For Windows users

- 1 Close all open software programs.
- 2 Insert the *Software and Documentation* CD.
- 3 From the main installation dialog, click **Install**.
- 4 Follow the instructions on the screen.

For Macintosh users

- 1 Close all open software applications.
- 2 Insert the *Software and Documentation* CD.
- 3 From the Finder desktop, double-click the printer CD icon that automatically appears.
- 4 Double-click the **Install** icon.
- 5 Follow the instructions on the screen.

Using the World Wide Web

- 1 Go to the Lexmark Web site at **www.lexmark.com**.
- 2 From the Drivers & Downloads menu, click **Driver Finder**.
- 3 Select your printer, and then select your operating system.
- 4 Download the driver and install the printer software.




Verifying printer setup

If your printer is a network model and is attached to a network, print a network setup page to verify the network connection. This page also provides important information that aids network printing configuration.

Printing a menu settings page

Print a menu settings page to review the current menu settings.



Note: If you have not made any menu item settings changes yet, then the menu settings page lists all the factory default settings. Once you select and save other settings from the menus, they replace the factory default settings as *user default settings*. A user default setting remains in effect until you access the menu again, choose another value, and save it.


- 1 Make sure the printer is on and **Ready** appears.
- 2 From the printer control panel, press .
- 3 Press the arrow buttons until **Reports** appears, and then press .
- 4 Press the arrow buttons until **Menu Settings Page** appears, and then press .

After the menu settings page prints, **Ready** appears.

Printing a network setup page

If the printer is attached to a network, print a network setup page to verify the network connection. This page also provides important information that aids network printing configuration.

- 1 Make sure the printer is on and **Ready** appears.
- 2 From the printer control panel, press .
- 3 Press the arrow buttons until **Reports** appears, and then press .

- 4 Press the arrow buttons until **Network Setup Page** appears, and then press .
After the network setup page prints, **Ready** appears.
- 5 Check the first section on the network setup page, and confirm that Status is “Connected.”
If Status is “Not Connected,” the LAN drop may not be active, or the network cable may be malfunctioning. Consult a system support person for a solution, and then print another network setup page.


Installing the printer on a wired network

Use the following instructions to install the printer on a wired network. These instructions apply to Ethernet connections.

Before you install the printer on a wired network, make sure that:

- You have completed the initial setup of the printer.
- The printer is connected to your network with the appropriate type of cable.

For Windows users

- 1 Insert the *Software and Documentation* CD.
Wait for the Welcome screen to appear.
If the CD does not launch after a minute, then launch the CD manually:
 - a Click , or click **Start** and then click **Run**.
 - b In the Start Search or Run box, type **D:\setup.exe**, where **D** is the letter of your CD or DVD drive.
- 2 Click **Install Printer and Software**.
- 3 Click **Agree** to agree to the License Agreement.
- 4 Select **Suggested**, and then click **Next**.
Note: To configure the printer using a static IP address, using IPv6, or to configure printers using scripts, select **Custom** and follow the on-screen instructions.
- 5 Select **Wired Network Attach**, and then click **Next**.
- 6 Select the printer manufacturer from the list.
- 7 Select the printer model from the list, and then click **Next**.
- 8 Select the printer from the list of printers discovered on the network, and then click **Finish**.
Note: If your configured printer does not appear in the list of discovered printers, then click **Add Port** and follow the on-screen instructions.
- 9 Follow the on-screen instructions to complete the installation.

For Macintosh users

- 1 Allow the network DHCP server to assign an IP address to the printer.
- 2 Print the network setup page from the printer. For information on printing a network setup page, see “Printing a network setup page” on page 22.
- 3 Locate the printer IP address in the TCP/IP section of the network setup page. You will need the IP address if you are configuring access for computers on a different subnet than the printer.

4 Install the drivers and add the printer.

a Install a PPD file on the computer:

- 1** Insert the *Software and Documentation* CD in the CD or DVD drive.
- 2** Double-click the installer package for the printer.
- 3** From the Welcome screen, click **Continue**.
- 4** Click **Continue** again after viewing the Readme file.
- 5** Click **Continue** after viewing the license agreement, and then click **Agree** to accept the terms of the agreement.
- 6** Select a Destination, and then click **Continue**.
- 7** From the Easy Install screen, click **Install**.
- 8** Type the user password, and then click **OK**.
All the necessary software is installed on the computer.
- 9** Click **Restart** when installation is complete.

b Add the printer:

- For IP printing:

In Mac OS X version 10.5

- 1** From the Apple menu, choose **System Preferences**.
- 2** Click **Print & Fax**.
- 3** Click **+**.
- 4** Select the printer from the list.
- 5** Click **Add**.

In Mac OS X version 10.4 and earlier

- 1** From the Finder desktop, choose **Go > Applications**.
- 2** Double-click **Utilities**.
- 3** Double-click **Printer Setup Utility** or **Print Center**.
- 4** From the Printer List, click **Add**.
- 5** Select the printer from the list.
- 6** Click **Add**.

Note: If the printer does not show up in the list, you may need to add it using the IP address. Contact your system support person for assistance.

Minimizing your printer's environmental impact

Lexmark is committed to environmental sustainability and is continually improving its printers to reduce their impact on the environment. We design with the environment in mind, engineer our packaging to reduce materials, and provide collection and recycling programs. For more information, see:

- The Notices chapter
- The Environmental Sustainability section of the Lexmark Web site at www.lexmark.com/environment
- The Lexmark recycling program at www.lexmark.com/recycling

By selecting certain printer settings or tasks, you may be able to reduce your printer's impact even further. This chapter outlines the settings and tasks that may yield a greater environmental benefit.

Saving paper and toner

Studies show that as much as 80% of the carbon footprint of a printer is related to paper usage. You can significantly reduce your carbon footprint by using recycled paper and the following printing suggestions, such as printing on both sides of the paper and printing multiple pages on one side of a single sheet of paper.

For information on how you can quickly save paper and energy using one printer setting, see "Using Eco-Mode".

Using recycled paper

As an environmentally conscious company, Lexmark supports the use of recycled office paper produced specifically for use in laser printers. For more information on recycled papers that work well with your printer, see "Using recycled paper and other office papers" on page 40.

Conserving supplies

There are a number of ways you can reduce the amount of paper and toner you use when printing, copying, or receiving faxes. You can:

Use both sides of the paper

You can control whether print appears on one or two sides of the paper for a printed document or a copy. For more information, see:

- "Printing on both sides of the paper (duplexing)" on page 43
- "Copying on both sides of the paper (duplexing)" on page 50

Place multiple pages on one sheet of paper

You can print up to 16 consecutive pages of a multiple-page document onto one side of a single sheet of paper from the Print dialog.

To copy two or four consecutive pages of a multiple-page document onto one side of a single sheet of paper, see "Copying multiple pages onto a single sheet" on page 55.

Choose scanning

You can avoid making a paper output of a document or photograph by scanning it and then saving it to a computer program or application. For more information, see:

- “Scanning to a computer” on page 82
- “E-mailing a document” on page 59

Check your first draft for accuracy

Before printing or making multiple copies of a document:

- Use the Lexmark preview feature, which you can select from the Print dialog, the Lexmark Toolbar, or the printer display, to see what the document will look like before you print it.
- Print one copy of the document to check its content and format for accuracy.

Avoid paper jams

Carefully select and load paper to avoid paper jams. For more information, see “Avoiding jams” on page 136.

Use lower settings

Use lower settings, such as a lower darkness setting from the Copy or Finishing menu.

Saving energy

For additional information on saving power, see the Notices chapter.



Using Eco-Mode




Use Eco-Mode to quickly select one or more ways to reduce your printer's environmental impact.

Note: See the table for the multiple settings that change when you select an Eco-Mode setting.







| Choose | To |
|--------------|--|
| Energy | Reduce energy use, especially when the printer is idle. <ul style="list-style-type: none">• Printer engine motors do not start until a job is ready to print. You may notice a short delay before the first page is printed.• The printer enters Power Saver mode after one minute of inactivity.• When the printer enters Power Saver mode, the printer control panel display light is turned off.• The scanner lamps are activated only when a scan job is started. |
| Paper | Turn off print log features. |
| Energy/Paper | Use all the settings associated with Energy mode and Paper mode. |
| Off | Use factory default settings for all settings associated with Eco-Mode. This setting supports the performance specifications for your printer. |

To select an Eco-Mode setting:

- 1 From the printer control panel, press .
- 2 Press the arrow buttons until **Settings** appears, and then press .

- 3 Press the arrow buttons until **General Settings** appears, and then press .
 - 4 Press the arrow buttons until **Eco-Mode** appears, and then press .
 - 5 Select the setting you want, and then press .
- Submitting changes** appears.

Adjusting Power Saver

- 1 Make sure the printer is on and **Ready** appears.
- 2 From the printer control panel, press .
- 3 Press the arrow buttons until **Settings** appears, and then press .
- 4 Press the arrow buttons until **General Settings** appears, and then press .
- 5 Press the arrow buttons until **Timeouts** appears, and then press .
- 6 Press the arrow buttons until **Power Saver** appears, and then press .
- 7 Press the arrow buttons to increase or decrease the number of minutes before the printer enters Power Saver mode, and then press . Available settings are Disabled and a range from 1–240 minutes.

Note: Power Saver settings can also be adjusted by issuing a Printer Job Language (PJM) command. For more information, see the *Technical Reference* available on the Lexmark Web site at www.lexmark.com/publications.

Recycling

Lexmark provides collection programs and environmentally progressive approaches to recycling. For more information, see:

- The Notices chapter
- The Environmental Sustainability section of the Lexmark Web site at www.lexmark.com/environment
- The Lexmark recycling program at www.lexmark.com/recycling

Recycling Lexmark products

To return Lexmark products to Lexmark for recycling:

- 1 Visit our Web site at www.lexmark.com/recycle.
- 2 Find the product type you want to recycle, and then select your country from the list.
- 3 Follow the instructions on the computer screen.

Recycling Lexmark packaging

Lexmark continually strives to minimize packaging. Less packaging helps to ensure that Lexmark printers are transported in the most efficient and environmentally sensitive manner and that there is less packaging to dispose of. These efficiencies result in fewer greenhouse emissions, energy savings, and natural resource savings.

Lexmark cartons are 100% recyclable where corrugated recycling facilities exist. Facilities may not exist in your area.

Expanded polystyrene (EPS) foam used in Lexmark packaging is recyclable where foam recycling facilities exist. Facilities may not exist in your area. For information on EPS foam recycling locations:

- 1 Visit EPS Recycling International's Web site at www.epsrecycling.org/pages/intcon.html.
- 2 Select your country or region from the list, and then click the links or use the contact information provided.

When you return a cartridge to Lexmark, you can reuse the box that the cartridge came in. Lexmark will recycle the box.

Returning Lexmark cartridges for reuse or recycling

The Lexmark Cartridge Collection Program diverts millions of Lexmark cartridges from landfills annually by making it both easy and free for Lexmark customers to return used cartridges to Lexmark for reuse or recycling. One hundred percent of the empty cartridges returned to Lexmark are either reused or demanufactured for recycling. Boxes used to return the cartridges are also recycled.

To return Lexmark cartridges for reuse or recycling, follow the instructions that came with your printer or cartridge and use the pre-paid shipping label. You can also:

- 1 Visit our Web site at www.lexmark.com/recycle.
- 2 From the Toner Cartridges section, select your country from the list.
- 3 Follow the instructions on the computer screen.




Reducing printer noise

Use Quiet Mode to reduce the printer noise.

Note: See the table for the multiple settings that change when you select a Quiet Mode setting.

| Choose | To |
|--------|--|
| On | <p>Reduce printer noise.</p> <ul style="list-style-type: none"> • You may notice a reduction in processing speed. • Printer engine motors do not start until a job is ready to print. You may notice a short delay before the first page is printed. • Fans run at a reduced speed or are turned off. • If your printer has faxing capability, fax sounds are reduced or disabled, including those made by the fax speaker and ringer. |
| Off | <p>Use factory default settings. This setting supports the performance specifications for your printer.</p> |

To select a Quiet Mode setting:

- 1 From the printer control panel, press .
- 2 Press the arrow buttons until **Settings** appears, and then press .
- 3 Press the arrow buttons until **General Settings** appears, and then press .









- 4 Press the arrow buttons until **Quiet Mode** appears, and then press .
 - 5 Select the setting you want, and then press .
- Submitting changes** appears.

Loading paper and specialty media

This section explains how to load the 250-sheet tray and the manual feeder. It also includes information about paper orientation and setting the Paper Size and Paper Type.

Setting the Paper Size and Paper Type

To print on a different size or type of paper, load the paper and then change the printer settings.

- 1 Make sure the printer is on and **Ready** appears.
- 2 From the printer control panel, press .
Paper Menu appears.
- 3 Press .
- 4 Press the arrow buttons until **Size/Type** appears, and then press .
- Select Source** appears.
- 5 Press the arrow buttons until the paper source you want appears, and then press .
- 6 To change the size setting:
 - a Press the arrow buttons until **Size** appears next to the paper source you want to use, and then press .
 - The current paper size setting appears.
 - b Press the arrow buttons until the size you want appears, and then press .
 - Submitting Changes** appears.
- 7 To change the type setting:
 - a Press the arrow buttons until **Type** appears next to the paper source you want to use, and then press .
 - The current paper type setting appears.
 - b Press the arrow buttons until the type you want appears, and then press .
 - Submitting Changes** appears.






Configuring Universal paper settings

The Universal Paper Size is a user-defined setting that lets you print on paper sizes that are not preset in the printer menus. Set the Paper Size for the Manual Feeder to Universal when the size you want is not available from the Paper Size menu. Then, specify all of the following Universal size settings for your paper:

- Units of measure (inches or millimeters)
- Portrait Height and Portrait Width
- Feed Direction

Note: The smallest supported Universal size is 76 x 127 mm (3 x 5 in.); the largest is 216 x 356 mm (8.5 x 14 in.). Paper that weighs at least 75 g/m² (20 lb) is recommended for sizes less than or equal to 182 mm (7.17 in.) wide.





Specify a unit of measurement

- 1 Make sure the printer is on and **Ready** appears.
 - 2 From the printer control panel, press .
Paper Menu appears.
 - 3 Press .
 - 4 Press the arrow buttons until **Universal Setup** appears, and then press .
 - 5 Press the arrow buttons until **Units of Measure** appears, and then press .
 - 6 Press the arrow buttons until the correct unit of measure appears, and then press .
- Submitting Changes** appears, followed by the **Universal Setup** menu.

Specify the paper height and width

Defining a specific height and width measurement for the Universal paper size (in the portrait orientation) allows the printer to support the size, including support for standard features such as duplex printing and printing multiple pages on one sheet.


Note: Select **Portrait Height** to adjust the paper height setting or **Paper Width** to adjust the paper width setting, or adjust both. Instructions to adjust both follow.

- 1 From the Universal Setup menu, press the arrow buttons until **Portrait Width** appears, and then press .
 - 2 Press the left arrow button to decrease the setting or the right arrow button to increase the setting, and then press .
- Submitting Changes** appears, followed by the **Universal Setup** menu.
- 3 From the Universal Setup menu, press the arrow buttons until **Portrait Height** appears, and then press .
 - 4 Press the left arrow button to decrease the setting or the right arrow button to increase the setting, and then press .
- Submitting Changes** appears, followed by the **Universal Setup** menu.


Loading the paper tray

Do not load the paper tray while a job prints or while **Busy** appears on the display. Doing so may cause a paper jam.


- 1 Pull the paper tray completely out.




- 2 Squeeze the width guide tabs on the right guide as shown, and slide the width guides to the sides of the tray. The width guides move in unison.




3 Squeeze the length guide tabs together as shown, and then slide the length guide to the correct position for the paper size. Use the size indicators on the bottom of the tray to help position the guide.



If you are loading a longer size of paper, then squeeze the length guide tab and slide the length guide backward to the correct position for the paper size. The tray extends backward as shown.




- 4 Flex the sheets back and forth to loosen them, and then fan them. Do not fold or crease the paper. Straighten the edges on a level surface.




- 5 Load the paper stack toward the back of the tray as shown with the recommended print side facedown.


Note: The maximum fill line on the side of the width guide indicates the maximum height for loading paper. Do not overload the tray.




Load letterhead with the print side facedown and the top edge of the sheet toward the front of the tray.



- 6 Squeeze the width guide tabs on the right guide, and then slide the width guides to lightly touch the side of the stack.



- 7 Insert the paper tray.



- 8 If the paper type you loaded differs from the type that was previously loaded in the tray, then change the Paper Type setting for the tray.


Using the manual feeder

The manual feeder can feed only one sheet of paper at a time. You can use the manual feeder to quickly print on paper types or sizes that are not currently loaded in the tray.

- 1 Insert the paper faceup into the center of the manual feeder.
- 2 Adjust the paper guides to the paper width.


3 Push the paper further into the manual feeder until the printer pulls it in.

Warning—Potential Damage: Do not force the paper into the feeder. Forcing the paper causes jams.



Notes:

- Load letterhead faceup, with the top of the sheet entering first.
- Load envelopes with the flap side down and with the stamp area as shown.



Paper capacities

| Paper type | Paper tray | Manual feeder |
|---------------------------|------------|---------------|
| Paper¹ | 250 sheets | 1 sheet |
| Labels² | 50 sheets | 1 sheet |
| Transparencies | 50 | 1 |
| Envelopes | X | 1 |

¹ Based on 75 g/m² (20 lb) paper

² Single-sided paper labels designed for laser printers are supported for occasional use: no more than 20 pages of labels a month. Vinyl, pharmacy, and dual-web labels are not supported.

The standard exit bin capacity is 150 sheets, based on 75 g/m² (20 lb) paper.

Paper and specialty media guidelines

Paper guidelines

Selecting the correct paper or specialty media reduces printing problems. For the best print quality, try a sample of the paper or specialty media before buying large quantities.

Paper characteristics

The following paper characteristics affect print quality and reliability. Consider these characteristics when evaluating new paper stock.

Weight

The paper tray can automatically feed paper weights up to 90 g/m² (24 lb bond) grain long paper. The manual feeder can automatically feed paper weights up to 163 g/m² (43 lb bond) grain long.

For best performance, use 75 g/m² (20 lb bond) grain long paper. Paper lighter than 60 g/m² (16 lb) might not be stiff enough to feed properly, causing jams. Paper that weighs at least 75 g/m² (20 lb) is recommended for sizes less than or equal to 182 mm (7.17 in.) wide.

Curl

Curl is the tendency for paper to curl at its edges. Excessive curl can cause paper feeding problems. Curl can occur after the paper passes through the printer, where it is exposed to high temperatures. Storing paper unwrapped in hot, humid, cold, or dry conditions, even in the trays, can contribute to paper curling prior to printing and can cause feeding problems.

Smoothness

Paper smoothness directly affects print quality. If paper is too rough, toner cannot fuse to it properly. If paper is too smooth, it can cause paper feeding or print quality issues. Always use paper between 100–300 Sheffield points; smoothness between 150–250 Sheffield points produces the best print quality.

Moisture content

The amount of moisture in paper affects both print quality and the ability of the printer to feed the paper correctly. Leave paper in its original wrapper until it is time to use it. This limits the exposure of paper to moisture changes that can degrade its performance.

Condition paper before printing by storing it in its original wrapper in the same environment as the printer for 24 to 48 hours before printing. Extend the time several days if the storage or transportation environment is very different from the printer environment. Thick paper may also require a longer conditioning period.

Grain direction

Grain refers to the alignment of the paper fibers in a sheet of paper. Grain is either *grain long*, running the length of the paper, or *grain short*, running the width of the paper.

For 64–90 g/m² (17–24 lb bond) paper, grain long paper is recommended. Short grain paper is not recommended for papers less than 64 g/m² or sizes less than or equal to 182 mm (7.17 in.) wide.

Fiber content

Most high-quality xerographic paper is made from 100% chemically treated pulped wood. This content provides the paper with a high degree of stability resulting in fewer paper feeding problems and better print quality. Paper containing fibers such as cotton can negatively affect paper handling.

Unacceptable paper

The following paper types are not recommended for use with the printer:

- Chemically treated papers used to make copies without carbon paper, also known as carbonless papers, carbonless copy paper (CCP), or no carbon required (NCR) paper
- Preprinted papers with chemicals that may contaminate the printer
- Preprinted papers that can be affected by the temperature in the printer fuser
- Preprinted papers that require a registration (the precise print location on the page) greater than ± 2.3 mm (± 0.9 in.), such as optical character recognition (OCR) forms

In some cases, registration can be adjusted with a software application to successfully print on these forms.

- Coated papers (erasable bond), synthetic papers, thermal papers
- Rough-edged, rough or heavily textured surface papers, or curled papers
- Recycled papers that fail EN12281:2002 (European)
- Paper weighing less than 60 g/m^2 (16 lb)
- Multiple-part forms or documents

Selecting paper

Using appropriate paper prevents jams and helps ensure trouble-free printing.

To help avoid jams and poor print quality:

- *Always* use new, undamaged paper.
- Before loading paper, know the recommended print side. This information is usually indicated on the package.
- *Do not* use paper, paper labels, or card stock that has been cut or trimmed by hand.
- *Do not* mix sizes, types, or weights in the same source; mixing results in jams.
- *Do not* use coated papers unless they are specifically designed for electrophotographic printing.

Selecting preprinted forms and letterhead

Use these guidelines when selecting preprinted forms and letterhead:

- Use grain long for 60 to 90 g/m^2 weight paper.
- Paper that weighs at least 75 g/m^2 (20 lb) is recommended for sizes less than or equal to 182 mm (7.17 in.) wide.
- Use only forms and letterhead printed using an offset lithographic or engraved printing process.
- Avoid papers with rough or heavily textured surfaces.

Use papers printed with heat-resistant inks designed for use in xerographic copiers. The ink must be able to withstand temperatures up to 225°C (437°F) without melting or releasing hazardous emissions. Use inks that are not affected by the resin in toner. Inks that are oxidation-set or oil-based generally meet these requirements; latex inks might not. When in doubt, contact the paper supplier.

Preprinted papers such as letterhead must be able to withstand temperatures up to 225°C (437°F) without melting or releasing hazardous emissions.

Using recycled paper and other office papers

As an environmentally conscious company, Lexmark supports the use of recycled office paper produced specifically for use in laser (electrophotographic) printers. In 1998, Lexmark presented to the US government a study demonstrating that recycled paper produced by major mills in the US fed as well as non-recycled paper. However, no blanket statement can be made that *all* recycled paper will feed well.

Lexmark consistently tests its printers with recycled paper (20–100% post-consumer waste) and a variety of test paper from around the world, using chamber tests for different temperature and humidity conditions. Lexmark has found no reason to discourage the use of today's recycled office papers, but generally the following property guidelines apply to recycled paper.

- Low moisture content (4–5%)
- Suitable smoothness (100–200 Sheffield units, or 140–350 Bendtsen units, European)

Note: Some much smoother papers (such as premium 24 lb laser papers, 50–90 Sheffield units) and much rougher papers (such as premium cotton papers, 200–300 Sheffield units) have been engineered to work very well in laser printers, despite surface texture. Before using these types of paper, consult your paper supplier.

- Suitable sheet-to-sheet coefficient of friction (0.4–0.6)
- Sufficient bending resistance in the direction of feed

Recycled paper, paper of lower weight (<60 g/m² [16 lb bond]) and/or lower caliper (<3.8 mils [0.1 mm]), and paper that is cut grain-short for portrait (or short-edge) fed printers may have lower bending resistance than is required for reliable paper feeding. Before using these types of paper for laser (electrophotographic) printing, consult your paper supplier. Remember that these are general guidelines only and that paper meeting these guidelines may still cause paper feeding problems in any laser printer (for example, if the paper curls excessively under normal printing conditions).

Paper that weighs at least 75 g/m² (20 lb) is recommended for sizes less than or equal to 182 mm (7.17 in.) wide.

Storing paper

Use these paper storage guidelines to help avoid jams and uneven print quality:

- For best results, store paper where the temperature is 21°C (70°F) and the relative humidity is 40%. Most label manufacturers recommend printing in a temperature range of 18 to 24°C (65 to 75°F) with relative humidity between 40 and 60%.
- Store paper in cartons when possible, on a pallet or shelf, rather than on the floor.
- Store individual packages on a flat surface.
- Do not store anything on top of individual paper packages.

Supported paper sizes, types, and weights

The following tables provide information on standard and optional paper sources and the types of paper they support.

Note: For an unlisted paper size, select the closest *larger* listed size.

For information on card stock and labels, see the *Card Stock & Label Guide*.

Paper types and weights supported by the printer

The printer engine and manual feeder support 60–90 g/m² (16–24 lb) paper weights. The ADF supports 60–105 g/m² (16–28 lb paper). Short grain paper less than 64 g/m² (17 lb) is not supported.

Note: Paper that weighs at least 75 g/m² (20 lb) is recommended for sizes less than or equal to 182 mm (7.17 in.) wide.

| Paper type | Paper tray (250 sheets) | Manual feeder (1 sheet) | ADF (30 sheets) ¹ |
|--|-------------------------|-------------------------|------------------------------|
| Paper <ul style="list-style-type: none"> • Plain • Light • Heavy • Rough/Cotton • Recycled • Custom | ✓ | ✓ | ✓ |
| Bond | ✓ | ✓ | ✓ |
| Letterhead | ✓ | ✓ | ✓ |
| Colored Paper | ✓ | ✓ | ✓ |
| Card stock | X | ✓ | X |
| Glossy paper | X | X | X |
| Paper labels² | ✓ | ✓ | X |
| Transparencies | ✓ | ✓ | ✓ |
| Envelopes | X | ✓ | X |

¹ Available on selected models.

² Single-sided paper labels designed for laser printers are supported for occasional use: no more than 20 pages of labels a month. Vinyl, pharmacy, and dual-web labels are not supported.

Paper sizes supported by the printer

Note: Paper that weighs at least 75 g/m² (20 lb) is recommended for sizes less than or equal to 182 mm (7.17 in.) wide.

| Paper size ¹ | Dimensions | Paper tray (250 sheets) | Manual feeder (1 sheet) |
|---------------------------------|---|-------------------------|-------------------------|
| A4 | 210 x 297 mm (8.3 x 11.7 in.) | ✓ | ✓ |
| A5² | 148 x 210 mm (5.8 x 8.3 in.) | ✓ | ✓ |
| Executive | 184 x 267 mm (7.3 x 10.5 in.) | ✓ | ✓ |
| Folio | 216 x 330 mm (8.5 x 13 in.) | ✓ | ✓ |
| JIS B5² | 182 x 257 mm (7.2 x 10.1 in.) | ✓ | ✓ |
| Legal | 216 x 356 mm (8.5 x 14 in.) | ✓ | ✓ |
| Letter | 216 x 279 mm (8.5 x 11 in.) | ✓ | ✓ |
| Oficio | 216 x 340 mm (8.5 x 13.4 in.) | ✓ | ✓ |
| Statement² | 140 x 216 mm (5.5 x 8.5 in.) | ✓ | ✓ |
| Universal | 76.2 x 127 mm (3 x 5 in.) up to 216 x 356 mm (8.5 x 14 in.) | X ³ | ✓ |
| B5 Envelope | 176 x 250 mm (6.9 x 9.8 in.) | X | ✓ |
| C5 Envelope | 162 x 229 mm (6.4 x 9 in.) | X | ✓ |
| DL Envelope | 110 x 220 mm (4.3 x 8.7 in.) | X | ✓ |
| 7 3/4 Envelope (Monarch) | 98 x 191 mm (3.9 x 7.5 in.) | X | ✓ |
| 9 Envelope | 98 x 225 mm (3.9 x 8.9 in.) | X | ✓ |
| 10 Envelope | 105 x 241 mm (4.1 x 9.5 in.) | X | ✓ |
| Other Envelope | 229 x 356 mm (9 x 14 in.) | X | ✓ |

¹ If a paper size you want to use is not listed, configure a Universal paper size. For more information, see “Configuring Universal paper settings” on page 30.

² Grain long only.

³ Supports only sizes for which the paper guide tabs can be adjusted to lightly touch the side of the paper stack.

Printing

This chapter covers printing, printer reports, and job cancelation. Selection and handling of paper and specialty media can affect how reliably documents print. For more information, see “Avoiding jams” on page 136 and “Storing paper” on page 40.

Printing a document

- 1 From the printer control panel Paper menu, set the Paper Type and Paper Size to match the loaded paper.
- 2 Send the print job:

For Windows users

- a With a document open, click **File > Print**.
- b Click **Properties, Preferences, Options, or Setup**, and then adjust the settings as needed.
Note: To print on a specific size or type of paper, adjust the paper size or type settings to match the loaded paper, or select the appropriate tray or feeder.
- c Click **OK**, and then click **Print**.


For Macintosh users

- a Customize the settings as needed in the Page Setup dialog:
 - 1 With a document open, choose **File > Page Setup**.
 - 2 Choose a paper size or create a custom size to match the loaded paper.
 - 3 Click **OK**.
- b Customize the settings as needed in the Print dialog:
 - 1 With a document open, choose **File > Print**.
If necessary, click the disclosure triangle to see more options.
 - 2 From the Print dialog and pop-up menus, adjust the settings as needed.
Note: To print on a specific paper type, adjust the paper type setting to match the loaded paper, or select the appropriate tray or feeder.
 - 3 Click **Print**.

Printing on both sides of the paper (duplexing)

- 1 From the printer control panel Paper menu, set the Paper Type and Paper Size to match the loaded paper.
- 2 Send the first page of the print job. For more information, see “Printing a document” on page 43.

3 Flip the printed document, and then load it in the paper tray as shown.



4 Send the second page of the print job.

Printing specialty documents

Tips on using letterhead

- Use letterhead designed specifically for laser printers.
- Print samples on the letterhead being considered for use before buying large quantities.
- Before loading letterhead, fan the stack to prevent sheets from sticking together.
- Page orientation is important when printing on letterhead. For information on how to load letterhead, see:
 - “Loading the paper tray” on page 32
 - “Using the manual feeder” on page 35

Tips on using transparencies

Print samples on the transparencies being considered for use before buying large quantities.

When printing on transparencies:

- Feed transparencies from the standard 250-sheet tray or the manual feeder.
- Use transparencies designed specifically for laser printers. Check with the manufacturer or vendor to ensure transparencies are able to withstand temperatures up to 190°C (374°F) without melting, discoloring, offsetting, or releasing hazardous emissions.

Note: Transparencies can be printed at a temperature up to 200°C (392°F) if Transparency Weight is set to Heavy and Transparency Texture is set to Rough. If the transparencies you are using can withstand that temperature, select those settings using the Embedded Web Server, or from the printer control panel Paper menu.

- To prevent print quality problems, avoid getting fingerprints on the transparencies.
- Before loading transparencies, fan the stack to prevent sheets from sticking together.
- We recommend Lexmark part number 70X7240 for letter-size transparencies and Lexmark part number 12A5010 for A4-size transparencies.

Tips on using envelopes

Print samples on the envelopes being considered for use before buying large quantities.

When printing on envelopes:

- Load envelopes from the manual feeder.
- Use envelopes designed specifically for laser printers. Check with the manufacturer or vendor to ensure the envelopes can withstand temperatures up to 210°C (410°F) without sealing, wrinkling, curling excessively, or releasing hazardous emissions.
- For the best performance, use envelopes made from 90 g/m² (24 lb bond) paper or 25% cotton bond. Use up to 105 g/m² (28 lb bond) weight for envelopes as long as the cotton content is 25% or less. All-cotton envelopes must not exceed 90 g/m² (24 lb bond) weight.
- The minimum supported weight for envelopes is 75 g/m² (20 lb bond). For non-peel strip, self-seal envelopes, the minimum supported weight is 80 g/m² (21 lb bond).
- Use only new envelopes.
- To optimize performance and minimize jams, do not use envelopes that:
 - Have excessive curl or twist
 - Are stuck together or damaged in any way
 - Have windows, holes, perforations, cutouts, or embossing
 - Have metal clasps, string ties, or folding bars
 - Have an interlocking design
 - Have postage stamps attached
 - Have any exposed adhesive when the flap is in the sealed or closed position
 - Have bent corners
 - Have rough, cockle, or laid finishes
 - Have rough, cockle, or laid finishes
- Adjust the width guides to fit the width of the envelopes.

Note: A combination of high humidity (over 60%) and the high printing temperature may wrinkle or seal envelopes.

Tips on using labels

Print samples on the labels being considered for use before buying large quantities.

Note: Use only paper label sheets. Vinyl, pharmacy, and dual-sided labels are not supported.

For detailed information on label printing, characteristics, and design, see the *Card Stock & Label Guide* available on the Lexmark Web site at www.lexmark.com/publications.

When printing on labels:

- Use labels only in the paper tray or manual feeder. Do not use labels in the ADF.
- Use labels designed specifically for laser printers. Check with the manufacturer or vendor to verify that:
 - The labels can withstand temperatures up to 225°C (437°F) without sealing, excessive curling, wrinkling, or releasing hazardous emissions.

Note: Labels can be printed at the highest fusing temperature if Label Weight is set to Heavy. Select this setting from the Embedded Web Server or from the printer control panel Paper menu.
 - Label adhesives, face sheet (printable stock), and topcoats can withstand up to 25 psi (172 kPa) pressure without delaminating, oozing around the edges, or releasing hazardous fumes.
- Do not use labels with slick backing material.
- Use full label sheets. Partial sheets may cause labels to peel off during printing, resulting in a jam. Partial sheets also contaminate the printer and the cartridge with adhesive, and could void the printer and cartridge warranties.
- Do not use labels with exposed adhesive.
- Do not print within 1 mm (0.04 in.) of the edge of the label, of the perforations, or between die-cuts of the label.
- Be sure adhesive backing does not reach to the sheet edge. Zone coating of the adhesive at least 1 mm (0.04 in.) away from edges is recommended. Adhesive material contaminates the printer and could void the warranty.
- If zone coating of the adhesive is not possible, remove a 1.6 mm (0.06 in.) strip on the leading and driver edge, and use a non-oozing adhesive.
- Portrait orientation works best, especially when printing bar codes.

Tips on using card stock

Card stock is heavy, single-ply specialty media. Many of its variable characteristics, such as moisture content, thickness, and texture, can significantly impact print quality. Print samples on the card stock being considered for use before buying large quantities.

When printing on card stock:





- Make sure the Paper Type is Card Stock.
- Select the appropriate Paper Texture setting.
- Be aware that preprinting, perforation, and creasing may significantly affect the print quality and cause jams or other paper handling problems.
- Check with the manufacturer or vendor to ensure the card stock can withstand temperatures up to 210°C (410°F) without releasing hazardous emissions.
- Do not use preprinted card stock manufactured with chemicals that may contaminate the printer. Preprinting introduces semi-liquid and volatile components into the printer.
- Use grain short card stock when possible.

Printing information pages

See “Printing a menu settings page” on page 22 and “Printing a network setup page” on page 22 for more information on printing these pages.



Printing a font sample list

To print samples of the fonts currently available for your printer:

- 1 Make sure the printer is on and **Ready** appears.
 - 2 From the printer control panel, press .
 - 3 Press the arrow buttons until **Reports** appears, and then press .
 - 4 Press the arrow buttons until **Print Fonts** appears, and then press .
 - 5 Press the arrow buttons until **PCL Fonts** or **PostScript Fonts** appears, and then press .
- After the font sample list prints, **Ready** appears.

Canceling a print job

Canceling a print job from the printer control panel


- 1 Press .
Stopping... appears, followed by **Cancel Print Job**.
- 2 Press .

Canceling a print job from the computer

To cancel a print job, do one of the following:

For Windows users

In Windows Vista:

- 1 Click .
- 2 Click **Control Panel**.
- 3 Click **Hardware and Sound**.
- 4 Click **Printers**.
- 5 Double-click the printer icon.
- 6 Select the job to cancel.
- 7 From the keyboard, press **Delete**.

In Windows XP:

- 1 Click **Start**.
- 2 From **Printers and Faxes**, double-click the printer icon.
- 3 Select the job to cancel.
- 4 From the keyboard, press **Delete**.

From the Windows taskbar:

When you send a job to print, a small printer icon appears in the right corner of the taskbar.

- 1 Double-click the printer icon.
A list of print jobs appears in the printer window.
- 2 Select a job to cancel.
- 3 From the keyboard, press **Delete**.

For Macintosh users



In Mac OS X version 10.5:

- 1 From the Apple menu, choose **System Preferences**.
- 2 Click **Print & Fax**, and then double-click the printer icon.
- 3 From the printer window, select the job to cancel.
- 4 From the icon bar at the top of the window, click the **Delete** icon.

In Mac OS X version 10.4 and earlier:



- 1 From the Go menu, choose **Applications**.
- 2 Double-click **Utilities**, and then double-click **Print Center** or **Printer Setup Utility**.
- 3 Double-click the printer icon.
- 4 From the printer window, select the job to cancel.
- 5 From the icon bar at the top of the window, click the **Delete** icon.

Copying

| ADF | Scanner glass |
|--|---|
|  <p>Use the ADF for multiple-page documents. Note: The ADF is available on selected models only.</p> |  <p>Use the scanner glass for single pages, small items (such as postcards or photos), transparencies, photo paper, or thin media (such as magazine clippings).</p> |


Making copies


Making a quick copy

- 1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass.
Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.
- 2 If you are loading a document into the ADF, then adjust the paper guides.
- 3 From the printer control panel, press .
- 4 If you placed the document on the scanner glass and have additional pages to copy, then place the next page on the scanner glass, and then press **1** on the keypad. Otherwise, press **2** on the keypad.
- 5 Press  to return to **Ready**.



Copying using the ADF

- 1 Load an original document faceup, short edge first into the ADF.
Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.
- 2 Adjust the paper guides.
- 3 From the printer control panel, press **Copy**, or use the keypad to enter the number of copies.
- 4 Change the copy settings as needed.

5 From the printer control panel, press .


6 Press  to return to **Ready**.


Copying using the scanner glass


- 1 Place an original document facedown on the scanner glass in the upper left corner.
- 2 From the printer control panel, press the **Copy** button, or use the keypad to enter the number of copies.
- 3 Change the copy settings as needed.
- 4 From the printer control panel, press .
- 5 Place the next document on the scanner glass, and then press **1** on the keypad. Otherwise, press **2** on the keypad.
- 6 Press  to return to **Ready**.

Copying on both sides of the paper (duplexing)


- 1 Load a document facedown on the scanner glass.



- 2 From the printer control panel, press the **Copy** button.
- 3 Press  to copy the first side of the original document.
- 4 Flip the original document, and then load it facedown on the scanner glass.










- 5 Flip the copy, and then load it in the paper tray.








- 6 Press **1** on the keypad to copy the second side of the original document.
- 7 Press **2** to indicate that there are no more pages to copy.

Copying photos





- 1 Place a photo facedown on the scanner glass in the upper left corner.
- 2 From the printer control panel, press .
- 3 Press the arrow buttons until **Settings** appears, and then press .
- 4 Press the arrow buttons until **Copy Settings** appears, and then press .
- 5 Press the arrow buttons until **Content** appears, and then press .
- 6 Press the arrow buttons until **Photo** appears, and then press .
- Submitting Changes...** appears.
- 7 Use the printer control panel buttons to change other copy settings as needed.
- 8 Press  repeatedly until **Ready** appears.
- 9 Press the **Copy** button.
- 10 Use the keypad to select the number of copies you want.
- 11 Press .
- 12 If you want to scan another photo, place it on the scanner glass, and then press **1** on the keypad. Otherwise, press **2** on the keypad.

Copying on specialty media

Copying to transparencies








- 1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass.
Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.
- 2 If you are loading a document into the ADF, then adjust the paper guides.
- 3 From the printer control panel, press the **Copy** button.
- 4 From the Copy area, press the **Options** button.
- 5 Press the arrow buttons until **Paper Source** appears, and then press .
- 6 Press the arrow buttons until the paper source containing the transparencies appears, and then press .
- 7 Press .
- 8 Change the copy settings as needed.
- 9 Press .
- 10 If you placed the document on the scanner glass and have additional pages to copy, then place the next page on the scanner glass, and then press **1** on the keypad. Otherwise, press **2** on the keypad.
- 11 Press  to return to **Ready**.

Copying to letterhead

- 1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass.
Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.
- 2 If you are loading a document into the ADF, then adjust the paper guides.
- 3 From the printer control panel, press the **Copy** button.
- 4 Press the **Options** button.
- 5 Press the arrow buttons until **Paper Source** appears, and then press .
- 6 Press the arrow buttons until the paper source containing the letterhead appears, and then press .
- 7 Change the copy settings as needed.
- 8 Press .
- 9 If you placed the document on the scanner glass and have additional pages to copy, then place the next page on the scanner glass, and then press **1** on the keypad. Otherwise, press **2** on the keypad.
- 10 Press  to return to **Ready**.

Customizing copy settings



Copying from one size to another





- 1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass.
Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.
- 2 If you are loading a document into the ADF, then adjust the paper guides.
- 3 From the printer control panel, press the **Copy** button.
- 4 Press the **Options** button.
Original Size appears.
- 5 Press .
- 6 Press the arrow buttons until the size of the original document appears, and then press .
- 7 Press the arrow buttons until **Paper Source** appears, and then press .
- 8 Press the arrow buttons until the tray or source containing the size you want the copy to be appears, and then press .
- Note:** If you select a paper size that is different from the original size, then the printer will scale the size automatically.
- 9 Press .
- 10 Change the copy settings as needed.
- 11 Press .
- 12 If you placed the document on the scanner glass and have additional pages to copy, then place the next page on the scanner glass, and then press **1** on the keypad. Otherwise, press **2** on the keypad.
- 13 Press  to return to **Ready**.

Reducing or enlarging copies




Copies can be reduced to 50% of the original document size or enlarged to 400% of the original document size. The factory default setting for Scale is Auto[100%]. If you leave Scale set to Auto[100%], then the content of your original document will be scaled to fit the size of the paper onto which you are copying.

To reduce or enlarge a copy:






- 1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass.
Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.
- 2 If you are loading a document into the ADF, then adjust the paper guides.
- 3 From the printer control panel, press the **Copy** button.
- 4 Press the **Options** button, and then press .
- 5 Press the arrow buttons until **Scale** appears, and then press .

- 6 Press the arrow buttons until the scale option you want appears, and then press .
If you selected Custom, select a custom size:
 - a Press the arrow buttons to decrease or increase the size, or enter a number between 50 and 400 on the keypad.
 - b Press .
- 7 Press .
- 8 If you placed the document on the scanner glass and have additional pages to copy, then place the next page on the scanner glass, and then press **1** on the keypad. Otherwise, press **2** on the keypad.
- 9 Press  to return to **Ready**.

Making a copy lighter or darker

- 1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass.
Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.
- 2 If you are loading a document into the ADF, then adjust the paper guides.
- 3 From the printer control panel, press the **Copy** button.
- 4 Press the **Options** button.
- 5 Press the arrow buttons until **Darkness** appears.
- 6 Press the arrow buttons to make the copy lighter or darker.
- 7 Press .
- 8 Press .
- 9 If you placed the document on the scanner glass and have additional pages to copy, then place the next page on the scanner glass, and then press **1** on the keypad. Otherwise, press **2** on the keypad.
- 10 Press  to return to **Ready**.

Adjusting copy quality

- 1 From the printer control panel, press .
 - 2 Press the arrow buttons until **Settings** appears, and then press .
 - 3 Press the arrow buttons until **Copy Settings** appears, and then press .
 - 4 Press the arrow buttons until **Content** appears, and then press .
 - 5 Press the arrow buttons until the setting appears that best represents what you are copying:
 - **Text**—Used for original documents that are mostly text or line art
 - **Text/Photo**—Used when the original documents are a mixture of text and graphics or pictures
 - **Photograph**—Used when the original document is a high-quality photograph or inkjet print
 - 6 Press .
- Submitting Changes...** appears, and then the setting you selected becomes the new default copy quality setting.

Collating copies

If you print multiple copies of a document, then you can choose to print each copy as a set (collated) or to print the copies as groups of pages (not collated).

Collated



Not collated



If you want to collate your copies, then select On. If you do not want to collate your copies, then select Off.

To select a Collate setting:


- 1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass.
Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.
- 2 If you are loading a document into the ADF, then adjust the paper guides.
- 3 From the printer control panel, press the **Copy** button.
- 4 Press the **Options** button.
- 5 Press the arrow buttons until **Collate** appears, and then press .
- 6 Press the arrow buttons until **On** [1, 2, 1, 2, 1, 2] or **Off** [1, 1, 1, 2, 2, 2] appears, and then press to select one.
- 7 Press .
- 8 If you placed the document on the scanner glass and have additional pages to copy, then place the next page on the scanner glass, and then press **1** on the keypad. Otherwise, press **2** on the keypad.
- 9 Press to return to **Ready**.


Copying multiple pages onto a single sheet

In order to save paper, you can copy either two or four consecutive pages of a multiple-page document onto a single sheet of paper.

Notes:

- The Paper Size must be set to Letter, Legal, A4, or B5 JIS.
 - The Copy Size must be set to 100%.
- 1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass.
Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.
 - 2 If you are loading a document into the ADF, then adjust the paper guides.
 - 3 From the printer control panel, press the **Copy** button.
 - 4 Press the **Options** button.
 - 5 Press the arrow buttons until **Paper Saver** appears, and then press .

6 Select the output you want, and then press .

For example, if you have four portrait-oriented original documents that you want copied to the same side of one sheet, then select **4 on 1 Portrait**, and then press .

7 Press .

8 If you placed the document on the scanner glass and have additional pages to copy, then place the next page on the scanner glass, and then press **1** on the keypad. Otherwise, press **2** on the keypad.

9 Press  to return to **Ready**.

Pausing the current print job to make copies

When the “Allow priority copies” setting is On, the printer pauses the current print job when you start a copy job.

Note: The “Allow priority copies” setting must be set to On in the Copy Settings menu so that you can pause the current print job and make copies.

1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass.

Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.

2 If you are loading a document into the ADF, then adjust the paper guides.

3 From the printer control panel, press .

4 If you placed the document on the scanner glass and have additional pages to copy, then place the next page on the scanner glass, and then press **1** on the keypad. Otherwise, press **2** on the keypad.


5 Press  to return to **Ready**.

Canceling a copy job

A copy job can be canceled when the document is in the ADF, on the scanner glass, or while the document is printing.

1 From the printer control panel, press .

Stopping appears, followed by **Cancel Job**.

2 Press  to cancel the job.

Canceling appears.



The printer clears all pages in the ADF or printer and then cancels the job.

Improving copy quality

| Question | Tip |
|------------------------------|---|
| When should I use Text mode? | <ul style="list-style-type: none">• Use text mode when text preservation is the main goal of the copy, and preserving images copied from the original document is not a concern.• Text mode is recommended for receipts, carbon copy forms, and documents that contain only text or fine line art. |

| Question | Tip |
|------------------------------------|---|
| When should I use Text/Photo mode? | <ul style="list-style-type: none">• Use Text/Photo mode when copying an original document that contains a mixture of text and graphics.• Text/Photo mode is recommended for magazine articles, business graphics, and brochures. |
| When should I use Photograph mode? | Use Photograph mode when the original document is a high-quality print or photograph. |

E-mailing

| ADF | Scanner glass |
|---|---|
|  <p>Use the ADF for multiple-page documents.</p> <p>Note: The ADF is available on selected models only.</p> |  <p>Use the scanner glass for single pages, small items (such as postcards or photos), transparencies, photo paper, or thin media (such as magazine clippings).</p> |

You can use the printer to e-mail scanned documents to one or more recipients. There are three ways to send and e-mail from the printer. You can type the e-mail address, use a shortcut number, or use the address book.

Getting ready to e-mail

Setting up the e-mail function

For e-mail to operate, it must be turned on in the printer settings and have a valid IP address or gateway address. To set up the e-mail function:

- 1 Type the printer IP address into the address field of your Web browser.
Note: If you do not know the IP address of the printer, then print a network setup page and locate the address in the TCP/IP section.
- 2 Click **Settings**.
- 3 Click **E-mail/FTP Settings**.
- 4 Click **E-mail Server Setup**.
- 5 Change the e-mail settings as needed.
- 6 Click **Submit**.

Setting up the address book

- 1 Type the printer IP address into the address field of your Web browser.
Note: If you do not know the IP address of the printer, then print a network setup page and locate the address in the TCP/IP section.
- 2 Click **Settings**.

- 3 Click **E-mail/FTP Settings**.
- 4 Click **Manage E-mail Shortcuts**.
- 5 Fill in the fields with the appropriate information.
- 6 Click **Add**.

Creating an e-mail shortcut using the Embedded Web Server


- 1 Type the printer IP address into the address field of your Web browser.
Note: If you do not know the IP address of the printer, then print a network setup page and locate the IP address in the TCP/IP section.
- 2 Click **Settings**.
- 3 Under Other Settings, click **Manage Shortcuts**.
- 4 Click **E-mail Shortcut Setup**.
- 5 Type a unique name for the recipient, and then enter the e-mail address.
Note: If you are entering multiple addresses, then separate each address with a comma (,).
- 6 Select the scan settings (Format, Content, Color, and Resolution).
- 7 Enter a shortcut number, and then click **Add**.
If you enter a number that is already in use, then you are prompted to select another number.

E-mailing a document

Sending an e-mail using the keypad


- 1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass.
Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.
- 2 If you are loading a document into the ADF, then adjust the paper guides.
- 3 From the printer control panel, press the **Scan/Email** button.
Scan to E-mail appears.
- 4 Press .
Search appears.
Note: If there are no entries in the address book, then **Manual Entry** appears.
- 5 Press to search the address book, or press the arrow buttons until **Manual** appears, and then press to select or enter an e-mail address.

Using the address book


- a After selecting **Search** on the printer control panel, press the arrow buttons until the address you want appears.
- b Press repeatedly until **Entry Saved** appears, followed by **Another E-mail? 1=Yes 2=NO**.
- c Press **1** to search for another address, or press **2** to end the search.
After you press **2**, **Press Start To Begin** appears.
- d Press .

Manually entering an e-mail address





After selecting **Manual** on the printer control panel, **To** appears on the first line, and a cursor appears on the second line.

- a Press the button on the keypad that corresponds with the number or letter you want. The first time you press the button, the number for that button appears. When you press the button again, one of the letters assigned to that button appears.
- b Press the right arrow button to move to the next space, or wait a few seconds, and the cursor will move to the next space.
- c Once the e-mail address is entered, press .
- Entry Saved** appears, followed by **Another E-mail? 1=Yes 2=NO**.
- d Press **1** to enter another address, or press **2** to stop adding addresses.
After you press **2**, **Press Start To Begin** appears.
- e Press .

Sending an e-mail using a shortcut number



- 1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass.
Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.
- 2 If you are loading a document into the ADF, then adjust the paper guides.
- 3 From the printer control panel, press the **Scan/Email** button.
Scan to E-mail appears.
- 4 Press .
- Search** appears.
Note: If there are no entries in the address book, then **Manual Entry** appears.
- 5 Press , and then enter the recipient's shortcut number.
- 6 Press **1** to enter another shortcut, or press **2** to end the shortcut entry.
- 7 Press .

Sending an e-mail using the address book

- 1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass.
Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.
- 2 If you are loading a document into the ADF, then adjust the paper guides.
- 3 From the printer control panel, press the **Scan/Email** button.
Scan to E-mail appears.
- 4 Press .
Search appears.
Note: If there are no entries in the address book, then **Manual Entry** appears.
- 5 Press  to search the address book.
- 6 Press the arrow buttons until the address you want appears, and then press .
- 7 Press **1** to search for another address, or press **2** to end the search.
After you press **2**, **Press Start To Begin** appears.
- 8 Press .

Canceling an e-mail



An e-mail can be canceled when the document is being scanned from the ADF or the scanner glass.

- 1 From the printer control panel, press .
Cancel Scan Job appears.
- 2 Press  to cancel the job.
Canceling appears.

The printer clears all pages in the ADF and then cancels the job.


Faxing

Note: The fax feature is available only on selected printer models.

| ADF | Scanner glass |
|---|---|
|  <p>Use the ADF for multiple-page documents.</p> <p>Note: The ADF is available on selected models only.</p> |  <p>Use the scanner glass for single pages, small items (such as postcards or photos), transparencies, photo paper, or thin media (such as magazine clippings).</p> |

Getting the printer ready to fax

The following connection methods may not be applicable in all countries or regions.

 **CAUTION—SHOCK HAZARD:** Do not use the fax feature during a lightning storm. Do not set up this product or make any electrical or cabling connections, such as the fax feature, power cord, or telephone, during a lightning storm.

Initial fax setup

Many countries and regions require outgoing faxes to contain the following information in a margin at the top or bottom of each transmitted page, or on the first page of the transmission: station name (identification of the business, other entity, or individual sending the message) and station number (telephone number of the sending fax machine, business, other entity, or individual).

To enter your fax setup information, use the printer control panel, or use your browser to access the Embedded Web Server and then enter the Settings menu.

Note: If you do not have a TCP/IP environment, then you must use the printer control panel to enter your fax setup information.

Using the printer control panel for fax setup

When the printer is turned on for the first time or if the printer has been off for an extended time, a series of start-up screens appear. If the printer has fax capabilities, then the following screens appear:

- Station Name
- Station Number

- 1 When **Station Name** appears, enter the name to be printed on all outgoing faxes.
 - a Press the button on the numeric keypad that corresponds with the number or letter you want. The first time you press the button, the number for that button appears. When you press the button again, one of the letters assigned to that button appears.
 - b Press the right arrow button to move to the next space, or wait a few seconds and the cursor will move to the next space.
- 2 After entering the Station Name, press .
- The display changes to Station Number.
- 3 When **Station Number** appears, enter the printer fax number.
 - a Press the button on the numeric keypad that corresponds with the number you want.
 - b Press the right arrow button to move to the next space, or wait a few seconds and the cursor will move to the next space.
- 4 After entering the Station Number, press .

Using the Embedded Web Server for fax setup

- 1 Type the printer IP address into the address field of your Web browser.

Note: If you do not know the IP address of the printer, then print a network setup page and locate the address in the TCP/IP section.
- 2 Click **Settings**.
- 3 Click **Fax Settings**.
- 4 Click **Analog Fax Setup**.
- 5 Click inside the Station Name box, and then enter the name to be printed on all outgoing faxes.
- 6 Click inside the Station Number box, and then enter the printer fax number.
- 7 Click **Submit**.

Choosing a fax connection

You can connect the printer with equipment such as a telephone, an answering machine, or a computer modem. To determine the best way to set up the printer, see the following table.


Notes:


- The printer is an analog device that works best when directly connected to the wall outlet. Other devices (such as a telephone or answering machine) can be successfully attached to pass through the printer, as described in the setup steps.
- If you want a digital connection such as ISDN, DSL, or ADSL, a third-party device (such as a DSL filter) is required. Contact your DSL provider for a DSL filter. The DSL filter removes the digital signal on the telephone line that can interfere with the ability of the printer to fax properly.
- You *do not* need to attach the printer to a computer, but you *do* need to connect it to an analog telephone line to send and receive faxes.

| Equipment and service options | Fax connection setup |
|---|---|
| Connect directly to the telephone line | See “Connecting to an analog telephone line” on page 64 |
| Connect to a Digital Subscriber Line (DSL or ADSL) service | See “Connecting to a DSL service” on page 64. |
| Connect to a Private Branch eXchange (PBX) or Integrated Services Digital Network (ISDN) system | See “Connecting to a PBX or ISDN system” on page 65. |
| Use a Distinctive Ring service | See “Connecting to a distinctive ring service” on page 65. |
| Connect to a telephone line, telephone, and answering machine | See “Connecting the printer and a telephone or answering machine to the same telephone line” on page 66 |
| Connect through an adapter used in your area | See “Connecting to an adapter for your country or region” on page 68. |
| Connect to a computer with a modem | See “Connecting to a computer with a modem” on page 72. |

Connecting to an analog telephone line


If your telecommunications equipment uses a US-style (RJ11) telephone line, then follow these steps to connect the equipment:

- 1 Connect one end of the telephone cable that came with the printer to the printer LINE port .
- 2 Connect the other end of the telephone cable to an active analog telephone wall jack.




Connecting to a DSL service

If you subscribe to a DSL service, then contact the DSL provider to obtain a DSL filter and telephone cord, and then follow these steps to connect the equipment:

- 1 Connect one end of the telephone cable that came with the printer to the printer LINE port .
- 2 Connect the other end of the telephone cable to the DSL filter.


Note: Your DSL filter may look different than the one in the illustration.

3 Connect the DSL filter cable to an active telephone wall jack.



Connecting to a PBX or ISDN system

If you use a PBX or ISDN converter or terminal adapter, then follow these steps to connect the equipment:

- 1** Connect one end of the telephone cable that came with the printer to the printer LINE port .
- 2** Connect the other end of the telephone cable to the port designated for fax and telephone use.

Notes:


- Make sure the terminal adapter is set to the correct switch type for your region.
- Depending on the ISDN port assignment, you may have to connect to a specific port.
- When using a PBX system, make sure the call waiting tone is off.
- When using a PBX system, dial the outside line prefix before dialing the fax number.
- For more information on using the fax with a PBX system, see the documentation that came with your PBX system.


Connecting to a distinctive ring service

A distinctive ring service may be available from your telephone service provider. This service allows you to have multiple telephone numbers on one telephone line with each telephone number having a different ring pattern. This may be useful for distinguishing between fax and voice calls.







The default printer settings enable the printer to receive faxes using all the ring patterns. If you want to use only one ring pattern to receive faxes, you must disable the other ring patterns.

If you subscribe to a distinctive ring service, follow these steps to connect the equipment:

- 1** Connect one end of the telephone cable that came with the printer to the printer LINE port .
- 2** Connect the other end of the telephone cable to an active analog telephone wall jack.





To disable a distinctive ring pattern:


- 1 From the printer control panel, press .
- 2 Press the arrow buttons until **Settings** appears, and then press .
- 3 Press the arrow buttons until **Fax Settings** appears, and then press .
- 4 Press the arrow buttons until **Distinctive Rings** appears, and then press .
- 5 Press the arrow buttons until a distinctive ring pattern you do not want to use appears, and then press .
- 6 Press the arrow buttons until **Off** appears, and then press .


Note: If you disable all the distinctive ring patterns, then the printer will not receive faxes.

Connecting the printer and a telephone or answering machine to the same telephone line

- 1 Connect one end of the telephone cable that came with the printer to the printer LINE port .
- 2 Connect the other end of the telephone cable to an active analog telephone wall jack .




- 3 Remove the plug from the printer EXT port .




- 4 Connect your telecommunications equipment directly to the printer EXT port .

Use one of the following methods:


Answering machine



Answering machine and telephone



Telephone or a telephone with an integrated answering machine



Connecting to an adapter for your country or region


The following countries or regions may require a special adapter to connect the telephone cable to the active telephone wall jack:


Country/region

- Austria
- Cyprus
- Denmark
- Finland
- France
- Germany
- Ireland
- Italy
- New Zealand
- Netherlands
- Norway
- Portugal
- Sweden
- Switzerland
- United Kingdom

Countries or regions except Austria, Germany, and Switzerland


For some countries or regions, a telephone line adapter is included in the box. Use this adapter to connect an answering machine, telephone, or other telecommunications equipment to the printer.

- 1 Connect one end of the telephone cable that came with the printer to the printer LINE port .

Note: There is a special RJ-11 plug installed in the printer EXT port . Do not remove this plug. It is necessary for the proper operation of the fax function and connected telephones.



- 2 Connect the other end of the telephone cable to the adapter, and then connect the adapter to the active telephone wall jack.

Note: Your telephone adapter may look different than the one shown. It will fit the wall jack used in your location.





- 3 Connect the answering machine or telephone to the adapter.

Use one of the following methods:





Austria, Germany, and Switzerland

There is a special RJ-11 plug installed in the printer EXT port . Do not remove this plug. It is necessary for the proper operation of the fax function and connected telephones.




Connecting to a telephone wall jack in Germany


Note: There is a special RJ-11 plug installed in the printer EXT port . Do not remove this plug. It is necessary for the proper operation of the fax function and connected telephones.

- 1 Connect one end of the telephone cable that came with the printer to the printer LINE port .
- 2 Connect the other end of the telephone cable to the adapter.


Note: Your telephone adapter may look different than the one shown. It will fit the wall jack used in your location.




3 Connect the adapter into the N slot of an active analog telephone wall jack.



4 If you would like to use the same line for both fax and telephone communication, then connect a second telephone line (not provided) between the telephone and the F slot of an active analog telephone wall jack.




5 If you would like to use the same line for recording messages on your answering machine, then connect a second telephone cable (not provided) between the answering machine and the other N slot of the active analog telephone wall jack.





Connecting to a computer with a modem


Connect the printer to a computer with a modem to send faxes from the software program.

Note: Setup steps may vary depending on your country or region.


- 1 Connect one end of the telephone cable that came with the printer to the printer LINE port .
- 2 Connect the other end of the telephone cable to an active analog telephone wall jack.





- 3 Remove the protective plug from the printer EXT port .



- 4 Connect your telephone to the computer telephone jack.



- 5 Connect an additional telephone cord (not provided) from the computer modem to the printer EXT port .



Setting the outgoing fax name and number

To have the designated fax name and fax number printed on outgoing faxes:

- 1 Type the printer IP address into the address field of your Web browser.
Note: If you do not know the IP address of the printer, then print a network setup page and locate the address in the TCP/IP section.
- 2 Click **Settings**.
- 3 Click **Fax Settings**.
- 4 Click **Analog Fax Setup**.
- 5 Click inside the Station Name box, and then enter the name to be printed on all outgoing faxes.
- 6 Click inside the Station Number box, and then enter the printer fax number.
- 7 Click **Submit**.

Setting the date and time

If the date or time that is printed on a fax job is incorrect, then you can reset the date and time. Then the correct date and time will be printed on every fax job. To set the date and time:

- 1 Type the printer IP address into the address field of your Web browser.
Note: If you do not know the IP address of the printer, then print a network setup page and locate the address in the TCP/IP section.
- 2 Click **Settings**.
- 3 Click **Security**.
- 4 Click **Set Date and Time**.

5 In the Network Time Protocol section, select **Enable NTP**.

Note: If you prefer to set the date and time manually, click inside the Manually Set Date & Time box, and then enter the current date and time.

6 Verify that the time zone is correct.

7 Click **Submit**.

Sending a fax


Sending a fax using the printer control panel

1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass.




Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.

2 If you are loading a document into the ADF, then adjust the paper guides.

3 From the printer control panel, press the **Fax** button.

4 Enter the fax number, and then press .

Notes:

- To cause a two- or three-second pause in a fax number, press the **Redial/Pause** button. The dial pause appears as a comma on the “Fax to” line. Use this feature if you need to dial an outside line first.
- Press  to move the cursor to the left and delete a number.
- To use a fax shortcut, press , and then press the arrow buttons until the fax shortcut you want appears. Press .

5 Press **1** to enter another fax number, or press **2** to end fax number entry.

6 Press .

Sending a fax using the computer

Faxing from a computer lets you send electronic documents without leaving your desk. This gives you the flexibility of faxing documents directly from software programs.

For Windows users

1 With a file open, click **File > Print**.

2 Click **Properties, Preferences, Options, or Setup**.

3 Click the **Other Options** tab, and then click **Fax**.

4 On the Fax screen, type the name and number of the fax recipient.

5 Click **OK**, and then click **OK** again.

6 Click **Send**.

For Mac OS X version 10.5 users

The steps for sending a fax from the computer vary depending on your operating system. For specific instructions using other Macintosh OS versions, see your Mac OS Help.

1 With a document open, choose **File > Print**.

2 From the Printer pop-up menu, choose your printer.

Note: In order to see the fax options on the Print dialog, you must use the fax driver for your printer. To install the fax driver, choose **Add a printer**, and then install the printer again with a different name, choosing the fax version of the driver.

3 Enter the fax information (for example, the name and number of the fax recipient).

4 Click **Fax**.

Sending a fax at a scheduled time

1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass.

Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.

2 If you are loading a document into the ADF, then adjust the paper guides.

3 From the printer control panel, press the **Fax** button.

4 Enter the fax number, and then press

5 From the Fax area, press the **Options** button.

6 Press the arrow buttons until **Delayed Send** appears, and then press .

7 Using the keypad, enter the time you want to send the fax.

If the printer clock is set to 12 Hour format, then use the arrow buttons to select **AM** or **PM**.

8 Press .

9 Using the keypad, enter the date you want to send the fax.

10 Press .

11 Press

Creating shortcuts

Creating a fax destination shortcut using the Embedded Web Server

Instead of entering the entire phone number of a fax recipient on the printer control panel each time you want to send a fax, you can create a permanent fax destination and assign a shortcut number. A shortcut can be created to a single fax number or a group of fax numbers.

- 1 Type the printer IP address into the address field of your Web browser.

Note: If you do not know the IP address of the printer, then print a network setup page and locate the IP address in the TCP/IP section.

- 2 Click **Settings**.

- 3 Click **Manage Shortcuts**.

Note: A password may be required. If you do not have an ID and password, get one from your system support person.

- 4 Click **Fax Shortcut Setup**.

- 5 Type a unique name for the shortcut, and then enter the fax number.

To create a multiple-number shortcut, enter the fax numbers for the group.

Note: Separate each fax number in the group with a semicolon (;).

- 6 Assign a shortcut number.

If you enter a number that is already in use, then you are prompted to select another number.


- 7 Click **Add**.


Creating a fax destination shortcut using the printer control panel

- 1 Press .

Directory Search appears.

- 2 Press the arrow buttons until **Add** appears, and then press .

- 3 Press the arrow buttons until **Fax Number** appears, and then press .


- 4 Enter the fax number, and then press .

- 5 Press **1** to enter another fax number, or press **2** to end fax number entry.

- 6 After selecting **2=NO**, **Enter Name** appears.

- a Press the button on the keypad that corresponds with the letter you want. The first time you press the button, the number for that button appears. When you press the button again, one of the letters assigned to that button appears.

- b Press the right arrow button to move to the next space, or wait a few seconds and the cursor will move to the next space.

- c Once the fax name is entered, press .

Save as Shortcut appears.

- d Enter the shortcut number, and then press .



Using shortcuts and the address book

Using fax shortcuts

Fax shortcuts are just like the speed dial numbers on a telephone or fax machine. You can assign shortcut numbers when creating permanent fax destinations. You create permanent fax destinations or speed dial numbers in the Manage Shortcuts link located under Settings on the Embedded Web Server. A shortcut number (1–99999) can contain a single recipient or multiple recipients. By making a group fax destination with a shortcut number, you can easily fax broadcast information to an entire group.

- 1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass.

Note: Do not place postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.

- 2 If you are loading a document into the ADF, then adjust the paper guides.
- 3 Press , and then enter the shortcut number.
- 4 Press .

Using the address book

Note: If the address book feature is not enabled, contact your system support person.




- 1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass.

Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.

- 2 If you are loading a document into the ADF, then adjust the paper guides.
- 3 From the printer control panel, press the **Fax** button.
To: appears on the first line, and the time and date appear on the second line.

- 4 Press the  button.


Search appears on the second line.

- 5 To send your fax, press .
- 6 Press the arrow buttons until the fax number you want appears, and then press .
- 7 To send your fax, press .


Customizing fax settings

Changing the fax resolution

Adjusting the resolution setting changes the quality of the fax. Settings range from Standard (fastest speed) to Super Fine (slowest speed, highest resolution).

- 1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass.
Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.
- 2 If you are loading a document into the ADF, then adjust the paper guides.
- 3 From the printer control panel, press the **Fax** button.
- 4 Enter the fax number using the keypad.
- 5 Press the **Options** button.
- 6 Press the arrow buttons until Resolution appears, and then press .
- 7 Press the arrow buttons to change the resolution, and then press .
- 8 Press .

Making a fax lighter or darker

- 1 Load an original document faceup, short edge first into the ADF or facedown on the scanner glass.
Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.
- 2 If you are loading a document into the ADF, then adjust the paper guides.
- 3 From the printer control panel, press the **Fax** button.
- 4 Enter the fax number using the keypad.
- 5 Press the **Options** button.
- 6 Press the arrow buttons until **Darkness** appears, and then press .
- 7 Press the arrow buttons to make the fax lighter or darker, and then press .
- 8 Press .

Blocking junk faxes

- 1 Type the printer IP address into the address field of your Web browser.
Note: If you do not know the IP address of the printer, then print a network setup page and locate the IP address in the TCP/IP section.
- 2 Click **Settings**.
- 3 Click **Fax Settings**.

4 Click **Analog Fax Setup**.

5 Select **Block No Name Fax**.

This option blocks all incoming faxes that have a private caller ID or no fax station name.

6 In the Banned Fax List field, enter the phone numbers or fax station names of specific fax callers you want to block.

7 Click **Submit**.

Viewing a fax log

1 Type the printer IP address into the address field of your Web browser.


Note: If you do not know the IP address of the printer, then print a network setup page and locate the IP address in the TCP/IP section.

2 Click **Reports**.


3 Click **Fax Job Log** or **Fax Call Log**.

Canceling an outgoing fax

A fax can be canceled when the document is in the ADF or on the scanner glass. To cancel a fax:

1 From the printer control panel, press .

Stopping appears, and then **Cancel Job** appears.

2 Press  to cancel the job.

Canceling appears. The printer clears all pages in the ADF or printer and then cancels the job.

Understanding fax options

Original Size

This option lets you choose the size of the documents you are going to fax.

Content

This option tells the printer the original document type. Content affects the quality and size of your scan to fax.

- **Text**—Emphasizes sharp, black, high-resolution text against a clean, white background
- **Text/Photo**—Used when the original documents are a mixture of text and graphics or pictures
- **Photograph**—Tells the scanner to pay extra attention to graphics and pictures. This setting increases the time it takes to scan, but emphasizes a reproduction of the full dynamic range of tones in the original document. This increases the amount of information saved.

Resolution

This option increases how closely the scanner examines the document you want to fax. If you are faxing a photo, a drawing with fine lines, or a document with very small text, increase the Resolution setting. This increases the amount of time required for the scan and increases the quality of the fax output.

- **Standard**—Suitable for most documents
- **Fine**—Recommended for documents with small print
- **Super fine**—Recommended for original documents with fine detail

Darkness

This option adjusts how light or dark your faxes will turn out in relation to the original document.

Improving fax quality

| Question | Tip |
|------------------------------------|---|
| When should I use Text mode? | <ul style="list-style-type: none">• Use Text mode when text preservation is the main goal of the fax, and preserving images copied from the original document is not a concern.• Text mode is recommended for faxing receipts, carbon copy forms, and documents that contain only text or fine line art. |
| When should I use Text/Photo mode? | <ul style="list-style-type: none">• Use Text/Photo mode when faxing an original document that contains a mixture of text and graphics.• Text/Photo mode is recommended for magazine articles, business graphics, and brochures. |
| When should I use Photograph mode? | Use Photograph mode when faxing photos printed on a laser printer or taken from a magazine or newspaper. |

Forwarding a fax

This option lets you print and forward received faxes to a fax number.

- 1 Type the printer IP address into the address field of your Web browser.

Note: If you do not know the IP address of the printer, then print a network setup page and locate the address in the TCP/IP section.

- 2 Click **Settings**.

- 3 Click **Fax Settings**.

- 4 Click **Analog Fax Setup**.

- 5 Click inside the **Fax Forwarding** box, and then select one of the following:

- Print
- Print and Forward
- Forward



- 6 From the **Forward to** list, select **Fax**.

7 Click inside the **Forward to Shortcut** box, and then enter the shortcut number where you want the fax forwarded.

Note: The shortcut number must be a valid shortcut number for the setting that was selected in the “Forward to” box.

8 Click **Submit**.

Scanning to a computer

| ADF | Scanner glass |
|--|---|
|  <p>Use the ADF for multiple-page documents. Note: The ADF is available on selected models only.</p> |  <p>Use the scanner glass for single pages, small items (such as postcards or photos), transparencies, photo paper, or thin media (such as magazine clippings).</p> |

The scanner lets you scan documents directly to a computer. The computer does not have to be directly connected to the printer for you to receive Scan to PC images. You can scan the document back to the computer over the network by creating a scan profile on the computer and then downloading the profile to the printer.

Scanning to a computer

- 1 Type the printer IP address into the address field of your Web browser.

Note: If you do not know the IP address of the printer, then print a network setup page and locate the address in the TCP/IP section.

- 2 Click **Scan Profile**.

- 3 Click **Create Scan Profile**.

- 4 Select your scan settings, and then click **Next**.

- 5 Select a location on your computer where you want to save the scanned output file.

- 6 Enter a user name and scan name.

The scan name is the name that appears in the Scan Profile list on the display.

- 7 Click **Submit**.

- 8 Scan your document.




A shortcut number was automatically assigned when you clicked Submit. Remember this shortcut number and use it when you are ready to scan your documents.

- a Load an original document faceup, short edge first into the ADF or facedown on the scanner glass.

Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.

- b If you are loading a document into the ADF, then adjust the paper guides.

- c Press the **Scan/Email** button.

- d Press the arrow buttons until **Profiles** appears, and then press .
- e Press , and then enter the shortcut number.
- f Press .

9 Return to the computer to view the file.

The output file is saved in the location you specified or launched in the program you specified.

Understanding scan profile options

These options let you select preset formats or customize the scan job settings. You can adjust these settings:

Standard scan settings

| Choose | To |
|-----------------|--|
| Quick Setup | Select preset output settings. To customize the scan job settings, select Custom . Then change the following settings as needed: <ul style="list-style-type: none"> • Custom • Text Document • Photo (for display) • Photo (for editing) • Presentation/Article • Drawing/Sketch • Last Used Scan Options |
| Default Content | Tell the printer the original document type. Choose from Text, Mixed, or Photo. Content affects the quality and size of your scanned file. <p>Text—Emphasizes sharp, black, high-resolution text against a clean, white background. Use Text mode when text preservation is the main goal of the scan, and preserving images copied from the original document is not a concern. Text mode is recommended for receipts, carbon copy forms, and documents that contain only text or fine line art.</p> <p>Mixed—Used when the original documents are a mixture of text and graphics or pictures. Mixed mode is recommended for magazine articles, business graphics, and brochures.</p> <p>Photo—Tells the scanner to pay extra attention to graphics and pictures. This setting increases the time it takes to scan, but emphasizes a reproduction of the full dynamic range of tones in the original document. This increases the amount of information saved. Use Photo mode when scanning photos printed on a laser printer or taken from a magazine or newspaper.</p> |
| Darkness | Adjust how light or dark your scanned documents will turn out in relation to the original document. |
| Color | Tell the printer the color of the original documents. You can select Gray, BW (Black and White), or Color. |
| Resolution | Adjust the output quality of your file. Increasing the image resolution increases the file size and the time needed to scan your original document. Image resolution can be decreased to reduce the file size. |

Page Options

| Choose | To |
|---------------|--|
| Duplex | Tell the printer if your original document is simplex (printed on one side) or duplex (printed on both sides). This lets the scanner know what needs to be scanned for inclusion in the document. Note: Duplex may not be available on all printer models. |
| Orientation | Tell the printer whether the original document is in portrait or landscape orientation and then change the Sides and Binding settings to match the original document orientation. |
| Original Size | Set the size of the documents you are going to scan. When Original Size is set to Mixed Sizes, you can scan an original document that contains mixed paper sizes (letter- and legal-size pages). |

Advanced Imaging

| Choose | To |
|--------------------|---|
| Background Removal | Adjust the white portion of the output. Click the arrow buttons to increase or decrease the white portion. |
| Contrast | Adjust the intensity of an image. Click the arrow buttons to increase or decrease the contrast. |
| Shadow Detail | Adjust the details visible in areas that are darkest in the image being scanned. Click the arrow buttons to increase or decrease the visible detail in the shadows. |
| Scan edge to edge | Specify if the original document is scanned edge-to-edge prior to scanning. |
| Mirror Image | Create a mirror image scan. |

File Options

| Choose | To |
|-------------|--|
| Format Type | Set the output (PDF, JPEG, TIFF) for the scanned image. <ul style="list-style-type: none">• PDF—Creates a single file with multiple pages, viewable with Adobe Reader. Adobe Reader is provided free by Adobe at www.adobe.com.• JPEG—Creates and attaches a separate file for each page of your original document, viewable by most Web browsers and graphics programs• TIFF—Creates multiple files or a single file. If Multi-page TIFF is turned off in the Settings menu of the Embedded Web Server, then TIFF saves one page in each file. The file size is usually larger than an equivalent JPEG. |
| Compression | Set the format used to compress the scanned output file. |

Improving scan quality

| Question | Tip |
|------------------------------|---|
| When should I use Text mode? | <ul style="list-style-type: none">• Use Text mode when text preservation is the main goal of the scan, and preserving images copied from the original document is not a concern.• Text mode is recommended for receipts, carbon copy forms, and documents that only contain text or fine line art. |

| Question | Tip |
|------------------------------------|---|
| When should I use Text/Photo mode? | <ul style="list-style-type: none"> • Use Text/Photo mode when scanning an original document that contains a mixture of text and graphics. • Text/Photo mode is recommended for magazine articles, business graphics, and brochures. |
| When should I use Photo mode? | Use Photograph mode when the original document is a high-quality print or photograph. |

Using the Scan Center software

Understanding the Scan Center features

The Scan Center software lets you modify scan settings and select where to send the scanned output. Scan settings modified with the Scan Center software can be saved and used for other scan jobs.

The following features are available:

- Scan and send images to your computer
- Convert scanned images to text
- Preview the scanned image and adjust the brightness and contrast
- Make larger scans without losing detail
- Scan two-sided documents

Understanding printer menus

Menus list

A number of menus are available to make it easy for you to change the default printer settings:

Paper Menu

Default Source
Size/Type
Paper Texture
Paper Weight
Paper Loading
Custom Types
Universal Setup

Network/Ports

Network Menu*
USB Menu

Reports

Menu Settings Page
Device Statistics
Network <x> Setup Page
Shortcut List
Fax Job Log
Fax Call Log
E-Mail Shortcuts
Fax Shortcuts
Profiles List
Print Fonts
Print Directory
Asset Report

Settings

General Settings
Copy Settings
Fax Settings
Print Settings
Utilities Menu
Set Date/Time

* Depending on the printer setup, this menu item appears as Standard Network or Network <x>.

Paper menu

Default Source menu

| Menu item | Description |
|---|---|
| Default Source Tray 1 Manual Paper Manual Env | Sets a default paper source for all print jobs Notes: <ul style="list-style-type: none">• Tray 1 (standard tray) is the factory default setting.• A paper source selected by a print job will override the Default Source setting for the duration of the print job. |

Size/Type menu

| Menu item | Description |
|---|--|
| Select Source menu Tray 1 Manual Paper Manual Env | Note: These menus let you specify the installed paper size and type in the selected tray or manual feeder. |
| Set Size menu for Tray 1 A4 A5 JIS B5 Executive Folio Legal Letter Oficio (Mexico) Statement Universal | Lets you specify the paper size loaded in Tray 1 Note: Letter is the US factory default setting. A4 is the international factory default setting. |
| Set Size menu for Manual Paper A4 A5 JIS B5 Executive Folio Legal Letter Oficio (Mexico) Statement Universal | Lets you specify the size of the paper being loaded in the manual feeder Note: Letter is the US factory default setting. A4 is the international factory default setting. |
| Set Size menu for Manual Env 7 3/4 Envelope 9 Envelope 10 Envelope C5 Envelope B5 Envelope DL Envelope Other Envelope | Lets you specify the size of the envelope being manually loaded Note: 10 Envelope is the US factory default setting. DL Envelope is the international factory default setting. |

| Menu item | Description |
|--|---|
| <p>Set Type menu for Tray 1</p> <ul style="list-style-type: none"> Plain Paper Card Stock Transparency Recycled Labels Bond Letterhead Preprinted Colored Paper Light Paper Heavy Paper Rough/Cotton Custom Type <x> | <p>Lets you specify the type of paper loaded in Tray 1</p> <p>Notes:</p> <ul style="list-style-type: none"> • Plain Paper is the factory default setting for Tray 1. • If available, a user-defined name will appear instead of Custom Type <x>. |
| <p>Set Type menu for Manual Paper</p> <ul style="list-style-type: none"> Plain Paper Card Stock Transparency Labels Bond Letterhead Preprinted Colored Paper Light Paper Heavy Paper Rough/Cotton Custom Type <x> | <p>Lets you specify the type of paper being manually loaded</p> <p>Note: Plain Paper is the factory default setting.</p> |
| <p>Set Type menu for Manual Env</p> <ul style="list-style-type: none"> Envelope Rough Envelope Custom Type <x> | <p>Lets you specify the type of envelope being manually loaded</p> <p>Note: Envelope is the factory default setting.</p> |

Paper Texture menu

In the Paper Texture menu, the Select Type and Select Texture features work together to enable you to select the texture for a specific type of paper.

| Menu item | Description |
|--|---|
| Select Type Plain Texture Card Stock Texture Transparency Texture Recycled Texture Labels Texture Bond Texture Envelope Texture Rough Envelope Texture Letterhead Texture Preprinted Texture Colored Texture Light Texture Heavy Texture Rough/Cotton Texture Custom <x> Texture | Specifies the paper type |
| Select Texture Smooth Normal Rough | After you select a setting for Select Type, the Select Texture feature lets you set the texture for that type of media. Notes: <ul style="list-style-type: none">• Normal is the factory default setting for most items.• Rough is the factory default setting for Bond.• When Rough Texture is the setting selected for Select Type, Rough is the only Select Texture setting available.• Settings appear only if the paper is supported. |

Paper Weight menu

In the Paper Weight menu, the Select Type and Select Weight features work together to enable you to select the weight for a specific type of paper.

| Menu item | Description |
|--|---|
| Select Type Plain Weight Card Stock Weight Transparency Weight Recycled Weight Labels Weight Bond Weight Envelope Weight Rough Envelope Weight Letterhead Weight Preprinted Weight Colored Weight Light Weight Heavy Weight Rough/Cotton Weight Custom <x> Texture | Specifies the paper type |
| Select Weight Light Normal Heavy | After you select a setting for Select Type, the Select Weight feature lets you set the weight for that type of media. Notes: <ul style="list-style-type: none"> • Normal is the factory default setting for most items. • When Light Weight is the setting selected for Select Type, Light is the only Select Weight setting available. • When Heavy Weight is the setting selected for Select Type, Heavy is the only Select Weight setting available. • Settings appear only if the paper is supported. |

Custom Types menu

| Menu item | Description |
|---|---|
| Custom Type <x> Paper Card Stock Transparency Labels Envelope Rough/Cotton | Name a Custom Type <x> , and this user-defined name displays instead of Custom Type <x> . Notes: <ul style="list-style-type: none"> • The Custom Name must be limited to 16 characters. • Paper is the factory default setting for the Custom Type. • The custom media type must be supported by the selected tray or feeder in order for you to print from that source. |

| Menu item | Description |
|--|--|
| Recycled Paper Card Stock Transparency Labels Envelope Rough/Cotton | Assign a paper type for the Recycled paper type loaded, and it will also be the Recycled paper type in other menus. Notes: <ul style="list-style-type: none"> • Paper is the factory default setting. • The Recycled type must be supported by the selected tray or feeder in order for you to print from that source. |

Custom Scan Sizes menu

| Menu item | Description |
|--|---|
| ID Card Width 1–8.50 inches (25–216 mm) Height 1–14 inches (25–356 mm) Orientation Portrait Landscape 2 scans/side Off On | Specifies a custom scan size name and options Notes: <ul style="list-style-type: none"> • The display shows “ID Card” unless you have named the menu item differently. • 4.65 inches is the US factory default setting for Width for Size 1. 118 millimeters is the international factory default setting for Width for Size 1. • 8.5 inches is the US factory default setting for Width for Size 2. 216 millimeters is the international factory default setting for Width for Size 2. • 6 inches is the US factory default setting for Height for Size 1. 154 millimeters is the international factory default setting for Height for Size 1. • 14 inches is the US factory default setting for Height for Size 2. 356 millimeters is the international factory default setting for Height for Size 2. • Landscape is the factory default setting for Orientation. • On is the factory default setting for 2 scans/side. |

| Menu item | Description |
|---|---|
| Custom Scan Size Width 1–8.50 inches (25–216 mm) Height 1–14 inches (25–356 mm) Orientation Portrait Landscape 2 scans/side Off On | Specifies a custom scan size name and options Notes: <ul style="list-style-type: none"> • The display shows “Custom Scan Size” unless you have named the menu item differently. • 4.65 inches is the US factory default setting for Width for Size 1. 118 millimeters is the international factory default setting for Width for Size 1. • 8.5 inches is the US factory default setting for Width for Size 2. 216 millimeters is the international factory default setting for Width for Size 2. • 6 inches is the US factory default setting for Height for Size 1. 154 millimeters is the international factory default setting for Height for Size 1. • 14 inches is the US factory default setting for Height for Size 2. 356 millimeters is the international factory default setting for Height for Size 2. • Landscape is the factory default setting for Orientation. • Off is the factory default setting for 2 scans/side. |

Universal Setup menu

These menu items are used to specify the height, width, and feed direction of the Universal Paper Size. The Universal Paper Size is a user-defined paper size. It is listed with the other paper size settings and includes similar options, such as support for duplex printing and printing multiple pages on one sheet.

| Menu item | Description |
|--|--|
| Units of Measure Inches Millimeters | Identifies the units of measure Notes: <ul style="list-style-type: none"> • Inches is the US factory default setting. • Millimeters is the international factory default setting. |
| Portrait Width 3–14.17 inches 76–360 mm | Sets the portrait width Notes: <ul style="list-style-type: none"> • If the width exceeds the maximum, then the printer uses the maximum width allowed. • 8.5 inches is the US factory default setting. Inches can be increased in 0.01-inch increments. • 216 mm is the international factory default setting. Millimeters can be increased in 1-mm increments. |

| Menu item | Description |
|---|--|
| Portrait Height 3–14.17 inches 76–360 mm | Sets the portrait height Notes: <ul style="list-style-type: none"> • If the height exceeds the maximum, then the printer uses the maximum height allowed. • 14 inches is the US factory default setting. Inches can be increased in 0.01-inch increments. • 356 mm is the international factory default setting. Millimeters can be increased in 1-mm increments. |
| Feed Direction Short Edge Long Edge | Specifies the feed direction Notes: <ul style="list-style-type: none"> • Short Edge is the factory default setting. • Long Edge appears only if the longest edge is shorter than the maximum length supported in the tray. |

Reports menu

Reports menu

Note: When you select a menu item from the Reports menu, the indicated report prints.

| Menu item | Description |
|---------------------------|---|
| Menu Settings Page | Prints a report containing information about paper loaded into trays, installed memory, the total page count, alarms, timeouts, the printer control panel language, the TCP/IP address, the status of supplies, the status of the network connection, and other information |
| Device Statistics | Prints a report containing printer statistics such as supply information and details about printed pages |
| Network Setup Page | Prints a report containing information about the network printer settings, such as the TCP/IP address information Note: This menu item appears only for network printers or printers connected to print servers. |
| Shortcut List | Prints a report containing information about configured shortcuts |
| Fax Job Log | Prints a report containing information about the last 200 completed faxes |
| Fax Call Log | Prints a report containing information about the last 100 attempted, received, and blocked calls |
| E-mail Shortcuts | Prints a report containing information about e-mail shortcuts |
| Fax Shortcuts | Prints a report containing information about fax shortcuts |
| Print Fonts | Prints a report of all the fonts available for the printer language currently set in the printer |

| Menu item | Description |
|---------------------|---|
| Asset Report | Prints a report containing asset information, including the printer serial number and model name. The report contains text and UPC barcodes that can be scanned into an asset database. |

Settings menu

General Settings menu

| Menu item | Description |
|---|--|
| Display Language English Francais Deutsch Italiano Espanol Dansk Norsk Nederlands Svenska Portuguese Suomi Russian Polski Magyar Turkce Cesky Simplified Chinese Traditional Chinese Korean Japanese | Sets the language of the text appearing on the display Note: All languages may not be available for all printers. |
| Eco-Mode Off Energy Energy/Paper Paper | Minimizes the use of energy, paper, or specialty media Notes: <ul style="list-style-type: none"> • Off is the factory default setting. Off resets the printer to its factory default settings. • The Energy setting minimizes the power used by the printer. Performance may be affected but quality is not. • Paper minimizes the amount of paper and specialty media needed for a print job. Performance may be affected but quality is not. • Energy/Paper minimizes the use of power and of paper and specialty media. |

| Menu item | Description |
|--|---|
| Quiet Mode Off On | Reduces the amount of noise produced by the printer Notes: <ul style="list-style-type: none"> • Off is the factory default setting. • On configures the printer to produce as little noise as possible. |
| Run Initial setup Yes No | Instructs the printer to run the setup wizard Notes: <ul style="list-style-type: none"> • Yes is the factory default setting. • After completing the setup wizard by selecting Done at the Country select screen, the default setting becomes No. |
| Paper Sizes U.S. Metric | Specifies the printer factory default measurements. The default setting is determined by the country selection in the initial setup wizard. |
| Scan to PC Port Range <port range> | Specifies a valid port range for printers behind a port blocking firewall. The valid ports are specified by two sets of numbers separated by a semicolon. Note: 9751:12000 is the factory default setting. |
| Date Format MM-DD-YYYY DD-MM-YYYY YYYY-MM-DD | Formats the printer date Note: MM-DD-YYYY is the US factory default setting and DD-MM-YYYY is the international factory default setting. |
| Time Format 12 hour A.M./P.M. 24 hour clock | Formats the printer time Note: The factory default setting is 12 hour A.M./P.M. |
| Alarms Alarm Control Cartridge Alarm | Sets an alarm to sound when the printer requires operator intervention. Available selections for each alarm type are: Off Single Continuous Notes: <ul style="list-style-type: none"> • Single is the factory default setting for Alarm Control. Single sounds three quick beeps. • Off means no alarm will sound. • Continuous repeats three beeps every 10 seconds. |
| Timeouts Power Saver Disabled 1–240 | Specifies the number of minutes of inactivity before some systems begin entering a minimum power state. Note: 30 minutes is the factory default setting. |
| Timeouts Screen Timeout 15–300 | Sets the amount of time in seconds the printer waits before returning the printer display to a Ready state Note: 30 seconds is the factory default setting. |

| Menu item | Description |
|--|--|
| Timeouts Print Timeout Disabled 1–255 | Sets the amount of time in seconds the printer waits to receive an end-of-job message before canceling the remainder of the print job Notes: <ul style="list-style-type: none"> • 90 seconds is the factory default setting. • When the timer expires, any partially printed page still in the printer is printed, and then the printer checks to see if any new print jobs are waiting. • Print Timeout is available only when using PCL or PPDS emulation. This setting has no effect on PostScript emulation print jobs. |
| Timeouts Wait Timeout Disabled 15–65535 | Sets the amount of time in seconds the printer waits for additional data before canceling a print job Notes: <ul style="list-style-type: none"> • 40 seconds is the factory default setting. • Wait Timeout is available only when the printer is using PostScript emulation. This setting has no effect on PCL or PPDS emulation print jobs. |
| Factory Defaults Do Not Restore Restore Now | Returns the printer settings to the factory default settings Notes: <ul style="list-style-type: none"> • Do Not Restore is the factory default setting. Do Not Restore keeps the user-defined settings. • Restore returns all printer settings to the factory default settings except Network/Ports menu settings. All downloads stored in RAM are deleted. |

Copy Settings menu

| Menu item | Description |
|--|---|
| Content Text Text/Photo Photograph | Specifies the type of content contained in the copy job Notes: <ul style="list-style-type: none"> • Text emphasizes sharp, black, high-resolution text against a clean, white background. • Text/Photo is the factory default setting. Text/Photo is used when the original documents are a mixture of text and graphics or pictures. • Photograph tells the scanner to pay extra attention to graphics and pictures. This setting increases the time it takes to scan, but emphasizes a reproduction of the full dynamic range of tones in the original document. This increases the amount of information saved. |

| Menu item | Description |
|--|---|
| Paper Saver Off 2 on 1 Portrait 2 on 1 Landscape 4 on 1 Portrait 4 on 1 Landscape | Sets two or four sheets of an original document together on the same page Note: Off is the factory default setting. |
| Print Page Borders On Off | Specifies whether a border is printed around the edge of the page at the margins Note: Off is the factory default setting. |
| Collate On Off | Keeps the pages of a print job stacked in sequence when making multiple copies of the job Note: On is the factory default setting. |
| Original Size Letter Legal Executive Folio Statement Universal ID Card Custom Scan Size 4 x 6 in. 3 x 5 in. Business Card A4 A5 Oficio (Mexico) JIS B5 | Specifies the paper size of the original document Notes: <ul style="list-style-type: none"> • Letter is the US factory default setting. A4 is the international factory default setting. • A setting with an * indicates it is the current default setting. |
| Paper Source Tray <x> Manual Feeder | Specifies the paper source for copy jobs Note: Tray 1 is the factory default setting. |
| Darkness -4 to +4 | Specifies the level of darkness for the copy job Note: The factory default setting is 0. |
| Number of Copies 1–999 | Specifies the number of copies for the copy job Note: The factory default setting is 1. |
| Background Removal -4 to +4 | Adjusts the amount of background visible on a copy Note: The factory default setting is 0. |
| Contrast 0–5 Best for content | Specifies the contrast used for the copy job Note: “Best for content” is the factory default setting. |
| Shadow Detail -4 to +4 | Adjusts the amount of shadow detail visible on a copy Note: 0 is the factory default setting. |

| Menu item | Description |
|---------------------------------------|---|
| Scan edge to edge On Off | Specifies if the original document is scanned edge-to-edge prior to copying Note: Off is the factory default setting. |
| Sharpness 1–5 | Adjusts the sharpness of a copy Note: 3 is the factory default setting. |

Fax Settings menu

General Fax Settings

| Menu item | Description |
|---|--|
| Station Name | Specifies the fax station name of the printer |
| Station Number | Specifies a fax number associated with the printer |
| Station ID Station Name Station Number | Specifies how the printer is identified |
| Enable Manual Fax On Off | Sets the printer to fax manually only, which requires a line splitter and a telephone hand set Notes: <ul style="list-style-type: none"> • Off is the factory default setting. • Use a regular telephone to answer an incoming fax job and to dial a fax number. • Touch # 0 on the numeric keypad to go directly to the Manual Fax function. |
| Cancel Faxes Allow Don't Allow | Specifies whether the printer may cancel fax jobs Note: If Cancel Faxes is not enabled, it will not appear as an option. Allow is the factory default setting. |
| Caller ID FSK DTMF | Specifies the type of caller ID being used Note: This option appears only when the selected country supports multiple caller ID patterns. |

Fax Send Settings

| Menu item | Description |
|---|--|
| Resolution Standard Fine Super Fine | Specifies quality in dots per inch (dpi). A higher resolution gives greater print quality, but it increases the fax transmission time for outgoing faxes. Note: Standard is the factory default setting. |

| Menu item | Description |
|--|--|
| Original Size Mixed Sizes Letter Legal Executive Folio Statement A4 A5 JIS B5 Universal 4 x 6 3 x 5 Business Card Oficio (Mexico) ID Card Custom Scan Sizes | Specifies the paper size of the document that is being scanned Note: Mixed Sizes is the US factory default setting. A4 is the international factory default setting. |
| Content Text Text/Photo Photograph | Specifies the type of content that will be scanned to fax Notes: <ul style="list-style-type: none"> • Text is the factory default setting. • Text is used when the document is mostly text. • Text/Photo is the factory default setting. Text/Photo is used when the documents are mostly text or line art. • Photograph is used when the document is a high-quality photograph or inkjet print. |
| Darkness -4 to +4 | Lightens or darkens the output Note: 0 is the factory default setting. |
| Dial Prefix | Lets you enter a dialing prefix, such as 99. A numeric entry field is provided. |
| Automatic Redial 0–9 | Specifies the number of times the printer tries to send the fax to a specified number Note: 5 is the factory default setting. |
| Redial Frequency 1–200 | Specifies the number of minutes between redials Note: 3 minutes is the factory default setting. |
| Behind a PABX Yes No | Enables switchboard blind dialing without a dial tone Note: No is the factory default setting. |
| Enable ECM Yes No | Enables Error Correction Mode for fax jobs Note: Yes is the factory default setting. |
| Enable Fax Scans On Off | Lets you send faxes by scanning at the printer Note: On is the factory default setting. |

| Menu item | Description |
|--|--|
| Driver to fax Yes No | Allows driver to fax jobs to be sent by the printer Note: Yes is the factory default setting. |
| Dial Mode Tone Pulse | Specifies the dialing sound, either as a tone or a pulse Note: Tone is the factory default setting. |
| Max Speed 2400 4800 9600 14400 33600 | Specifies the maximum speed in baud at which faxes are sent Note: 33600 baud is the factory default setting. |
| Background Removal -4 to +4 | Adjusts the amount of background visible on a copy Note: 0 is the factory default setting. |
| Contrast Best for content 0–5 | Specifies the contrast of the output Note: “Best for content” is the factory default setting. |
| Shadow Detail -4 to +4 | Adjusts the amount of shadow detail visible on a copy Note: 0 is the factory default setting. |
| Scan edge to edge On Off | Specifies if the original document is scanned edge-to-edge Note: Off is the factory default setting. |
| Sharpness 1–5 | Adjusts the sharpness of a fax Note: 3 is the factory default setting. |

Fax Receive Settings

| Menu item | Description |
|--|--|
| Enable Fax Receive On Off | Allows fax jobs to be received by the printer Note: On is the factory default setting. |
| Rings to Answer 1–25 | Specifies the number of rings before answering an incoming fax job Note: 3 is the factory default setting. |
| Auto Answer Yes No | Allows the printer to answer an incoming fax job Note: Yes is the factory default setting. |
| Manual Answer Code 1–9 | Lets you enter a code on the telephone number pad to begin receiving a fax Notes: <ul style="list-style-type: none"> • This menu item is used when the printer shares a line with a telephone. • 9 is the factory default setting. |

| Menu item | Description |
|--|--|
| Auto Reduction On Off | Scales an incoming fax job so it fits the size of the paper loaded in the designated fax source Note: On is the factory default setting. |
| Fax Footer On Off | Prints the transmission information at the bottom of each page from a received fax Note: Off is the factory default setting. |
| Max Speed 2400 4800 9600 14400 33600 | Specifies the maximum speed in baud at which faxes are received Note: 33600 (baud) is the factory default setting. |
| Block No Name Fax On Off | Enables blocking of incoming faxes sent from devices with no station ID specified Note: Off is the factory default setting. |

Fax Log Settings

| Menu item | Description |
|--|--|
| Transmission Log Print log Do not print log Print only for error | Enables printing of a transmission log after each fax job Note: Print log is the factory default setting. |
| Receive Error Log Print Never Print on Error | Enables printing of a receive error log following a receive error Note: Print Never is the factory default setting. |
| Auto Print Logs On Off | Enables automatic printing of fax logs Note: On is the factory default setting. |
| Logs Display Remote Station Name Dialed Number | Specifies whether printed logs display the dialed number or the station name Note: "Remote Station Name" is the factory default setting. |
| Enable Job Log On Off | Enables access to the Fax Job log Note: On is the factory default setting. |
| Enable Call Log On Off | Enables access to the Fax Call log Note: On is the factory default setting. |

Speaker Settings

| Menu item | Description |
|--|---|
| Speaker Mode Always Off On until Connected Always On | Notes: <ul style="list-style-type: none"> • Always Off turns the speaker off. • “On until Connected” is the factory default setting. The speaker is on and issues a noise until the fax connection is made. • Always On turns the speaker on. |
| Speaker Volume High Medium Low | Controls the volume setting Note: High is the factory default setting. |
| Ringer Volume On Off | Controls the ringer volume for the fax speaker Note: On is the factory default setting. |

Distinctive Ring Settings

| Menu item | Description |
|---------------------------------|---|
| Single Ring On Off | Answers calls with a one-ring pattern Note: On is the factory default setting. |
| Double Ring On Off | Answers calls with a double-ring pattern Note: On is the factory default setting. |
| Triple Ring On Off | Triple Ring answers calls with a triple-ring pattern Note: On is the factory default setting. |

Print Settings

Setup menu

| Menu item | Description |
|--|--|
| Printer Language PS Emulation PCL Emulation | Sets the default printer language Notes: <ul style="list-style-type: none"> • PostScript emulation uses a PS interpreter for processing print jobs. PCL emulation uses a PCL interpreter for processing print jobs. • The factory default printer language is PCL Emulation. • Setting a printer language as the default does not prevent a software program from sending print jobs that use another printer language. |

| Menu item | Description |
|---|---|
| Print Area Normal Whole Page | Sets the logical and physical printable area Notes: <ul style="list-style-type: none"> • Normal is the factory default setting. When attempting to print data in the non-printable area defined by the Normal setting, the printer clips the image at the boundary. • The Whole Page setting allows the image to be moved into the non-printable area defined by the Normal setting, but the printer will clip the image at the Normal setting boundary. • The Whole Page setting affects only pages printed using a PCL 5e interpreter. This setting has no effect on pages printed using the PCL XL or PostScript interpreter. |

Finishing menu

| Menu item | Description |
|--|--|
| Copies 1–999 | Specifies a default number of copies for each print job Note: 1 is the factory default setting. |
| Blank Pages Do Not Print Print | Specifies whether blank pages are inserted in a print job Note: “Do Not Print” is the factory default setting. |
| Collate On Off | Stacks the pages of a print job in sequence when printing multiple copies Notes: <ul style="list-style-type: none"> • Off is the factory default setting. No pages will be collated. • The On setting stacks the print job sequentially. • Both settings print the entire job the number of times specified by the Copy menu setting. |
| N-Up Off 2 Up 4 Up 6 Up 9 Up 16 Up | Specifies that multiple-page images are printed on one side of a sheet of paper Notes: <ul style="list-style-type: none"> • The number selected is the number of page images that will print per side • Off is the factory default setting. |
| N-Up Ordering Horizontal Reverse Horizontal Reverse Vertical Vertical | Specifies how the page images appear on the physical page Note: Horizontal is the factory default setting. |

| Menu item | Description |
|---|--|
| Orientation Auto Landscape Portrait | Specifies the orientation of a multiple-page sheet Notes: <ul style="list-style-type: none"> • Auto is the factory default setting. The printer chooses between portrait and landscape. • Long Edge uses landscape. • Short Edge uses portrait. |
| N-Up Border None Solid | Prints a border around each page image Note: None is the factory default setting. |

Quality menu

| Menu item | Description |
|---|---|
| Print Resolution 600 dpi 1200 dpi 1200 Image Q 2400 Image Q | Specifies the printed output resolution Note: 600 dpi is the factory default setting. The printer driver default is 1200 Image Q. |
| Pixel Boost Off Fonts Horizontally Vertically Both Directions | Enhances the printed quality of small fonts and graphics Notes: <ul style="list-style-type: none"> • Off is the factory default setting. • The Fonts setting applies only to text. • Horizontally darkens horizontal lines of text and images. • Vertically darkens vertical lines of text and images. • Both Directions darkens horizontal and vertical lines of text and images. • Isolated allows you to select a particular area. |
| Toner Darkness 1–10 | Lightens or darkens the printed output Notes: <ul style="list-style-type: none"> • 8 is the factory default setting. • Selecting a smaller number can help conserve toner. |
| Enhance Fine Lines On Off | Enables a print mode preferable for files such as architectural drawings, maps, electrical circuit diagrams, and flow charts Notes: <ul style="list-style-type: none"> • Off is the factory default setting. • To set Enhance Fine Lines using the Embedded Web Server, type the network printer IP address in a browser window. |

PostScript menu

| Menu item | Description |
|------------------------------------|---|
| Print PS Error On Off | Prints a page containing the PostScript error Note: Off is the factory default setting. |

PCL Emul menu

| Menu item | Description |
|---|---|
| Font Source Resident Download All | Specifies the set of fonts available Notes: <ul style="list-style-type: none"> Resident is the factory default setting. It shows the factory default set of fonts downloaded into RAM. Download appears only if downloaded fonts exist. It shows all the fonts downloaded into RAM. All shows all fonts available to any option. |
| Font Name <x> | Lets you view or change the setting from a selection list |
| Symbol Set <x> | Lets you view or change the setting from a selection list |
| PCL Emulation Settings Pitch 0.08–100 | Specifies the font pitch for scalable monospaced fonts Notes: <ul style="list-style-type: none"> 10 is the factory default setting. Pitch refers to the number of fixed-space characters per inch (cpi). Pitch can be increased or decreased in 0.01-cpi increments. For nonscalable monospaced fonts, the pitch appears on the display but cannot be changed. |
| PCL Emulation Settings Orientation Portrait Landscape | Specifies the orientation of text and graphics on the page Notes: <ul style="list-style-type: none"> Portrait is the factory default setting. Portrait prints text and graphics parallel to the short edge of the page. Landscape prints text and graphics parallel to the long edge of the page. |
| PCL Emulation Settings Lines per Page 1–255 | Specifies the number of lines that print on each page Notes: <ul style="list-style-type: none"> 60 is the US factory default setting. 64 is the international factory default setting. The printer sets the amount of space between each line based on the Lines per Page, Paper Size, and Orientation settings. Select the desired Paper Size and Orientation before setting Lines per Page. |

| Menu item | Description |
|--|--|
| PCL Emulation Settings A4 Width 198 mm 203 mm | Sets the printer to print on A4-size paper Notes: <ul style="list-style-type: none"> • 198 mm is the factory default setting. • The 203 mm setting sets the width of the page to allow the printing of eighty 10-pitch characters. |
| PCL Emulation Settings Auto CR after LF On Off | Specifies whether the printer automatically performs a carriage return (CR) after a line feed (LF) control command Note: Off is the factory default setting. |
| PCL Emulation Settings Auto LF after CR On Off | Specifies whether the printer automatically performs a line feed (LF) after a carriage return (CR) control command Note: Off is the factory default setting. |

Network/Ports menu

Standard Network or Network <x> menus

Note: Only active ports appear in this menu; all inactive ports are omitted.

| Menu item | Description |
|-------------------------------------|--|
| PCL SmartSwitch On Off | Sets the printer to automatically switch to PCL emulation when a print job requires it, regardless of the default printer language Notes: <ul style="list-style-type: none"> • On is the factory default setting. • When the Off setting is used, the printer does not examine incoming data. • When the Off setting is used, the printer uses PostScript emulation if PS SmartSwitch is set to On. It uses the default printer language specified in the Setup menu if PS SmartSwitch is set to Off. |
| PS SmartSwitch On Off | Sets the printer to automatically switch to PS emulation when a print job requires it, regardless of the default printer language Notes: <ul style="list-style-type: none"> • On is the factory default setting. • When the Off setting is used, the printer does not examine incoming data. • When the Off setting is used, the printer uses PCL emulation if PCL SmartSwitch is set to On. It uses the default printer language specified in the Setup menu if PCL SmartSwitch is set to Off. |

| Menu item | Description |
|--|--|
| NPA Mode Off Auto | Sets the printer to perform the special processing required for bidirectional communication following the conventions defined by the NPA protocol Notes: <ul style="list-style-type: none"> • Auto is the factory default setting. • Changing this setting from the printer control panel and then exiting the menus causes the printer to restart. The menu selection is updated. |
| Network Buffer Auto 3K to <maximum size allowed> | Sets the size of the network input buffer Notes: <ul style="list-style-type: none"> • Auto is the factory default setting. • The value can be changed in 1-K increments. • The maximum size allowed depends on the amount of memory in the printer, the size of the other link buffers, and whether Resource Save is set to On or Off. • To increase the maximum size range for the Network Buffer, disable or reduce the size of the USB buffer. • Changing this setting from the printer control panel and then exiting the menus causes the printer to restart. The menu selection is updated. |
| Mac Binary PS On Off Auto | Sets the printer to process Macintosh binary PostScript print jobs Notes: <ul style="list-style-type: none"> • Auto is the factory default setting. • The Off setting filters print jobs using the standard protocol. • The On setting processes raw binary PostScript print jobs. |
| Std Network Setup Reports Network Card TCP/IP IPv6 Net <x> Setup Reports Network Card TCP/IP IPv6 | For descriptions and settings of the network setup menus, see the following: <ul style="list-style-type: none"> • “Network Reports menu” on page 107 • “Network Card menu” on page 108 • “TCP/IP menu” on page 108 • “IPv6 menu” on page 109 |

Network Reports menu

This menu is available from the Network/Ports menu:

Network/Ports > Standard Network or Network <x> > Std Network Setup or Net <x> Setup > Reports or Network Reports

| Menu item | Description |
|-------------------------|--|
| Print Setup Page | Prints a report containing information about the current network setup Note: The Print Setup Page contains information about the network printer settings, such as the TCP/IP address. |

Network Card menu

This menu is available from the Network/Ports menu:

Network/Ports > Standard Network or Network <x> > Std Network Setup or Net <x> Setup > Network Card

| Menu item | Description |
|--|---|
| View Card Status Connected Disconnected | Lets you view the connection status of the Network Card |
| View Card Speed | Lets you view the speed of a currently active network card |
| Network Address UAA LAA | Lets you view the network addresses |
| Job Timeout 0-225 seconds | Sets the amount of time in seconds that a network print job can take before it is canceled Notes: <ul style="list-style-type: none"> • 90 seconds is the factory default setting. • A setting value of 0 disables the timeout. • If a value of 1–9 is selected, then the setting is saved as 10. |
| Banner Page Off On | Allows the printer to print a banner page Note: Off is the factory default setting. |

TCP/IP menu

Use the following menu items to view or set the TCP/IP information.

Note: This menu is available only for network models or printers attached to print servers.

This menu is available from the Network/Ports menu:

Network/Ports > Standard Network or Network <x> > Std Network Setup or Net <x> Setup > TCP/IP

| Menu item | Description |
|------------------------------|---|
| Activate On Off | Activates TCP/IP Note: On is the factory default setting. |

| Menu item | Description |
|--|--|
| View Hostname | Lets you view the current TCP/IP hostname Note: This can be changed only from the Embedded Web Server. |
| IP Address | Lets you view or change the current TCP/IP Address Note: Manually setting the IP address sets the Enable DHCP and Enable Auto IP settings to Off. It also sets Enable BOOTP and Enable RARP to Off on systems that support BOOTP and RARP. |
| Netmask | Lets you view or change the current TCP/IP Netmask |
| Gateway | Lets you view or change the current TCP/IP Gateway |
| Enable DHCP On Off | Specifies the DHCP address and parameter assignment setting |
| Enable AutoIP Yes No | Specifies the Zero Configuration Networking setting Note: Yes is the factory default setting. |
| Enable FTP/TFTP Yes No | Enables the built-in FTP server, which allows you to send files to the printer using the File Transfer Protocol. Note: Yes is the factory default setting. |
| Enable HTTP Server Yes No | Enables the built-in web server (Embedded Web Server). When enabled, the printer can be monitored and managed remotely using a Web browser. Note: Yes is the factory default setting. |
| WINS Server Address | Lets you view or change the current WINS Server Address |
| DNS Server Address | Lets you view or change the current DNS Server Address |

IPv6 menu

Use the following menu items to view or set the Internet Protocol version 6 (IPv6) information.

Note: This menu is available only for network models or printers attached to print servers.

This menu is available from the Network/Ports menu:

Network/Ports > Standard Network or Network <x> > Std Network Setup or Net <x> Setup > IPv6

| Menu item | Description |
|--|--|
| Enable IPv6 On Off | Enables IPv6 in the printer Note: On is the factory default setting. |
| Auto Configuration On Off | Specifies whether the network adapter accepts the automatic IPv6 address configuration entries provided by a router Note: On is the factory default setting. |

| Menu item | Description |
|---|--|
| View Hostname View Address View Router Address | Lets you view the current setting Note: These settings can be changed only from the Embedded Web Server. |
| Enable DHCPv6 On Off | Enables DHCPv6 in the printer Note: On is the factory default setting. |

USB menu

| Menu item | Description |
|--------------------------------------|--|
| PCL SmartSwitch On Off | Sets the printer to automatically switch to PCL emulation when a print job received through a USB port requires it, regardless of the default printer language Notes: <ul style="list-style-type: none"> • On is the factory default setting. • When the Off setting is used, the printer does not examine incoming data. • When the Off setting is used, the printer uses PostScript emulation if the PS SmartSwitch setting is On. It uses the default printer language specified in the Setup menu if the PS SmartSwitch setting is Off. |
| PS SmartSwitch On Off | Sets the printer to automatically switch to PS emulation when a print job received through a USB port requires it, regardless of the default printer language Notes: <ul style="list-style-type: none"> • On is the factory default setting. • When the Off setting is used, the printer does not examine incoming data. • When the Off setting is used, the printer uses PCL emulation if the PCL SmartSwitch setting is On. It uses the default printer language specified in the Setup menu if the PCL SmartSwitch setting is Off. |
| NPA Mode On Off Auto | Sets the printer to perform the special processing required for bidirectional communication following the conventions defined by the NPA protocol Notes: <ul style="list-style-type: none"> • Auto is the factory default setting. • Changing this setting from the printer control panel and then exiting the menus causes the printer to restart. The menu selection is updated. |

| Menu item | Description |
|---|--|
| USB Buffer Disabled Auto 3K to <maximum size allowed> | Sets the size of the USB input buffer Notes: <ul style="list-style-type: none"> • Auto is the factory default setting. • The Disabled setting turns off job buffering. Any jobs already buffered on the disk are printed before normal processing is resumed. • The USB buffer size value can be changed in 1-K increments. • The maximum size allowed depends on the amount of memory in the printer, the size of the other link buffers, and whether the Resource Save setting is On or Off. • To increase the maximum size range for the USB Buffer, disable or reduce the size of the parallel, serial, and network buffers. • Changing this setting from the printer control panel and then exiting the menus causes the printer to restart. The menu selection is updated. |
| Mac Binary PS On Off Auto | Sets the printer to process Macintosh binary PostScript print jobs Notes: <ul style="list-style-type: none"> • Auto is the factory default setting. • The Off setting filters print jobs using the standard protocol. • The On setting processes raw binary PostScript print jobs. |
| USB With ENA ENA Address ENA Netmask ENA Gateway | Sets the network address, netmask, or gateway information for an external print server that is attached to the printer using a USB cable Note: This menu item is available only if the printer is attached to an external print server through the USB port. |

Set Date and Time

| Menu item | Description |
|-----------------------------------|--|
| View Date/Time | Displays the time in YYYY-MM-DD HH:MM format Note: This is a view only screen. |
| Set Date/Time Yes No | Instructs the printer to run the setup wizard Notes: <ul style="list-style-type: none"> • Yes is the factory default setting. • After completing the setup wizard by selecting Done at the Country/Region select screen, the default becomes No. |

| Menu item | Description |
|---|--|
| Time Zone (North, Central, and South America) Hawaii * Alaska Tijuana (PST) USA/Canada PST USA/Canada MST USA/Canada CST USA/Canada EST Canada AST Caracas (VET) Newfoundland (NST) Brasilia (BRT) | Specifies the time zone for the fax Note: * indicates that this value <i>does not</i> have pre-programmed Daylight Savings Time Start and End times. |
| Time Zone (Europe and Africa) Azores (AZOT) Praia (CVT) * GMT (*) Dublin, Ireland London (BST) Western Europe Central Europe Eastern Europe Cairo (EET) Pretoria (SAST) * Moscow (MSK) | Specifies the time zone for the fax Note: * indicates that this value <i>does not</i> have pre-programmed Daylight Savings Time Start and End times. |
| Time Zone (Asia) Jerusalem (IST) Abu Dhabi GIST)* Kabul (AFT) * Islamabad (PKT) * New Delhi (IST) * Kathmandu (NPT) * Astana (ALMT) * Yangon (MMT) * Bangkok (ICT) * Beijing (CST) * Seoul (KST) * Tokyo (JST) * | Specifies the time zone for the fax Note: * indicates that this value <i>does not</i> have pre-programmed Daylight Savings Time Start and End times. |

| Menu item | Description |
|--|--|
| Time Zone (Australia and the Pacific region) Australia WST Australia CST Darwin (CST) * Australia EST Queensland (EST) * Tasmania (EST) Wellington (NZST) Not Listed | Specifies the time zone for the fax Note: * indicates that this value <i>does not</i> have pre-programmed Daylight Savings Time Start and End times. |
| Observe DST On Off | Accommodates Daylight Savings Time changes Note: On is the factory default setting. |
| Enable NTP On Off | Lets the printer clock synchronize with the Network Time Protocol (NTP) server Note: On is the factory default setting. |

Maintaining the printer

Periodically, certain tasks are required to maintain optimum print quality.

Cleaning the exterior of the printer

- 1 Make sure that the printer is turned off and unplugged from the wall outlet.



CAUTION—SHOCK HAZARD: To avoid the risk of electric shock when cleaning the exterior of the printer, unplug the power cord from the wall outlet and disconnect all cables to the printer before proceeding.

- 2 Remove all paper from the printer.
- 3 Dampen a clean, lint-free cloth with water.

Warning—Potential Damage: Do not use household cleaners or detergents, as they may damage the finish of the printer.

- 4 Wipe only the outside of the printer.


Warning—Potential Damage: Using a damp cloth to clean the interior may cause damage to your printer.

- 5 Make sure all areas of the printer are dry before beginning a new print job.

Cleaning the scanner glass

If you encounter print quality problems, such as streaks on copied or scanned images, clean the areas shown.

- 1 Slightly dampen a soft, lint-free cloth or paper towel with water.
- 2 Open the scanner cover.



| | |
|---|---|
| 1 | White undersides of the scanner glass cover and the ADF cover |
| 2 | Scanner glass and ADF glass |
| 3 | ADF tabs |

- 3 Wipe the areas shown and let them dry.


Warning—Potential Damage: Do not fold or crease the ADF tabs. Doing so may cause jams.

- 4 Close the scanner cover.


Cleaning the ADF separator rollers

After you have copied over 5,000 pages using the ADF, or if streaks are appearing, clean the ADF separator rollers.


- 1 Open the ADF cover.




- 2 Unlock the separator roll.




- 3 Remove the separator roll.




4 Use a clean, lint-free cloth dampened with water to wipe the separator roller.




5 Reinstall the separator roll.




6 Lock the separator roll.



7 Use a second clean, lint-free cloth dampened with water to wipe the other separator roller while gently rotating it.



8 Close the ADF cover.



Storing supplies

Choose a cool, clean storage area for the printer supplies. Store supplies right side up in their original packing until you are ready to use them.

Do not expose supplies to:

- Direct sunlight
- Temperatures above 35°C (95°F)
- High humidity above 80%
- Salty air
- Corrosive gases
- Heavy dust

Checking the status of supplies from a network computer

Note: The computer must be connected to the same network as the printer.

1 Type the printer IP address into the address field of your Web browser.

Note: If you do not know the IP address of the printer, print a network setup page and locate the IP address in the TCP/IP section.

2 Click **Device Status**. The Device Status page appears, displaying a summary of supply levels.

Ordering supplies

To order supplies in the U.S., contact Lexmark at 1-800-539-6275 for information about Lexmark authorized supplies dealers in your area. In other countries or regions, visit the Lexmark Web Site at www.lexmark.com or contact the place where you purchased the printer.


Warning—Potential Damage: Damage caused by the use of a supply or replacement item not produced by the manufacturer of this printer is not covered under warranty. Degraded print quality may result from using supplies or replacement items not produced by the manufacturer of this printer.

Note: All life estimates for printer supplies assume printing on letter- or A4-size plain paper.

Ordering toner cartridges

When **88 Cartridge is Low** appears or when the print becomes faded:

- 1 Remove the toner cartridge.
- 2 Firmly shake the cartridge side-to-side and front-to-back several times to redistribute toner.



3 Reinsert the cartridge and continue printing.

Note: Repeat this procedure multiple times until the print remains faded, and then replace the cartridge.

Recommended toner cartridge part numbers

| Part name | Regular cartridge | Lexmark Return Program Cartridge |
|-----------------|-------------------|----------------------------------|
| Toner cartridge | X340A21G | X203A11G |

Ordering a photoconductor kit

When **84 PC Kit Life Warning** appears on the display, the photoconductor kit is near its end of life. Order a photoconductor kit so that one is available when **84 Replace PC Kit** appears.

You can also check the status of the photoconductor kit by printing a network setup page.

| Part name | Part number |
|--------------------|-------------|
| Photoconductor kit | X203H22G |

Replacing supplies


Replacing the toner cartridge

When **88 Cartridge is low** appears, or when you experience faded print, remove the toner cartridge. Firmly shake it side-to-side and front-to-back several times to redistribute the toner, and then reinsert it and continue printing. When shaking the cartridge no longer improves the print quality, replace the toner cartridge.


Note: You can check to see approximately how much toner is left in your cartridge by printing a menu settings page.

To replace the toner cartridge:

- 1 Open the front door by pressing the button on the left side of the printer and lowering the door.




2 Press the button on the base of the photoconductor kit, and then pull the toner cartridge out using the handle.




3 Unpack the new toner cartridge.

4 Shake the cartridge in all directions to distribute the toner.



- 5 Install the new toner cartridge by aligning the rollers on the toner cartridge with the arrows on the tracks of the photoconductor kit. Push the toner cartridge in as far as it will go. The cartridge *clicks* into place when correctly installed.




- 6 Close the front door.

Replacing the photoconductor kit


The printer automatically notifies you before the photoconductor kit reaches a page maximum by showing **84 PC Kit life warning** or **84 Replace PC Kit** on the display. You can also see the status of the photoconductor kit by printing a menu settings page.

When **84 PC Kit life warning** or **84 Replace PC Kit** first appears, you should immediately order a new photoconductor kit. While the printer may continue to function properly after the photoconductor kit has reached its official end-of-life, print quality significantly decreases.

Note: The photoconductor kit is one item only.




1 Open the front door by pressing the button on the left side of the printer and lowering the front door.




2 Pull the photoconductor kit and toner cartridge out of the printer as a unit by pulling on the toner cartridge handle.


Note: The photoconductor kit and toner cartridge form a unit.



Place the unit on a flat, clean surface.




3 Press the button on the base of the photoconductor kit. Pull the toner cartridge up and out using the handle.




4 Unpack the new photoconductor kit. Be careful not to touch the photoconductor drum.


Warning—Potential Damage: When replacing the photoconductor kit, do not leave the kit exposed to direct light for an extended period of time. Extended light exposure can cause significant print quality problems.



- 5 Insert the toner cartridge into the photoconductor kit by aligning the rollers on the toner cartridge with the tracks. Push the toner cartridge until it *clicks* into place.



- 6 Install the unit into the printer by aligning the arrows on the guides of the unit with the arrows in the printer. Push the unit in as far as it will go.



- 7 After you replace the photoconductor kit, reset the photoconductor counter. To reset the counter, see the instruction sheet that came with the new photoconductor kit.

Warning—Potential Damage: Resetting the photoconductor counter without replacing the photoconductor may damage your printer and void your warranty.

- 8 Close the front door.

Moving the printer to another location

Warning—Potential Damage: Damage to the printer caused by improper moving is not covered by the printer warranty.

CAUTION—POTENTIAL INJURY: Follow these guidelines to avoid personal injury or printer damage:

- Turn the printer off using the power switch, and then unplug the power cord from the wall outlet.
- Disconnect all cords and cables from the printer before moving it.

- Use the handholds located on both sides of the printer to lift it.
- Make sure your fingers are not under the printer when you set it down.
- Before setting up the printer, make sure there is adequate clearance around it. For more information, see “Selecting a location for the printer” on page 12.

The printer and options can be safely moved to another location by following these precautions:

- Any cart used to move the printer must be able to support its weight and have a large enough surface to support the full footprint of the printer.
- Keep the printer in an upright position.
- Avoid severe jarring movements.

Shipping the printer

When shipping the printer, use the original packaging or call the place of purchase for a relocation kit.

Administrative support

Finding advanced networking and administrator information

This chapter covers basic administrative support tasks. For more advanced system support tasks, see the *Networking Guide* on the *Software and Documentation* CD and the *Embedded Web Server Administrator's Guide* on the Lexmark Web site at www.lexmark.com.

Using the Embedded Web Server

If the printer is installed on a network, the Embedded Web Server is available for a range of functions including:

- Viewing a virtual display of the printer control panel
- Checking the status of the printer supplies
- Configuring printer settings
- Configuring network settings
- Viewing reports

To access the Embedded Web Server, type the printer IP address into the address field of your Web browser.

Notes:

- If you do not know the IP address of the printer, then print a network setup page and locate the IP address in the TCP/IP section.
- For more information, see the *Networking Guide* on the *Software and Documentation* CD and the *Embedded Web Server Administrator's Guide* on the Lexmark™ Web site at www.lexmark.com.

Viewing reports

You can view some reports from the Embedded Web Server. These reports are useful for assessing the status of the printer, the network, and supplies.

To view reports from a network printer:

- 1 Type the printer IP address into the address field of your Web browser.

Note: If you do not know the IP address of the printer, then print a network setup page and locate the IP address in the TCP/IP section.

- 2 Click **Reports**, and then click the type of report you want to view.

Checking the device status

Using the Embedded Web Server, you can view paper tray settings, the level of toner in the print cartridge, the percentage of life remaining in the maintenance kit, and capacity measurements of certain printer parts. To view the device status:

- 1 Type the printer IP address in the address field of your Web browser.

Note: If you do not know the IP address of the printer, then print a network setup page and locate the IP address in the TCP/IP section.

- 2 Click **Device Status**.

Setting up e-mail alerts

You can have the printer send you an e-mail when toner is getting low.

To set up e-mail alerts:

- 1 Type the printer IP address into the address field of your Web browser.

Note: If you do not know the IP address of the printer, then print a network setup page and locate the IP address in the TCP/IP section.

- 2 Click **Settings**.

- 3 Under Other Settings, click **E-mail Alert Setup**.

- 4 Select the items for notification and type in the e-mail addresses that you want to receive e-mail alerts.

- 5 Click **Submit**.

Note: See your system support person to set up the e-mail server.



Restoring the factory default settings

If you want to retain a list of the current menu settings for reference, then print a menu settings page before you restore the factory default settings. For more information, see “Printing a menu settings page” on page 22.

Warning—Potential Damage: Restoring factory defaults returns most printer settings to the original factory default setting. Exceptions include the display language, custom sizes and messages, and Network/Port menu settings. All downloads stored in RAM are deleted. Downloads stored in flash memory or on a printer hard disk are not affected.

- 1 From the printer control panel, press .

- 2 Press the arrow buttons until  **Settings** appears, and then press .

- 3 Press the arrow buttons until  **General Settings** appears, and then press .

- 4 Press the arrow buttons until  **Factory Defaults** appears, and then press .

- 5 Press the arrow buttons until  **Restore Now** appears, and then press .

Restoring Factory Defaults appears.

Troubleshooting

Checking an unresponsive printer

If there are basic printer problems, or the printer is unresponsive, make sure:

- The power cord is plugged into the printer and a properly grounded electrical outlet.
- The electrical outlet is not turned off by any switch.
- The *Ground Fault Circuit Interrupter* (GFCI) has not tripped.
- The printer is not plugged into any surge protectors, uninterrupted power supplies, or extension cords.
- Other electronic equipment plugged into the outlet is working.
- The printer is turned on. Check the printer power switch.
- The printer cable is securely attached to the printer and the host computer, print server, or other network device.
- The printer driver settings are correct.

Once you have checked each of these possibilities, turn the printer off, wait for about 10 seconds, and then turn the printer back on. This often fixes the problem.

Printer control panel display is blank or displays only diamonds

The printer self test failed. Turn the printer off, wait about 10 seconds, and then turn the printer back on.

If **Performing Self Test** and **Ready** do not appear, turn the printer off and contact Customer Support.

Partial document or photo print, copies, or scans

These are possible solutions. Try one or more of the following:

CHECK THE DOCUMENT PLACEMENT

Make sure the document or photo is loaded facedown on the scanner glass in the upper left corner.

CHECK THE PAPER SIZE SETTING

Make sure the paper size setting matches the paper loaded in the tray:

- 1 From the printer control panel, check the Paper Size setting from the Paper menu.
- 2 Before sending the job to print, specify the correct size setting:
 - For Windows users, specify the size from Print Properties.
 - For Macintosh users, specify the size from the Page Setup dialog.

REINSTALL THE TONER CARTRIDGE

Remove and reinstall the toner cartridge, making sure that it is aligned correctly.

Understanding printer messages

Close front door

Close the front door of the printer.

Invalid Engine Code

You need to download valid engine code for the printer.

Note: Engine code may be downloaded while this message appears on the display.

Load <src> with <x>

Try one or more of the following:

- Load the paper tray with the correct paper type and size.
- Cancel the current job.

Network/Network <x>

The printer is connected to the network.

Network indicates that the printer is using the standard network port built into the printer system board. **Network <x>** indicates that an internal print server is installed inside the printer or that the printer is connected to an external print server.

Programming Engine Code DO NOT POWER OFF

Wait for the message to clear.

Warning—Potential Damage: Do not turn the printer power off while **Programming Engine Code** appears on the display.



Programming System Code DO NOT POWER OFF

Wait for the message to clear.

Warning—Potential Damage: Do not turn the printer power off while **Programming System Code** appears on the display.

Cartridge is low

Try one or more of the following:

- Replace the toner cartridge, and then press  to clear the message and continue printing.
- Press  to clear the message and continue printing.

Waiting

The printer has received data to print, but is waiting for an End-of-Job command, a Form Feed command, or additional data.

- Press to print the contents of the buffer.
- Cancel the current print job.

31.yy Replace defective or missing cartridge

The toner cartridge is either missing or not functioning properly.

Try one or more of the following:

- Remove the toner cartridge, and then reinstall it.
- Remove the toner cartridge, and then install a new one.

30 Invalid refill, change toner cartridge

The printer has detected an invalid, refilled toner cartridge. Remove the toner cartridge, and then install a new one.

32 Replace unsupported cartridge

Remove the toner cartridge, and then install a supported one.

34 Short paper

The printer paper size setting did not match the length of the paper that entered the printer.

Try one or more of the following:

- Press to clear the message and continue printing.
- Press , and then press to cancel printing.
- Make sure the paper size setting matches the size of the paper in the tray.

37 Insufficient memory to collate job

Try one or more of the following:

- Press the arrow buttons until **Continue** appears, and then press to print the portion of the job already stored and begin collating the rest of the print job.
- Cancel the current print job.

38 Memory full

Try one or more of the following:

- Press the arrow buttons until **Continue** appears, and then press to clear the message.
- Cancel the current print job.

39 Complex page, some data may not have printed

Try one or more of the following:

- Press the arrow buttons until **Continue** appears, and then press to clear the message and continue printing.
- Cancel the current print job.

54 Standard network software error

Try one or more of the following:

- Press the arrow buttons until **Continue** appears, and then press to continue printing.
- Turn the printer off and then back on to reset the printer.
- Upgrade (flash) the network firmware in the printer or print server.

54 Network <x> software error

Try one or more of the following:

- Press the arrow buttons until **Continue** appears, and then press to continue printing.
- Turn the printer off and then back on to reset the printer.
- Upgrade (flash) the network firmware in the printer or print server.

56 Standard USB port disabled

Try one or more of the following:

- The printer discards any data received through the USB port. Press to clear the message and continue printing.
- Make sure the USB Buffer menu item is not set to Disabled.

84 PC Kit life warning

The photoconductor kit is near exhaustion.

Try one or more of the following:

- Replace the photoconductor kit.
- Press to clear the message and continue printing.

84 Replace PC Kit

The photoconductor kit is exhausted. Install a new photoconductor kit.

88.yy Cartridge is low


Replace the toner cartridge, and then press to clear the message and continue printing.

200–250 paper jam


- 1 Clear the paper path. For more information, see “Clearing jams” on page 136.
- 2 After clearing the paper path, press to resume printing.

290–294 paper jams


- 1 Remove all original documents from the ADF.
- 2 Open the ADF cover.




- 3 Unlock the separator roll.




- 4 Remove the separator roll.




- 5 Remove the jammed paper.
- 6 Reinstall the separator roll.




- 7 Lock the separator roll.



- 8 Close the ADF cover.



9 Open the scanner cover, and then remove any jammed pages.




10 Press .

840.01 Scanner Disabled

This message indicates that the scanner has been disabled by the system support person.

840.02 Scanner Auto Disabled

This message indicates that the printer identified a problem with the scanner and automatically disabled it.

- 1 Remove all pages from the ADF.
- 2 Turn the printer off.
- 3 Wait 15 seconds, and then turn the printer on.
- 4 Place the document in the ADF, and then adjust the paper guides.
- 5 Press .

Note: If turning the printer off and then on again does not clear the message, then contact your system support person.

Clearing jams

By carefully selecting paper and loading it properly, you can avoid most jams. If jams do occur, follow the steps outlined in this chapter.

To clear a jam message and resume printing, clear the entire paper path, and then press . If Jam Recovery is set to On, the printer prints a new copy of the page that jammed. If Jam Recovery is set to Auto, the printer may or may not print a new copy of the page that jammed.

Avoiding jams


The following hints can help you avoid jams:

Paper tray recommendations

- Make sure the paper lies flat in the paper tray.
- Do not remove the paper tray while the printer is printing.
- Do not load the paper tray while the printer is printing. Load it prior to printing, or wait for a prompt to load it.
- Do not load too much paper. Make sure the stack height does not exceed the indicated maximum height.
- Make sure the guides in the paper tray or the manual feeder are properly positioned and are not pressing too tightly against the paper or envelopes.
- Push the paper tray in firmly after loading paper.

Paper recommendations

- Use only recommended paper or specialty media.
- Do not load wrinkled, creased, damp, bent, or curled paper.
- Flex, fan, and straighten paper before loading it.




- Do not use paper that has been cut or trimmed by hand.
- Do not mix paper sizes, weights, or types in the same stack.
- Make sure all sizes and types are set correctly in the printer control panel menus.
- Store paper per the manufacturer's recommendations.


200–201 paper jam

200 paper jam

- 1 Remove the tray from the printer.




- 2 Remove the jam if you see it here.




- 3 If you do not see it, see “201 paper jam” on page 138.

201 paper jam

- 1 Open the front door, and then remove the photoconductor kit and toner cartridge.




- 2 Lift the flap at the front of the printer, and remove any jammed sheets.




- 3 Align and insert the photoconductor kit and toner cartridge.
- 4 Close the front door.
- 5 Insert the tray.
- 6 Press .


202 paper jam

 **CAUTION—HOT SURFACE:** The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching.


- 1 Open the front door, and then remove the photoconductor kit and toner cartridge.




- 2 Lift the flap at the front of the printer, and then remove any jammed sheets.



3 Open the rear door.



4 Remove the jam.



5 Close the rear door.


6 Align and insert the photoconductor kit and toner cartridge.

7 Close the front door.


8 Press .

241 paper jam


1 Remove the tray from the printer.



2 Remove the jam.




3 Insert the tray.

4 Press .


251 paper jam

A sheet of paper or specialty media failed to feed completely from the manual feeder. Part of it may be still visible. If it is visible, then gently pull the jammed sheet from the front of the manual feeder.




If the sheet is not visible, then complete the following steps:

- 1 Remove the photoconductor kit and toner cartridge.



2 Lift the flap at the front of the printer, and then remove any jammed sheets.



3 Align and insert the photoconductor kit and toner cartridge.

4 Press .

Solving printing problems

Jobs do not print

These are possible solutions. Try one or more of the following:

MAKE SURE THE PRINTER IS READY TO PRINT

Make sure **Ready** or **Power Saver** appears on the display before sending a job to print.

CHECK TO SEE IF THE STANDARD EXIT BIN IS FULL

Remove the stack of paper from the standard exit bin.

CHECK TO SEE IF THE TRAY IS EMPTY

Load paper in the tray.

MAKE SURE THE CORRECT PRINTER SOFTWARE IS INSTALLED

Verify that you installed the correct printer software for your printer model. Open the *Software and Documentation* CD to check which software is installed. For more information, see “Installing printer software” on page 21. Make sure the model number of the software matches the model number of your printer.

To verify that the printer software is the most current, check the Lexmark Web site at www.lexmark.com.

MAKE SURE THE PRINTER IS CONNECTED TO THE NETWORK

Print a network setup page and check that the status shows **Connected**. If the status is **Not Connected**, check the network cables, and then try printing the network setup page again. Contact your system support person to make sure the network is functioning correctly.

MAKE SURE YOU ARE USING A RECOMMENDED USB OR ETHERNET CABLE

For more information, visit the Lexmark Web site at www.lexmark.com.

MAKE SURE PRINTER CABLES ARE SECURELY CONNECTED

Check the cable connections to the printer to make sure they are secure. For more information, see the setup documentation that came with the printer.

Multiple-language PDFs do not print

The documents contain unavailable fonts.

- 1** Open the document you want to print in Adobe Acrobat.
- 2** Click the printer icon.
The Print dialog appears.
- 3** Click **Advanced**.
- 4** Select **Print as image**.
- 5** Click **OK** twice.

Job takes longer than expected to print

These are possible solutions. Try one or more of the following:

REDUCE THE COMPLEXITY OF THE PRINT JOB

Reduce the number and size of fonts, the number and complexity of images, and the number of pages in the job.

CHANGE ENVIRONMENTAL SETTINGS

When using Eco-Mode or Quiet Mode settings, you may notice a short delay before the first page is printed. If you want to change the settings and need more information, then see “Using Eco-Mode” on page 26 or “Reducing printer noise” on page 28.

Incorrect characters print

- Make sure the printer is not in Hex Trace mode. If **Ready Hex** appears on the display, you must exit Hex Trace mode before you can print your job. Turn the printer off and back on to exit Hex Trace mode.
- Make sure the SmartSwitch settings are set to On in the Network and USB menus.

Large jobs do not collate

These are possible solutions. Try one or more of the following:

MAKE SURE COLLATE IS SET TO ON

From Print Properties or the printer control panel Finishing menu, set Collate to On.







Note: Setting Collate to Off in the software overrides the setting in the Finishing menu.

REDUCE THE COMPLEXITY OF THE PRINT JOB

Reduce the complexity of the print job by reducing the number and size of fonts, the number and complexity of images, and the number of pages in the job.

Unexpected page breaks occur

Increase the Print Timeout value:

- 1 From the printer control panel, press .
- 2 Press the arrow buttons until **Settings** appears, and then press .
- 3 Press the arrow buttons until **General Settings** appears, and then press .
- 4 Press the arrow buttons until **Timeouts** appears, and then press .
- 5 Press the arrow buttons until **Print Timeout** appears, and then press .
- 6 Press the arrow buttons until the value you want appears, and then press .

Solving copy problems

Copier does not respond

These are possible solutions. Try one or more of the following:

CHECK THE DISPLAY FOR ERROR MESSAGES

Clear any error messages.

CHECK THE POWER

Make sure the printer is plugged in, the power is on, and **Ready** appears.

Scanner unit does not close

Make sure there are no obstructions:

- 1 Lift the scanner unit.
- 2 Remove any obstruction keeping the scanner unit open.

3 Lower the scanner unit.

Poor copy quality

These are some examples of poor copy quality:

- Blank pages
- Checkerboard pattern
- Distorted graphics or pictures
- Missing characters
- Faded print
- Dark print
- Skewed lines
- Smudges
- Streaks
- Unexpected characters
- White or black lines in print

These are possible solutions. Try one or more of the following. For additional potential solutions, see “Solving print quality problems” on page 153.

CHECK THE DISPLAY FOR ERROR MESSAGES

Clear any error messages.

THE TONER MAY BE LOW

When **88 Cartridge is low** appears or when the print becomes faded, replace the toner cartridge.

THE SCANNER GLASS MAY BE DIRTY

Clean the scanner glass with a clean, lint-free cloth dampened with water. For more information, see “Cleaning the scanner glass” on page 115.

THE COPY IS TOO LIGHT OR TOO DARK

Adjust the darkness of the copy.

CHECK THE QUALITY OF THE ORIGINAL DOCUMENT

Make sure the quality of the original document is satisfactory.

CHECK THE DOCUMENT PLACEMENT

Make sure the document or photo is loaded facedown on the scanner glass in the upper left corner.

UNWANTED TONER IS IN THE BACKGROUND

- Increase the background removal setting.
- Adjust the darkness to a lighter setting.

PATTERNS (MOIRÉ) APPEAR IN THE OUTPUT

- Use the **Text/Photo** or **Photo** settings.
- Adjust the scale setting.
- Adjust the sharpness setting.

TEXT IS LIGHT OR DISAPPEARING

- Decrease the background removal setting.
- Increase the contrast setting.
- Decrease the shadow detail setting.
- Increase the sharpness setting.

THE OUTPUT APPEARS WASHED OUT OR OVEREXPOSED

- Increase the darkness setting.
- Decrease the background removal setting.

Solving scanner problems

Checking an unresponsive scanner

If your scanner is not responding, then make sure:

- The printer is turned on.
- The printer cable is securely attached to the printer and the host computer.
- The Ethernet cable is securely attached to the printer and your network connection.
- The power cord is plugged into the printer and a properly grounded electrical outlet.
- The electrical outlet is not turned off by any switch or breaker.
- The printer is not plugged into any surge protectors, uninterruptible power supplies, or extension cords.
- Other electrical equipment plugged into the outlet is working.

Once you have checked each of these possibilities, turn the printer off and then back on. This often fixes the problem with the scanner.

Scan was not successful

These are possible solutions. Try one or more of the following:

CHECK THE CABLE CONNECTIONS

Make sure the network or USB cable is securely connected to the computer and the printer.

AN ERROR MAY HAVE OCCURRED IN THE PROGRAM

Turn off and then restart the computer.

Scanning takes too long or freezes the computer

These are possible solutions. Try one or more of the following:

OTHER SOFTWARE PROGRAMS MAY BE INTERFERING WITH SCANNING

Close all programs not being used.

THE SCAN RESOLUTION MAY BE SET TOO HIGH

Select a lower scan resolution.

Poor scanned image quality

These are possible solutions. Try one or more of the following:

CHECK THE DISPLAY FOR ERROR MESSAGES

Clear any error messages.

THE SCANNER GLASS MAY BE DIRTY

Clean the scanner glass with a clean, lint-free cloth dampened with water. For more information, see “Cleaning the scanner glass” on page 115.

ADJUST THE SCAN RESOLUTION

Increase the resolution of the scan for a higher quality output.

CHECK THE QUALITY OF THE ORIGINAL DOCUMENT

Make sure the quality of the original document is satisfactory.

CHECK THE DOCUMENT PLACEMENT

Make sure the document or photo is loaded facedown on the scanner glass in the upper left corner.

Cannot scan from a computer

These are possible solutions. Try one or more of the following:

CHECK THE DISPLAY FOR ERROR MESSAGES

Clear any error messages.

CHECK THE POWER

Make sure the printer is plugged in, the power is on, and **Ready** appears.

CHECK THE CABLE CONNECTIONS

Make sure the network or USB cable is securely connected to the computer and the printer.

Cannot create a Scan Profile

These are possible solutions. Try one or more of the following:

CHECK THE JAVA SETTING

If only a grey box appears, then make sure Sun Microsystems' Java Virtual Machine (JVM) version 1.4.2 or higher is installed on your computer.

DISABLE WINDOWS XP FIREWALL

If you are using Windows XP, then the Windows XP personal firewall must be disabled before you can use Scan to PC profiles.

Solving fax problems

Caller ID is not shown

Contact your telecommunications company to verify that your telephone line is subscribed to the caller ID service.

If your region supports multiple caller ID patterns, you may have to change the default setting. There are two settings available: FSK (pattern 1) and DTMF (pattern 2). The availability of these settings by way of the Fax menu depends on whether your country or region supports multiple caller ID patterns. Contact your telecommunications company to determine which pattern or switch setting to use.

Cannot send or receive a fax

These are possible solutions. Try one or more of the following:

CHECK THE DISPLAY FOR ERROR MESSAGES

Clear any error messages.

CHECK THE POWER

Make sure the printer is plugged in, the power is on, and **Ready** appears.

CHECK THE PRINTER CONNECTIONS

Make sure the cable connections for the following hardware are secure, if applicable:

- Telephone
- Handset
- Answering machine

CHECK THE TELEPHONE WALL JACK

- 1 Plug a telephone into the wall jack.
- 2 Listen for a dial tone.
- 3 If you do not hear a dial tone, then plug a different telephone into the wall jack.
- 4 If you still do not hear a dial tone, then plug a telephone into a different wall jack.
- 5 If you hear a dial tone, then connect the printer to that wall jack.

REVIEW THIS DIGITAL PHONE SERVICE CHECKLIST

The fax modem is an analog device. Certain devices can be connected to the printer so that digital telephone services can be used.

- If you are using an ISDN telephone service, then connect the printer to an analog telephone port (an R-interface port) on an ISDN terminal adapter. For more information and to request an R-interface port, contact your ISDN provider.
- If you are using DSL, then connect to a DSL filter or router that will support analog use. For more information, contact your DSL provider.
- If you are using a PBX telephone service, then make sure you are connecting to an analog connection on the PBX. If none exists, consider installing an analog telephone line for the fax machine.

CHECK FOR A DIAL TONE

- Place a test call to the telephone number to which you want to send a fax to make sure that it is working correctly.
- If the telephone line is being used by another device, then wait until the other device is finished before sending a fax.
- If you are using the On Hook Dial feature, then turn up the volume to verify a dial tone.

TEMPORARILY DISCONNECT OTHER EQUIPMENT

To ensure the printer is working correctly, connect it directly to the telephone line. Disconnect any answering machines, computers with modems, or telephone line splitters.

CHECK FOR JAMS

Clear any jams, and then make sure that **Ready** appears.

TEMPORARILY DISABLE CALL WAITING

Call Waiting can disrupt fax transmissions. Disable this feature before sending or receiving a fax. Call your telephone company to obtain the keypad sequence for temporarily disabling Call Waiting.

VOICE MAIL SERVICE MAY BE INTERFERING WITH THE FAX TRANSMISSION

Voice Mail offered through your local telephone company may disrupt fax transmissions. To enable both Voice Mail and the printer to answer calls, you may want to consider adding a second telephone line for the printer.

THE PRINTER MEMORY MAY BE FULL

- 1 Dial the fax number.
- 2 Scan the original document one page at a time.

Can send but not receive faxes

These are possible solutions. Try one or more of the following:

CHECK TO SEE IF THE PAPER TRAY IS EMPTY

Load paper in the tray.

CHECK THE RING COUNT DELAY SETTINGS

The ring count delay sets the number of times the phone line rings before the printer answers. If you have extension phones on the same line as the printer, or subscribe to the telephone company's Distinctive Ring service, then keep the Ring Delay setting at 4.

- 1 Type the printer IP address into the address field of your Web browser.

Note: If you do not know the IP address of the printer, then print a network setup page and locate the IP address in the TCP/IP section.

- 2 Click **Settings**.
- 3 Click **Fax Settings**.
- 4 Click **Analog Fax Setup**.
- 5 In the Rings to Answer box, enter the number of times you want the phone to ring before answering.
- 6 Click **Submit**.

THE TONER MAY BE LOW

88 **Cartridge low** appears when the toner is low.

Can receive but not send faxes

These are possible solutions. Try one or more of the following:

MAKE SURE THE PRINTER IS IN FAX MODE

From the printer control panel, press the **Fax** button to put the printer in Fax mode.

MAKE SURE THE DOCUMENT IS LOADED PROPERLY

Load the original document faceup, short edge first into the ADF or facedown on the scanner glass in the upper left corner.

Note: Do not load postcards, photos, small items, transparencies, photo paper, or thin media (such as magazine clippings) into the ADF. Place these items on the scanner glass.

MAKE SURE THE SHORTCUT NUMBER IS SET UP PROPERLY

- Check to make sure the shortcut number has been programmed for the number that you want to dial.
- As an alternative, dial the telephone number manually.

Received fax has poor print quality

These are possible solutions. Try one or more of the following:

RESEND THE DOCUMENT

Ask the person who sent you the fax to:

- Check that the quality of the original document is satisfactory.
- Resend the fax. There may have been a problem with the quality of the telephone line connection.
- Increase the fax scan resolution, if possible.

THE TONER MAY BE LOW

When **88 Cartridge low** appears or when you experience faded print, replace the cartridge.

MAKE SURE THE FAX TRANSMISSION SPEED IS NOT SET TOO HIGH

Decrease the incoming fax transmission speed:

1 Type the printer IP address into the address field of your Web browser.

Note: If you do not know the IP address of the printer, then print a network setup page and locate the IP address in the TCP/IP section.

2 Click **Settings**.

3 Click **Fax Settings**.

4 Click **Analog Fax Setup**.

5 In the Max Speed box, select a lower speed.

6 Click **Submit**.

Solving paper feed problems

Paper frequently jams

These are possible solutions. Try one or more of the following:

CHECK THE PAPER

Use recommended paper and other specialty media. For more information, see “Paper and specialty media guidelines” on page 38.

MAKE SURE THERE IS NOT TOO MUCH PAPER IN THE PAPER TRAY OR MANUAL FEEDER

In the paper tray, make sure the stack of paper you load does not exceed the maximum stack height indicated in the tray. In the manual feeder, do not load more than a single sheet of paper at a time.


CHECK THE GUIDES

Move the guides in the paper tray to the correct positions for the paper size loaded.

THE PAPER ABSORBED MOISTURE DUE TO HIGH HUMIDITY

- Load paper from a fresh package.
- Store paper in its original wrapper until you use it.

Paper jam message remains after jam is cleared


The paper path is not clear. Clear jammed paper from the entire paper path, and then press .

Solving print quality problems

The information in the following topics may help you solve print quality problems. If these suggestions still do not correct the problem, then contact Customer Support. You may have a printer part that requires adjustment or replacement.


Isolating print quality problems

To help isolate print quality problems, print the print quality test pages:

- 1 Turn the printer off.
- 2 Load paper.
- 3 From the printer control panel, hold down  and the right arrow button while turning the printer on.
- 4 Release the buttons when **CONFIG MENU** appears.

- 5 Press the arrow buttons until **Prt Quality Pgs** appears, and then press .
The print quality test pages print.
- 6 Press the arrow buttons until **Exit Config Menu** appears, and then press .
Resetting the Printer appears briefly, and then **Ready** appears.

Blank pages



These are possible solutions. Try one or more of the following:

PACKING MATERIAL MAY BE ON THE TONER CARTRIDGE OR PHOTOCONDUCTOR KIT


- 1 Remove the toner cartridge and photoconductor kit.
- 2 Remove any remaining packing material.
- 3 Reinstall the toner cartridge and photoconductor kit.

THE TONER MAY BE LOW

When **88 Cartridge low** appears, order a new toner cartridge.

If the problem continues, the printer may need to be serviced. For more information, contact Customer Support.

Characters have jagged or uneven edges



If you are using downloaded fonts, verify that the fonts are supported by the printer, the host computer, and the software program.

Clipped images

These are possible solutions. Try one or more of the following:

CHECK THE GUIDES


Move the width and length guides in the tray to the correct positions for the paper size loaded.

CHECK THE PAPER SIZE SETTING

Make sure the paper size setting matches the paper loaded in the tray:

- 1 From the printer control panel, check the Paper Size setting from the Paper menu.
- 2 Before sending the job to print, specify the correct size setting:
 - For Windows users, specify the size from Print Properties.
 - For Macintosh users, specify the size from the Page Setup dialog.

Gray background




CHECK THE TONER DARKNESS SETTING

Select a lighter Toner Darkness setting:

- From the printer control panel, change the setting from the Quality menu.
- For Windows users, change the setting from Print Properties.
- For Macintosh users, change the setting from the Print dialog.

Ghost images



These are possible solutions. Try one or more of the following:

THE PHOTOCONDUCTOR KIT IS DEFECTIVE


Replace the photoconductor kit.

CHECK THE PAPER TYPE SETTING

Make sure the paper type setting matches the paper loaded in the tray:

- 1 From the printer control panel, check the Paper Type setting from the Paper menu.
- 2 Before sending the job to print, specify the correct type setting:
 - For Windows users, specify the type from Print Properties.
 - For Macintosh users, specify the type from the Print dialog.

Incorrect margins



These are possible solutions. Try one or more of the following:

CHECK THE PAPER GUIDES

Move the guides in the tray to the correct positions for the paper size loaded.

CHECK THE PAPER SIZE SETTING

Make sure the paper size setting matches the paper loaded in the tray:

- 1 From the printer control panel, check the Paper Size setting from the Paper menu.
- 2 Before sending the job to print, specify the correct size setting:
 - For Windows users, specify the size from Print Properties.
 - For Macintosh users, specify the size from the Page Setup dialog.

Paper curl

These are possible solutions. Try one or more of the following:

CHECK THE PAPER TYPE SETTING


Make sure the paper type setting matches the paper loaded in the tray:

- 1 From the printer control panel, check the Paper Type setting from the Paper menu.
- 2 Before sending the job to print, specify the correct type setting:
 - For Windows users, specify the type from Print Properties.
 - For Macintosh users, specify the type from the Print dialog.

THE PAPER HAS ABSORBED MOISTURE DUE TO HIGH HUMIDITY

- Load paper from a fresh package.
- Store paper in its original wrapper until you use it.

Print is too dark



These are possible solutions. Try one or more of the following:

CHECK THE DARKNESS SETTINGS

The Toner Darkness setting is too dark.

- From the printer control panel, change this setting from the Quality menu.
- For Windows users, change this setting from Print Properties.
- For Macintosh users, change this setting from the Print dialog and pop-up menus.

THE PAPER HAS ABSORBED MOISTURE DUE TO HIGH HUMIDITY

- Load paper from a fresh package.
- Store paper in its original wrapper until you use it.

CHECK THE PAPER

Avoid textured paper with rough finishes.

CHECK THE PAPER TYPE SETTING


Make sure the paper type setting matches the paper loaded in the tray:

- 1 From the printer control panel, check the Paper Type setting from the Paper menu.
- 2 Before sending the job to print, specify the correct type setting:
 - For Windows users, specify the type from Print Properties.
 - For Macintosh users, specify the type from the Print dialog.

THE TONER CARTRIDGE MAY BE DEFECTIVE

Replace the toner cartridge.

Print is too light



These are possible solutions. Try one or more of the following:

CHECK THE DARKNESS SETTINGS

The Toner Darkness setting is too light.

- From the printer control panel, change this setting from the Quality menu.
- For Windows users, change this setting from Print Properties.
- For Macintosh users, change this setting from the Print dialog and pop-up menus.

THE PAPER HAS ABSORBED MOISTURE DUE TO HIGH HUMIDITY

- Load paper from a fresh package.
- Store paper in its original wrapper until you use it.

CHECK THE PAPER

Avoid textured paper with rough finishes.

CHECK THE PAPER TYPE SETTING

Make sure the paper type setting matches the paper loaded in the tray:

- 1 From the printer control panel, check the Paper Type setting from the Paper menu.
- 2 Before sending the job to print, specify the correct type setting:
 - For Windows users, specify the type from Print Properties.
 - For Macintosh users, specify the type from the Print dialog.

THE TONER MAY BE LOW

When **88 Cartridge is low** appears, replace the toner cartridge.

THE TONER CARTRIDGE MAY BE DEFECTIVE

Replace the toner cartridge.

Skewed print

These are possible solutions. Try one or more of the following:



CHECK THE PAPER GUIDES

Move the guides in the tray to the correct positions for the paper size loaded.

CHECK THE PAPER

Make sure you are using paper that meets the printer specifications.

Solid black or white streaks appear on transparencies or paper



These are possible solutions. Try one or more of the following:

MAKE SURE THE FILL PATTERN IS CORRECT

If the fill pattern is incorrect, choose a different fill pattern from your software program.

CHECK THE PAPER TYPE

- Try a different type of paper.
- For transparencies, use only ones recommended by the printer manufacturer.
- Make sure the Paper Type setting matches what is loaded in the tray or feeder.
- Make sure the Paper Texture setting is correct for the type of paper or specialty media loaded in the tray or feeder.

MAKE SURE THE TONER IS DISTRIBUTED EVENLY IN THE TONER CARTRIDGE

Remove the toner cartridge and shake it from side to side to redistribute the toner, and then reinstall it.


THE TONER CARTRIDGE MAY BE DEFECTIVE OR LOW ON TONER

Replace the used toner cartridge with a new one.

CLEAN THE ADF AND SCANNER GLASS

If you are using the ADF and vertical black or white lines appear, then clean the ADF glass.

Streaked horizontal lines



These are possible solutions. Try one or more of the following:

THE TONER MAY SMEAR WHEN PAPER IS FED FROM A SPECIFIC SOURCE


From Print Properties, the Print dialog, or the printer control panel, select another paper source for the job.

THE TONER CARTRIDGE MAY BE DEFECTIVE

Replace the toner cartridge.

MAKE SURE THE PAPER PATH IS CLEAR

Paper could be caught between the photoconductor kit and the fuser. Check the paper path around the fuser area.


 **CAUTION—HOT SURFACE:** The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching.

Clear any paper you see.

THERE MAY BE EXCESS TONER IN THE PAPER PATH

Clean the toner from the paper path. If the problem persists, contact Customer Support.

Streaked vertical lines



These are possible solutions. Try one or more of the following:

THE TONER MAY SMEAR WHEN PAPER IS FED FROM A SPECIFIC SOURCE

From Print Properties, the Print dialog, or the printer control panel, select another paper source for the job.

THE TONER CARTRIDGE IS DEFECTIVE

Replace the toner cartridge.

MAKE SURE THE PAPER PATH IS CLEAR

Paper could be caught between the photoconductor kit and the fuser. Check the paper path around the fuser area.

Warning—Potential Damage: Do not touch the photoconductor on the underside of the photoconductor kit. Use the cartridge handle whenever you are holding the cartridge.



CAUTION—HOT SURFACE: The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching.

Clear any paper you see.

THERE MAY BE EXCESS TONER IN THE PAPER PATH

Clean the toner from the paper path. Contact Customer Support.

Toner fog or background shading appears on the page

These are possible solutions. Try one or more of the following:


THE TONER CARTRIDGE MAY BE DEFECTIVE

Replace the toner cartridge.

THERE IS TONER IN THE PAPER PATH

Contact Customer Support.

Toner rubs off



These are possible solutions. Try one or more of the following:

CHECK THE PAPER TYPE SETTING


Make sure the paper type setting matches the paper loaded in the tray:

- 1 From the printer control panel, check the Paper Type setting from the Paper menu.
- 2 Before sending the job to print, specify the correct type setting:
 - For Windows users, specify the type from Print Properties.
 - For Macintosh users, specify the type from the Print dialog.

CHECK THE PAPER TEXTURE SETTING

From the printer control panel Paper menu, make sure the Paper Texture setting matches the paper loaded in the tray.

Toner specks



These are possible solutions. Try one or more of the following:

THE TONER CARTRIDGE MAY BE DEFECTIVE

Replace the toner cartridge.

THERE IS TONER IN THE PAPER PATH

Contact Customer Support.

Transparency print quality is poor

Try one or more of the following:

CHECK THE TRANSPARENCIES

Use only transparencies recommended by the printer manufacturer.

CHECK THE PAPER TYPE SETTING

Make sure the paper type setting matches the paper loaded in the tray:

- 1 From the printer control panel, check the Paper Type setting from the Paper menu.
- 2 Before sending the job to print, specify the correct type setting:
 - For Windows users, specify the type from Print Properties.
 - For Macintosh users, specify the type from the Print dialog.

Embedded Web Server does not open

These are possible solutions. Try one or more of the following:

CHECK THE NETWORK CONNECTIONS

Make sure the printer and computer are turned on and connected to the same network.

CHECK THE NETWORK SETTINGS

Depending on the network settings, you may need to type `https://` instead of `http://` before the printer IP address to access the Embedded Web Server. For more information, see your system administrator.

Contacting Customer Support

When you call Customer Support, describe the problem you are experiencing, the message on the display, and the troubleshooting steps you have already taken to find a solution.

You need to know your printer model type and serial number. For more information, see the label on the inside top front cover of the printer. The serial number is also listed on the menu settings page.

In the U.S. or Canada, call (1-800-539-6275). For other countries/regions, visit the Lexmark Web site at www.lexmark.com.

Notices

Product information

Product name:

Lexmark X203n, Lexmark X204n

Machine type:

7011

Model(s):

200, 215, 300, 315

Edition notice

August 2011

The following paragraph does not apply to any country where such provisions are inconsistent with local law:

LEXMARK INTERNATIONAL, INC., PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions; therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time.

References in this publication to products, programs, or services do not imply that the manufacturer intends to make these available in all countries in which it operates. Any reference to a product, program, or service is not intended to state or imply that only that product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any existing intellectual property right may be used instead. Evaluation and verification of operation in conjunction with other products, programs, or services, except those expressly designated by the manufacturer, are the user's responsibility.

For Lexmark technical support, visit support.lexmark.com.

For information on supplies and downloads, visit www.lexmark.com.

If you don't have access to the Internet, you can contact Lexmark by mail:

Lexmark International, Inc.
Bldg 004-2/CSC
740 New Circle Road NW
Lexington, KY 40550
USA

© 2009 Lexmark International, Inc.

All rights reserved.

UNITED STATES GOVERNMENT RIGHTS

This software and any accompanying documentation provided under this agreement are commercial computer software and documentation developed exclusively at private expense.

Trademarks

Lexmark and Lexmark with diamond design are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

PCL® is a registered trademark of the Hewlett-Packard Company. PCL is Hewlett-Packard Company's designation of a set of printer commands (language) and functions included in its printer products. This printer is intended to be compatible with the PCL language. This means the printer recognizes PCL commands used in various application programs, and that the printer emulates the functions corresponding to the commands.

Sun, Sun Microsystems, Solaris, and the Solaris Logo are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries, and are used under license.

All other trademarks are the property of their respective owners.

Federal Communications Commission (FCC) compliance information statement

This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The FCC Class B limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult your point of purchase or service representative for additional suggestions.

The manufacturer is not responsible for radio or television interference caused by using other than recommended cables or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate this equipment.

Note: To assure compliance with FCC regulations on electromagnetic interference for a Class B computing device, use a properly shielded and grounded cable such as Lexmark part number 1021231 for parallel attach or 1021294 for USB attach. Use of a substitute cable not properly shielded and grounded may result in a violation of FCC regulations.

Any questions regarding this compliance information statement should be directed to:

Director of Lexmark Technology & Services
Lexmark International, Inc.
740 West New Circle Road
Lexington, KY 40550
(859) 232-3000

Noise emission levels

The following measurements were made in accordance with ISO 7779 and reported in conformance with ISO 9296.

Note: Some modes may not apply to your product.

| 1-meter average sound pressure, dBA | |
|-------------------------------------|---------------|
| Printing | 51 dBA |
| Scanning | 52 dBA, 49dBA |
| Copying | 52 dBA |
| Ready | 26 dBA |

Values are subject to change. See www.lexmark.com for current values.

Waste from Electrical and Electronic Equipment (WEEE) directive



The WEEE logo signifies specific recycling programs and procedures for electronic products in countries of the European Union. We encourage the recycling of our products. If you have further questions about recycling options, visit the Lexmark Web site at www.lexmark.com for your local sales office phone number.

Static sensitivity notice



This symbol identifies static-sensitive parts. Do not touch in the areas near these symbols without first touching the metal frame of the printer.

ENERGY STAR




Laser notice

The printer is certified in the U.S. to conform to the requirements of DHHS 21 CFR Subchapter J for Class I (1) laser products, and elsewhere is certified as a Class I laser product conforming to the requirements of IEC 60825-1.

Class I laser products are not considered to be hazardous. The printer contains internally a Class IIIb (3b) laser that is nominally a 7 milliwatt gallium arsenide laser operating in the wavelength of 655-675 nanometers. The laser system and printer are designed so there is never any human access to laser radiation above a Class I level during normal operation, user maintenance, or prescribed service condition.

Laser advisory label

A laser notice label may be affixed to this printer as shown:



Power consumption

Product power consumption

The following table documents the power consumption characteristics of the product.

Note: Some modes may not apply to your product.

| Mode | Description | Power consumption (Watts) |
|-------------|--|---------------------------|
| Printing | The product is generating hard-copy output from electronic inputs. | 400 W |
| Copying | The product is generating hard-copy output from hard-copy original documents. | 460 W |
| Scanning | The product is scanning hard-copy documents. | 60 W |
| Ready | The product is waiting for a print job. | 70 W |
| Power Saver | The product is in energy-saving mode. | 10 W |
| Off | The product is plugged into a wall outlet, but the power switch is turned off. | 0 W |

The power consumption levels listed in the previous table represent time-averaged measurements. Instantaneous power draws may be substantially higher than the average.

Values are subject to change. See www.lexmark.com for current values.

Power Saver

This product is designed with an energy-saving mode called Power Saver. The Power Saver Mode is equivalent to the EPA Sleep Mode. The Power Saver Mode saves energy by lowering power consumption during extended periods of inactivity. The Power Saver Mode is automatically engaged after this product is not used for a specified period of time, called the Power Saver Timeout.

| | |
|--|--------------------------------------|
| Factory default Power Saver Timeout for this product (in minutes): | 110V = 45 minutes, 220V = 60 minutes |
|--|--------------------------------------|

By using the configuration menus, the Power Saver Timeout can be modified between 1 minute and 240 minutes. Setting the Power Saver Timeout to a low value reduces energy consumption, but may increase the response time of the product. Setting the Power Saver Timeout to a high value maintains a fast response, but uses more energy.

Off mode

If this product has an off mode which still consumes a small amount of power, then to completely stop product power consumption, disconnect the power supply cord from the wall outlet.

Total energy usage

It is sometimes helpful to calculate the total product energy usage. Since power consumption claims are provided in power units of Watts, the power consumption should be multiplied by the time the product spends in each mode in order to calculate energy usage. The total product energy usage is the sum of each mode's energy usage.

Statement of Limited Warranty

Lexmark X203n, Lexmark X204n

Lexmark International, Inc., Lexington, KY

This limited warranty applies to the United States and Canada. For customers outside the U.S., refer to the country-specific warranty information that came with your product.

This limited warranty applies to this product only if it was originally purchased for your use, and not for resale, from Lexmark or a Lexmark Remarketer, referred to in this statement as “Remarketer.”

Limited warranty

Lexmark warrants that this product:

- Is manufactured from new parts, or new and serviceable used parts, which perform like new parts
- Is, during normal use, free from defects in material and workmanship

If this product does not function as warranted during the warranty period, contact a Remarketer or Lexmark for repair or replacement (at Lexmark's option).

If this product is a feature or option, this statement applies only when that feature or option is used with the product for which it was intended. To obtain warranty service, you may be required to present the feature or option with the product.

If you transfer this product to another user, warranty service under the terms of this statement is available to that user for the remainder of the warranty period. You should transfer proof of original purchase and this statement to that user.

Limited warranty service

The warranty period starts on the date of original purchase as shown on the purchase receipt and ends 12 months later provided that the warranty period for any supplies and for any maintenance items included with the printer shall end earlier if it, or its original contents, are substantially used up, depleted, or consumed.

To obtain warranty service you may be required to present proof of original purchase. You may be required to deliver your product to the Remarketer or Lexmark, or ship it prepaid and suitably packaged to a Lexmark designated location. You are responsible for loss of, or damage to, a product in transit to the Remarketer or the Lexmark designated location.

When warranty service involves the exchange of a product or part, the item replaced becomes the property of the Remarketer or Lexmark. The replacement may be a new or repaired item.

The replacement item assumes the remaining warranty period of the original product.

Replacement is not available to you if the product you present for exchange is defaced, altered, in need of a repair not included in warranty service, damaged beyond repair, or if the product is not free of all legal obligations, restrictions, liens, and encumbrances.

Before you present this product for warranty service, remove all print cartridges, programs, data, and removable storage media (unless directed otherwise by Lexmark).

For further explanation of your warranty alternatives and the nearest Lexmark authorized servicer in your area contact Lexmark on the World Wide Web at www.lexmark.com/support.

Remote technical support is provided for this product throughout its warranty period. For products no longer covered by a Lexmark warranty, technical support may not be available or only be available for a fee.

Extent of limited warranty

Lexmark does not warrant uninterrupted or error-free operation of any product or the durability or longevity of prints produced by any product.

Warranty service does not include repair of failures caused by:

- Modification or unauthorized attachments

- Accidents, misuse, abuse or use inconsistent with Lexmark user's guides, manuals, instructions or guidance
- Unsuitable physical or operating environment
- Maintenance by anyone other than Lexmark or a Lexmark authorized servicer
- Operation of a product beyond the limit of its duty cycle
- Use of printing media outside of Lexmark specifications
- Refurbishment, repair, refilling or remanufacture by a third party of products, supplies or parts
- Products, supplies, parts, materials (such as toners and inks), software, or interfaces not furnished by Lexmark

TO THE EXTENT PERMITTED BY APPLICABLE LAW, NEITHER LEXMARK NOR ITS THIRD PARTY SUPPLIERS OR REMARKETERS MAKE ANY OTHER WARRANTY OR CONDITION OF ANY KIND, WHETHER EXPRESS OR IMPLIED, WITH RESPECT TO THIS PRODUCT, AND SPECIFICALLY DISCLAIM THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND SATISFACTORY QUALITY. ANY WARRANTIES THAT MAY NOT BE DISCLAIMED UNDER APPLICABLE LAW ARE LIMITED IN DURATION TO THE WARRANTY PERIOD. NO WARRANTIES, EXPRESS OR IMPLIED, WILL APPLY AFTER THIS PERIOD. ALL INFORMATION, SPECIFICATIONS, PRICES, AND SERVICES ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE.

Limitation of liability

Your sole remedy under this limited warranty is set forth in this document. For any claim concerning performance or nonperformance of Lexmark or a Remarketer for this product under this limited warranty, you may recover actual damages up to the limit set forth in the following paragraph.

Lexmark's liability for actual damages from any cause whatsoever will be limited to the amount you paid for the product that caused the damages. This limitation of liability will not apply to claims by you for bodily injury or damage to real property or tangible personal property for which Lexmark is legally liable. **IN NO EVENT WILL LEXMARK BE LIABLE FOR ANY LOST PROFITS, LOST SAVINGS, INCIDENTAL DAMAGE, OR OTHER ECONOMIC OR CONSEQUENTIAL DAMAGES.** This is true even if you advise Lexmark or a Remarketer of the possibility of such damages. Lexmark is not liable for any claim by you based on a third party claim.

This limitation of remedies also applies to claims against any Suppliers and Remarketers of Lexmark. Lexmark's and its Suppliers' and Remarketers' limitations of remedies are not cumulative. Such Suppliers and Remarketers are intended beneficiaries of this limitation.

Additional rights

Some states do not allow limitations on how long an implied warranty lasts, or do not allow the exclusion or limitation of incidental or consequential damages, so the limitations or exclusions contained above may not apply to you.

This limited warranty gives you specific legal rights. You may also have other rights that vary from state to state.

LEXMARK SOFTWARE LIMITED WARRANTY AND LICENSE AGREEMENTS

PLEASE READ CAREFULLY BEFORE USING THIS PRODUCT: BY USING THIS PRODUCT, YOU AGREE TO BE BOUND BY ALL THE TERMS AND CONDITIONS OF THIS SOFTWARE LIMITED WARRANTY AND LICENSE AGREEMENTS. IF YOU DO NOT AGREE WITH THE TERMS OF THIS SOFTWARE LIMITED WARRANTY AND LICENSE AGREEMENTS, PROMPTLY RETURN THE PRODUCT UNUSED AND REQUEST A REFUND OF THE AMOUNT YOU PAID. IF YOU ARE INSTALLING THIS PRODUCT FOR USE BY OTHER PARTIES, YOU AGREE TO INFORM THE USERS THAT USE OF THE PRODUCT INDICATES ACCEPTANCE OF THESE TERMS.

DEVICE LICENSE AGREEMENT

The patented printer is licensed for, and designed to work with only genuine Lexmark toner cartridges and developer components for the life of the patented printer. Under this patent license, you agree to: (1) use only genuine Lexmark toner cartridges and developer components with this printer except as otherwise provided below, and (2) pass this license/agreement to any subsequent user of this printer. The patented Lexmark toner cartridges and developer components inside are licensed subject to a restriction that they may be used only once. Following their initial use, you agree to return them only to Lexmark for recycling. Lexmark toner cartridges are designed to stop working after a delivering a fixed amount of toner. A variable amount of toner may remain in them when replacement is required. Replacement toner cartridge(s) sold without these terms are available through www.lexmark.com, may be refilled by you, or a third party, as the only cartridge alternative to be used with the licensed printer.

LEXMARK SOFTWARE LICENSE AGREEMENT

This Software License Agreement (“Software License Agreement”) is a legal agreement between you (either an individual or a single entity) and Lexmark International, Inc. (“Lexmark”) that, to the extent your Lexmark product or Software Program is not otherwise subject to a written software license agreement between you and Lexmark or its suppliers, governs your use of any Software Program installed on or provided by Lexmark for use in connection with your Lexmark product. The term “Software Program” includes machine-readable instructions, audio/visual content (such as images and recordings), and associated media, printed materials and electronic documentation, whether incorporated into, distributed with or for use with your Lexmark product.

- 1 STATEMENT OF SOFTWARE LIMITED WARRANTY.** Lexmark warrants that the media (e.g., diskette or compact disk) on which the Software Program (if any) is furnished is free from defects in materials and workmanship under normal use during the warranty period. The warranty period is ninety (90) days and commences on the date the Software Program is delivered to the original end-user. This limited warranty applies only to Software Program media purchased new from Lexmark or an Authorized Lexmark Reseller or Distributor. Lexmark will replace the Software Program should it be determined that the media does not conform to this limited warranty.
- 2 DISCLAIMER AND LIMITATION OF WARRANTIES.** EXCEPT AS PROVIDED IN THIS SOFTWARE LICENSE AGREEMENT AND TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, LEXMARK AND ITS SUPPLIERS PROVIDE THE SOFTWARE PROGRAM "AS IS" AND HEREBY DISCLAIM ALL OTHER WARRANTIES AND CONDITIONS, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, TITLE, NON-INFRINGEMENT, MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, AND ABSENCE OF VIRUSES, ALL WITH REGARD TO THE SOFTWARE PROGRAM. TO THE EXTENT LEXMARK CANNOT BY LAW DISCLAIM ANY COMPONENT OF THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, LEXMARK LIMITS THE DURATION OF SUCH WARRANTIES TO THE 90-DAY TERM OF THE EXPRESS SOFTWARE LIMITED WARRANTY.

This Agreement is to be read in conjunction with certain statutory provisions, as that may be in force from time to time, that imply warranties or conditions or impose obligations on Lexmark that cannot be excluded or modified. If any such provisions apply, then to the extent Lexmark is able, Lexmark hereby limits its liability for breach of those provisions to one of the following: providing you a replacement copy of the Software Program or reimbursement of the price paid for the Software Program.

The Software Program may include internet links to other software applications and/or internet web pages hosted and operated by third parties unaffiliated with Lexmark. You acknowledge and agree that Lexmark is not responsible in any way for the hosting, performance, operation, maintenance, or content of, such software applications and/or internet web pages.

- 3 LIMITATION OF REMEDY.** TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, ANY AND ALL LIABILITY OF LEXMARK UNDER THIS SOFTWARE LICENSE AGREEMENT IS EXPRESSLY LIMITED TO THE GREATER OF THE PRICE PAID FOR THE SOFTWARE PROGRAM AND FIVE U.S. DOLLARS (OR THE EQUIVALENT IN LOCAL CURRENCY). YOUR SOLE REMEDY AGAINST LEXMARK IN ANY DISPUTE UNDER THIS SOFTWARE LICENSE AGREEMENT SHALL BE TO SEEK TO RECOVER ONE OF THESE AMOUNTS, UPON PAYMENT OF WHICH LEXMARK SHALL BE RELEASED AND DISCHARGED OF ALL FURTHER OBLIGATIONS AND LIABILITY TO YOU.

IN NO EVENT WILL LEXMARK, ITS SUPPLIERS, SUBSIDIARIES, OR RESELLERS BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, EXEMPLARY, PUNITIVE, OR CONSEQUENTIAL DAMAGES (INCLUDING BUT NOT LIMITED TO LOST PROFITS OR REVENUES, LOST SAVINGS, INTERRUPTION OF USE OR ANY LOSS OF, INACCURACY IN, OR DAMAGE TO, DATA OR RECORDS, FOR CLAIMS OF THIRD PARTIES, OR DAMAGE TO REAL OR TANGIBLE PROPERTY, FOR LOSS OF PRIVACY ARISING OUT OR IN ANY WAY RELATED TO THE USE OF OR INABILITY TO USE THE SOFTWARE PROGRAM, OR OTHERWISE IN CONNECTION WITH ANY PROVISION OF THIS SOFTWARE LICENCE AGREEMENT), REGARDLESS OF THE NATURE OF THE CLAIM, INCLUDING BUT NOT LIMITED TO BREACH OF WARRANTY OR CONTRACT, TORT (INCLUDING NEGLIGENCE OR STRICT LIABILITY), AND EVEN IF LEXMARK, OR ITS SUPPLIERS, AFFILIATES, OR REMARKETERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR FOR ANY CLAIM BY YOU BASED ON A THIRD-PARTY CLAIM, EXCEPT TO THE EXTENT THIS EXCLUSION OF DAMAGES IS DETERMINED LEGALLY INVALID. THE FOREGOING LIMITATIONS APPLY EVEN IF THE ABOVE-STATED REMEDIES FAIL OF THEIR ESSENTIAL PURPOSE.

- 4 U.S.A. STATE LAWS.** This Software Limited Warranty gives you specific legal rights. You may also have other rights that vary from state to state. Some states do not allow limitations on how long an implied warranty lasts or the exclusion of limitation of incidental or consequential damages, so the above limitations may not apply to you.
- 5 LICENSE GRANT.** Lexmark grants you the following rights provided you comply with all terms and conditions of this Software License Agreement:
- a Use.** You may Use one (1) copy of the Software Program. The term “Use” means storing, loading, installing, executing, or displaying the Software Program. If Lexmark has licensed the Software Program to you for concurrent use, you must limit the number of authorized users to the number specified in your agreement with Lexmark. You may not separate the components of the Software Program for use on more than one computer. You agree that you will not Use the Software Program, in whole or in part, in any manner that has the effect of overriding, modifying, eliminating, obscuring, altering or de-emphasizing the visual appearance of any trademark, trade name, trade dress or intellectual property notice that appears on any computer display screens normally generated by, or as a result of, the Software Program.
 - b Copying.** You may make one (1) copy of the Software Program solely for purposes of backup, archiving, or installation, provided the copy contains all of the original Software Program’s proprietary notices. You may not copy the Software Program to any public or distributed network.
 - c Reservation of Rights.** The Software Program, including all fonts, is copyrighted and owned by Lexmark International, Inc. and/or its suppliers. Lexmark reserves all rights not expressly granted to you in this Software License Agreement.
 - d Freeware.** Notwithstanding the terms and conditions of this Software License Agreement, all or any portion of the Software Program that constitutes software provided under public license by third parties (“Freeware”) is licensed to you subject to the terms and conditions of the software license agreement accompanying such Freeware, whether in the form of a discrete agreement, shrink-wrap license, or electronic license terms at the time of download or installation. Use of the Freeware by you shall be governed entirely by the terms and conditions of such license.
- 6 TRANSFER.** You may transfer the Software Program to another end-user. Any transfer must include all software components, media, printed materials, and this Software License Agreement and you may not retain copies of the Software Program or components thereof. The transfer may not be an indirect transfer, such as a consignment. Prior to the transfer, the end-user receiving the transferred Software Program must agree to all these Software License Agreement terms. Upon transfer of the Software Program, your license is automatically terminated. You may not rent, sublicense, or assign the Software Program except to the extent provided in this Software License Agreement.
- 7 UPGRADES.** To Use a Software Program identified as an upgrade, you must first be licensed to the original Software Program identified by Lexmark as eligible for the upgrade. After upgrading, you may no longer use the original Software Program that formed the basis for your upgrade eligibility.
- 8 LIMITATION ON REVERSE ENGINEERING.** You may not alter, decrypt, reverse engineer, reverse assemble, reverse compile or otherwise translate the Software Program or assist or otherwise facilitate others to do so, except as and to the extent expressly permitted to do so by applicable law for the purposes of inter-operability, error correction, and security testing. If you have such statutory rights, you will notify Lexmark in writing of any intended reverse

engineering, reverse assembly, or reverse compilation. You may not decrypt the Software Program unless necessary for the legitimate Use of the Software Program.

- 9 ADDITIONAL SOFTWARE.** This Software License Agreement applies to updates or supplements to the original Software Program provided by Lexmark unless Lexmark provides other terms along with the update or supplement.
- 10 TERM.** This Software License Agreement is effective unless terminated or rejected. You may reject or terminate this license at any time by destroying all copies of the Software Program, together with all modifications, documentation, and merged portions in any form, or as otherwise described herein. Lexmark may terminate your license upon notice if you fail to comply with any of the terms of this Software License Agreement. Upon such termination, you agree to destroy all copies of the Software Program together with all modifications, documentation, and merged portions in any form.
- 11 TAXES.** You agree that you are responsible for payment of any taxes including, without limitation, any goods and services and personal property taxes, resulting from this Software License Agreement or your Use of the Software Program.
- 12 LIMITATION ON ACTIONS.** No action, regardless of form, arising out of this Software License Agreement may be brought by either party more than two years after the cause of action has arisen, except as provided under applicable law.
- 13 APPLICABLE LAW.** This Software License Agreement is governed by the laws of the Commonwealth of Kentucky, United States of America. No choice of law rules in any jurisdiction shall apply. The UN Convention on Contracts for the International Sale of Goods shall not apply.
- 14 UNITED STATES GOVERNMENT RESTRICTED RIGHTS.** The Software Program has been developed entirely at private expense. Rights of the United States Government to use the Software Program are as set forth in this Software License Agreement and as restricted in DFARS 252.227-7014 and in similar FAR provisions (or any equivalent agency regulation or contract clause).
- 15 CONSENT TO USE OF DATA.** You agree that Lexmark, its affiliates, and agents may collect and use information you provide in relation to support services performed with respect to the Software Program and requested by you. Lexmark agrees not to use this information in a form that personally identifies you except to the extent necessary to provide such services.
- 16 EXPORT RESTRICTIONS.** You may not (a) acquire, ship, transfer, or reexport, directly or indirectly, the Software Program or any direct product therefrom, in violation of any applicable export laws or (b) permit the Software Program to be used for any purpose prohibited by such export laws, including, without limitation, nuclear, chemical, or biological weapons proliferation.
- 17 AGREEMENT TO CONTRACT ELECTRONICALLY.** You and Lexmark agree to form this Software License Agreement electronically. This means that when you click the “Agree” or “I accept” button on this page or use this product, you acknowledge your agreement to these Software License Agreement terms and conditions and that you are doing so with the intent to “sign” a contract with Lexmark.
- 18 CAPACITY AND AUTHORITY TO CONTRACT.** You represent that you are of the legal age of majority in the place you sign this Software License Agreement and, if applicable, you are duly authorized by your employer or principal to enter into this contract.
- 19 ENTIRE AGREEMENT.** This Software License Agreement (including any addendum or amendment to this Software License Agreement that is included with the Software Program) is the entire agreement between you and Lexmark relating to the Software Program. Except as otherwise provided for herein, these terms and conditions supersede all prior or contemporaneous oral or written communications, proposals, and representations with respect to the Software Program or any other subject matter covered by this Software License Agreement (except to the extent such extraneous terms do not conflict with the terms of this Software License Agreement, any other written agreement signed by you and Lexmark relating to your Use of the Software Program). To the extent any Lexmark policies or programs for support services conflict with the terms of this Software License Agreement, the terms of this Software License Agreement shall control.

European Community (EC) directives conformity

This product is in conformity with the protection requirements of EC Council directives 2004/108/EC and 2006/95/EC on the approximation and harmonization of the laws of the Member States relating to electromagnetic compatibility and safety of electrical equipment designed for use within certain voltage limits.

The manufacturer of this product is: Lexmark International, Inc., 740 West New Circle Road, Lexington, KY, 40550 USA. The authorized representative is: Lexmark International Technology Hungária Kft., 8 Lechner Ödön fasor, Millennium Tower III, 1095 Budapest HUNGARY, A declaration of conformity to the requirements of the Directives is available upon request from the Authorized Representative.

This product satisfies the Class B limits of EN 55022 and safety requirements of EN 60950.

Industry Canada compliance statement

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Standard ICES-003.

Avis de conformité aux normes de l'industrie du Canada

Cet appareil numérique de classe B est conforme aux exigences de la norme canadienne relative aux équipements pouvant causer des interférences NMB-003.

Regulatory notices for telecommunication terminal equipment

This section contains regulatory information pertaining to products that contain telecommunication terminal equipment such as facsimile.

Notice to users of the US telephone network: FCC requirements

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the Administrative Council for Terminal Attachments (ACTA). On the back of this equipment is a label that contains, among other information, a product identifier in the format US:AAAEQ##TXXXX. If requested, this number must be provided to your telephone company.

This equipment uses the RJ-11C Universal Service Order Code (USOC) jack.

A plug and jack used to connect this equipment to the premises' wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See your setup documentation for more information.

The Ringer Equivalence Number (REN) is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact your local telephone company. For products approved after July 23, 2001, the REN for this product is part of the product identifier that has the format US:AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point (for example, 03 is a REN of 0.3). For earlier products, the REN is shown separately on the label.

If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. If advance notice is not practical, the telephone company will notify the customer as soon as possible. You will also be advised of your right to file a complaint with the FCC.

The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of this equipment. If this happens, the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

If you experience trouble with this equipment, for repair or warranty information, contact Lexmark International, Inc. at www.lexmark.com or your Lexmark representative. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

This equipment contains no user serviceable parts. For repair and warranty information, contact Lexmark International, Inc. See the previous paragraph for contact information.

Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission, or corporation commission for information.

If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this equipment does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

Telephone companies report that electrical surges, typically lightning transients, are very destructive to customer terminal equipment connected to AC power sources. This has been identified as a major nationwide problem. It is recommended that the customer install an appropriate AC surge arrester in the AC outlet to which this device is connected. An appropriate AC surge arrester is defined as one that is suitably rated, and certified by UL (Underwriter's Laboratories), another NRTL (Nationally Recognized Testing Laboratory), or a recognized safety certification body in the country/region of use. This is to avoid damage to the equipment caused by local lightning strikes and other electrical surges.

The Telephone Consumer Protection Act of 1991 makes it unlawful for any person to use a computer or other electronic device, including fax machines, to send any message unless said message clearly contains in a margin at the top or bottom of each transmitted page or on the first page of the transmission, the date and time it is sent and an identification of the business or other entity, or other individual sending the message, and the telephone number of the sending machine or such business, other entity, or individual. (The telephone number provided may not be a 900 number or any other number for which charges exceed local or long-distance transmission charges.)

See your user documentation in order to program this information into your fax machine.

South Africa telecommunications notice

This modem must be used in conjunction with an approved surge protection device when connected to the PSTN.

Notice to users of the Canadian telephone network

This product meets the applicable Industry Canada technical specifications. The Ringer Equivalence Number (REN) is an indication of the maximum number of terminals allowed to be connected to a telephone interface. The terminus of an interface may consist of any combination of devices, subject only to the requirement that the sum of the RENs of all the devices does not exceed five. The modem REN is located on the rear of the equipment on the product labeling.

Telephone companies report that electrical surges, typically lightning transients, are very destructive to customer terminal equipment connected to AC power sources. This has been identified as a major nationwide problem. It is recommended that the customer install an appropriate AC surge arrester in the AC outlet to which this device is connected. An appropriate AC surge arrester is defined as one that is suitably rated, and certified by UL (Underwriter's Laboratories), another NRTL (Nationally Recognized Testing Laboratory), or a recognized safety certification body in

the country/region of use. This is to avoid damage to the equipment caused by local lightning strikes and other electrical surges.

This equipment uses CA11A telephone jacks.

Avis réservé aux utilisateurs du réseau téléphonique du Canada

Ce produit est conforme aux spécifications techniques d'Industrie Canada. Le numéro REN (ringer equivalence number : numéro d'équivalence de sonnerie) fournit une indication du nombre maximum de terminaux pouvant être connectés à l'interface téléphonique. En bout de ligne, le nombre d'appareils qui peuvent être connectés n'est pas directement limité, mais la somme des REN de ces appareils ne doit pas dépasser cinq. Le numéro REN du modem est indiqué sur l'étiquette produit située à l'arrière de l'équipement.

Les compagnies de téléphone constatent que les surtensions électriques, en particulier celles dues à la foudre, entraînent d'importants dégâts sur les terminaux privés connectés à des sources d'alimentation CA. Il s'agit-là d'un problème majeur d'échelle nationale. En conséquence, il vous est recommandé de brancher un parasurtenseur dans la prise de courant à laquelle l'équipement est connecté. Utilisez un parasurtenseur répondant à des caractéristiques nominales satisfaisantes et certifié par le laboratoire d'assureurs UL (Underwriter's Laboratories), un autre laboratoire agréé de type NRTL (Nationally Recognized Testing Laboratory) ou un organisme de certification agréé dans votre région ou pays. Ceci prévient tout endommagement de l'équipement causé par les orages et autres surtensions électriques.

Cet équipement utilise des prises de téléphone CA11A.

Notice to users of the New Zealand telephone network

The following are special conditions for the Facsimile User Instructions. The grant of a telepermit for any item of terminal equipment indicates only that Telecom has accepted that the item complies with minimum conditions for connection to its network. It indicates no endorsement of the product by Telecom, nor does it provide any sort of warranty. Above all, it provides no assurance that any item will work correctly in all respects with another item of telepermitted equipment of a different make or model, nor does it imply that any product is compatible with all of Telecom's network services.

This equipment shall not be set up to make automatic calls to the Telecom's 111 Emergency Service.

This equipment may not provide for the effective hand-over of a call to another device connected to the same line.

This equipment should not be used under any circumstances that may constitute a nuisance to other Telecom customers.

Some parameters required for compliance with Telecom's telepermit requirements are dependent on the equipment associated with this device. The associated equipment shall be set to operate within the following limits for compliance to Telecom's specifications:

- There shall be no more than 10 call attempts to the same number within any 30 minute period for any single manual call initiation, and
- The equipment shall go on-hook for a period of not less than 30 seconds between the end of one attempt and the beginning of the next call attempt.
- The equipment shall be set to ensure that automatic calls to different numbers are spaced such that there is not less than 5 seconds between the end of one call attempt and the beginning of another.

Using this product in Switzerland

This product requires a Swiss billing tone filter (Lexmark part number 14B5109 or 80D1877) to be installed on any line which receives metering pulses in Switzerland. The Lexmark filter must be used, as metering pulses are present on all analog telephone lines in Switzerland.

Utilisation de ce produit en Suisse

Cet appareil nécessite l'utilisation d'un filtre de tonalité de facturation suisse (n° de référence Lexmark : 14B5109 ou 80D1877) devant être installé sur toute ligne recevant des impulsions de comptage en Suisse. Ce filtre doit être utilisé pour toute installation car ces impulsions existent sur toutes les lignes téléphoniques suisses.

Verwendung dieses Produkts in der Schweiz

Für dieses Produkt muss ein schweizerischer Billing Tone Filter zur Zählzeichenübertragung (Lexmark Teilenummer 14B5109 oder 80D1877) für jede Leitung installiert werden, über die in der Schweiz Zeitsteuertakte übertragen werden. Die Verwendung des Lexmark Filters ist obligatorisch, da in allen analogen Telefonleitungen in der Schweiz Zeitsteuertakte vorhanden sind.

Uso del prodotto in Svizzera

Questo prodotto richiede un filtro toni Billing svizzero, (codice Lexmark 14B5109 o 80D1877) da installare su tutte le linee che ricevono impulsi remoti in Svizzera. È necessario utilizzare il filtro Lexmark poiché gli impulsi remoti sono presenti su tutte le linee analogiche in Svizzera.

Notice to Users in the European Union

Products bearing the CE mark are in conformity with the protection requirements of EC Council directives 2004/108/EC, 2006/95/EC, and 1999/5/EC on the approximation and harmonization of the laws of the Member States relating to electromagnetic compatibility, safety of electrical equipment designed for use within certain voltage limits and on radio equipment and telecommunications terminal equipment.

Compliance is indicated by the CE marking.



The manufacturer of this product is: Lexmark International, Inc., 740 West New Circle Road, Lexington, KY, 40550 USA. The authorized representative is: Lexmark International Technology Hungária Kft., 8 Lechner Ödön fasor, Millennium Tower III, 1095 Budapest HUNGARY, A declaration of conformity to the requirements of the Directives is available upon request from the Authorized Representative.

Refer to the table at the end of the Notices section for further compliance information.

Regulatory notices for wireless products

This section contains the following regulatory information pertaining to wireless products.

Exposure to radio frequency radiation

The following notice is applicable if your printer has a wireless network card installed: The radiated output power of this device is far below the radio frequency exposure limits of the FCC and other regulatory agencies. A minimum

separation of 20 cm (8 inches) must be maintained between the antenna and any persons for this device to satisfy the RF exposure requirements of the FCC and other regulatory agencies.

Notice to users in Brazil

Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário. (Res. ANATEL 282/2001).

Industry Canada (Canada)

This device complies with Industry Canada specification RSS-210. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This device has been designed to operate only with the antenna provided. Use of any other antenna is strictly prohibited per regulations of Industry Canada.

To prevent radio interference to the licensed service, this device is intended to be operated indoors and away from windows to provide maximum shielding. Equipment (or its transmit antenna) that is installed outdoors is subject to licensing.

The installer of this radio equipment must ensure that the antenna is located or pointed such that it does not emit RF fields in excess of Health Canada limits for the general population; consult Safety Code 6, obtainable from Health Canada's Web site www.hc-sc.gc.ca/rpb.

The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were met.

Industry Canada (Canada)

Cet appareil est conforme à la norme RSS-210 d'Industry Canada. Son fonctionnement est soumis aux deux conditions suivantes :

(1) cet appareil ne doit pas provoquer d'interférences et (2) il doit accepter toute interférence reçue, y compris celles risquant d'altérer son fonctionnement.

Cet appareil a été conçu pour fonctionner uniquement avec l'antenne fournie. L'utilisation de toute autre antenne est strictement interdite par la réglementation d'Industry Canada.

En application des réglementations d'Industry Canada, l'utilisation d'une antenne de gain supérieur est strictement interdite.

Pour empêcher toute interférence radio au service faisant l'objet d'une licence, cet appareil doit être utilisé à l'intérieur et loin des fenêtres afin de garantir une protection optimale.

Si le matériel (ou son antenne d'émission) est installé à l'extérieur, il doit faire l'objet d'une licence.

L'installateur de cet équipement radio doit veiller à ce que l'antenne soit implantée et dirigée de manière à n'émettre aucun champ HF dépassant les limites fixées pour l'ensemble de la population par Santé Canada. Reportez-vous au Code de sécurité 6 que vous pouvez consulter sur le site Web de Santé Canada www.hc-sc.gc.ca/rpb.

Le terme « IC » précédant le numéro de d'accréditation/inscription signifie simplement que le produit est conforme aux spécifications techniques d'Industry Canada.

Taiwan NCC RF notice statement

NCC型式認證設備注意事項 台灣低功率射頻電機設備之使用注意事項

經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前項合法通信，指依電信規定作業之無線電信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

Notice to users in the European Union

Products bearing the CE mark are in conformity with the protection requirements of EC Council directives 2004/108/EC, 2006/95/EC, and 1999/5/EC on the approximation and harmonization of the laws of the Member States relating to electromagnetic compatibility, safety of electrical equipment designed for use within certain voltage limits and on radio equipment and telecommunications terminal equipment.

Compliance is indicated by the CE marking.



The manufacturer of this product is: Lexmark International, Inc., 740 West New Circle Road, Lexington, KY, 40550 USA. The authorized representative is: Lexmark International Technology Hungária Kft., 8 Lechner Ödön fasor, Millennium Tower III, 1095 Budapest HUNGARY, A declaration of conformity to the requirements of the Directives is available upon request from the Authorized Representative.

Products equipped with 2.4GHz Wireless LAN option are in conformity with the protection requirements of EC Council directives 2004/108/EC, 2006/95/EC, and 1999/5/EC on the approximation and harmonization of the laws of the Member States relating to electromagnetic compatibility, safety of electrical equipment designed for use within certain voltage limits and on radio equipment and telecommunications terminal equipment.

Compliance is indicated by the CE marking.



Operation is allowed in all EU and EFTA countries, but is restricted to indoor use only.

The manufacturer of this product is: Lexmark International, Inc., 740 West New Circle Road, Lexington, KY, 40550 USA. The authorized representative is: Lexmark International Technology Hungária Kft., 8 Lechner Ödön fasor, Millennium Tower III, 1095 Budapest HUNGARY, A declaration of conformity to the requirements of the Directives is available upon request from the Authorized Representative.

| | |
|-------|--|
| Česky | Společnost Lexmark International, Inc. tímto prohlašuje, že výrobek tento výrobek je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES. |
| Dansk | Lexmark International, Inc. erklærer herved, at dette produkt overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF. |

| | |
|------------|--|
| Deutsch | Hiermit erklärt Lexmark International, Inc., dass sich das Gerät dieses Gerät in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet. |
| Ελληνική | ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Η LEXMARK INTERNATIONAL, INC. ΔΗΛΩΝΕΙ ΟΤΙ ΑΥΤΟ ΤΟ ΠΡΟΪΟΝ ΣΥΜΜΟΡΦΟΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ. |
| English | Hereby, Lexmark International, Inc., declares that this type of equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. |
| Español | Por medio de la presente, Lexmark International, Inc. declara que este producto cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE. |
| Eesti | Käesolevaga kinnitab Lexmark International, Inc., et seade see toode vastab direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele muudele asjakohastele sätetele. |
| Suomi | Lexmark International, Inc. vakuuttaa täten, että tämä tuote on direktiivin 1999/5/EY oleellisten vaatimusten ja muiden sitä koskevien direktiivin ehtojen mukainen. |
| Français | Par la présente, Lexmark International, Inc. déclare que l'appareil ce produit est conforme aux exigences fondamentales et autres dispositions pertinentes de la directive 1999/5/CE. |
| Magyar | Alulírott, Lexmark International, Inc. nyilatkozom, hogy a termék megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak. |
| Íslenska | Hér með lýsir Lexmark International, Inc. yfir því að þessi vara er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC. |
| Italiano | Con la presente Lexmark International, Inc. dichiara che questo questo prodotto è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE. |
| Latviski | Ar šo Lexmark International, Inc. deklarē, ka šis izstrādājums atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem. |
| Lietuvių | Šiuo Lexmark International, Inc. deklaruoja, kad šis produktas atitinka esminius reikalavimus ir kitas 1999/5/EB direktyvos nuostatas. |
| Malti | Bil-preżenti, Lexmark International, Inc., jiddikjara li dan il-prodott huwa konformi mal-ftiġġijiet essenzjali u ma dispożizzjonijiet oħrajn relevanti li jinsabu fid-Direttiva 1999/5/KE. |
| Nederlands | Hierbij verklaart Lexmark International, Inc. dat het toestel dit product in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG. |
| Norsk | Lexmark International, Inc. erklærer herved at dette produktet er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF. |
| Polski | Niniejszym Lexmark International, Inc. oświadcza, że niniejszy produkt jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC. |
| Português | A Lexmark International Inc. declara que este este produto está conforme com os requisitos essenciais e outras disposições da Diretiva 1999/5/CE. |
| Slovensky | Lexmark International, Inc. týmto vyhlasuje, že tento produkt spĺňa základné požiadavky a všetky príslušné ustanovenia smernice 1999/5/ES. |
| Slovensko | Lexmark International, Inc. izjavlja, da je ta izdelek v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES. |
| Svenska | Härmed intygar Lexmark International, Inc. att denna produkt står i överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG. |

Index

Numerics

- 30 Invalid refill, change toner cartridge 131
- 31.yy Replace defective or missing cartridge 131
- 32 Replace unsupported cartridge 131
- 34 Short paper 131
- 37 Insufficient memory to collate job 131
- 38 Memory full 131
- 39 Complex page, some data may not have printed 132
- 54 Network <x> software error 132
- 54 Standard network software error 132
- 56 Standard USB port disabled 132
- 84 PC Kit life warning 132
- 84 Replace PC Kit 132
- 840.01 Scanner Disabled 135
- 840.02 Scanner Auto Disabled 135
- 88.yy Cartridge is low 132

Symbols

- “scan to computer” screen options 83

A

- address book, e-mail setting up 58
- address book, fax using 77
- ADF copying using 49
- ADF separator rollers, cleaning 116
- attaching cables 21
- Automatic Document Feeder (ADF) 16

B

- buttons, printer control panel 17

C

- cables
 - Ethernet 21
 - USB 21
- calling Customer Support 163

- canceling a job
 - from Macintosh 47
 - from Windows 47
- canceling print jobs
 - from printer control panel 47
- card stock tips 46
- Cartridge Low 130
- checking an unresponsive printer 129
- checking an unresponsive scanner 147
- checking device status
 - on Embedded Web Server 128
- cleaning
 - ADF separator rollers 116
 - exterior of the printer 114
 - scanner glass 115
- Close front door 130
- collating copies 55
- configurations
 - printer 13
- connecting the printer to
 - answering machine 66
 - computer modem 72
 - regional adapters 68
 - telephone 66
- conservation settings
 - Eco-Mode 26
 - Power Saver 27
 - Quiet Mode 28
- conserving supplies 25
- contacting Customer Support 163
- control panel, printer 17
- copy quality
 - adjusting 54
 - improving 56
- Copy Settings menu 96
- copy troubleshooting
 - copier does not respond 145
 - poor copy quality 146
 - poor scanned image quality 148
 - scanner unit does not close 145
- copying
 - adjusting quality 54
 - canceling a copy job 56
 - collating copies 55
 - enlarging 53

- from one size to another 53
- improving copy quality 56
- making a copy lighter or darker 54
- multiple pages on one sheet 55
- on both sides of the paper (duplexing) 50
- pausing a print job to make copies 56
- photos 51
- quick copy 49
- reducing 53
- to letterhead 52
- to transparencies 52
- using the ADF 49
- using the scanner glass 50
- Custom Scan Sizes menu 91
- Custom Types menu 90

D

- date and time setting 73
- Default Source menu 86
- display troubleshooting
 - display is blank 129
 - display shows only diamonds 129
- display, printer control panel 17
- distinctive ring service
 - connecting to 65
- documents, printing
 - from Macintosh 43
 - from Windows 43
- duplexing
 - copy jobs 50
 - print jobs 43

E

- Eco-Mode setting 26
- Embedded Web Server 127
 - administrator settings 127
 - checking device status 128
 - does not open 163
 - networking settings 127
 - setting up e-mail alerts 128
- Embedded Web Server Administrator's Guide 127
- emission notices 165, 166, 174, 177, 178
- enlarging a copy 53

- envelopes
 - loading 35
 - tips 45
- environmental settings
 - Eco-Mode 26
 - Power Saver 27
 - Quiet Mode 28
- Ethernet networking
 - Macintosh 23
 - Windows 23
- Ethernet port 21
- exterior of the printer
 - cleaning 114
- e-mail
 - canceling 61
 - notice of low supply level 128
 - notice of paper jam 128
 - notice of paper needed 128
 - notice that different paper is needed 128
- e-mail function
 - setting up 58
- e-mailing
 - creating shortcuts using the Embedded Web Server 59
 - setting up address book 58
 - setting up e-mail function 58
 - using shortcut numbers 60
 - using the address book 61
 - using the keypad 59

F

- factory defaults, restoring 128
- fax
 - canceling 79
 - options 80
- fax connection
 - connecting the printer to the wall jack 64
 - connecting to a distinctive ring service 65
 - connecting to a DSL line 64
 - connecting to a PBX or ISDN 65
- fax connections
 - answering machine 66
 - computer modem 72
 - regional adapters 68
 - telephone 66
- fax quality, improving 80
- fax screen
 - options 79
- Fax Settings menu 98

- fax troubleshooting
 - blocking junk faxes 78
 - caller ID is not shown 149
 - can receive but not send faxes 151
 - can send but not receive faxes 151
 - cannot send or receive a fax 149
 - received fax has poor print quality 152
- faxing
 - changing resolution 78
 - choosing a fax connection 63
 - creating shortcuts using the Embedded Web Server 76
 - creating shortcuts using the printer control panel 76
 - fax setup 62
 - forwarding faxes 80
 - improving fax quality 80
 - making a fax lighter or darker 78
 - sending a fax at a scheduled time 75
 - sending using the computer 74
 - sending using the printer control panel 74
 - setting the date and time 73
 - setting the outgoing fax name and number 73
 - using shortcuts 77
 - using the address book 77
 - viewing a fax log 79
- FCC notices 165, 174, 177
- features
 - Scan Center 85
- finding
 - information 11
 - publications 11
 - Web site 11
- Finishing menu 103
- font sample list
 - printing 47
- forwarding faxes 80

G

- green settings
 - Eco-Mode 26
 - Power Saver 27
 - Quiet Mode 28

I

- information, finding 11
- installing
 - printer software 21
- Invalid Engine Code 130
- IPv6 menu 109

J

- jams
 - avoiding 136
- jams, avoiding
 - cutting paper and specialty media 39
 - selecting paper and specialty media 39
- jams, clearing
 - 200–201 137
 - 202 139
 - 241 141
 - 251 142
 - 290–294 133

L

- labels, paper
 - tips 46
- letterhead
 - copying to 52
 - loading 35
 - tips 44
- light, indicator 17
- Load <src> with <x> 130
- loading
 - envelopes 35
 - letterhead 35
 - manual feeder 35
 - paper tray 32

M

- manual feeder
 - loading 35
- menu settings page
 - printing 22
- menus
 - Copy Settings 96
 - Custom Scan Sizes 91
 - Custom Types 90
 - Default Source 86
 - diagram of 86
 - Fax Settings 98
 - Finishing 103

- IPv6 109
- Network <x> 106
- Network Card 108
- Network Reports 107
- Paper Texture 89
- Paper Weight 90
- PCL Emul 105
- PostScript 105
- Quality 104
- Reports 93
- Set Date and Time 111
- Settings 94
- Setup 102
- Size/Type 87
- Standard Network 106
- Standard USB 110
- TCP/IP 108
- Universal Setup 92
- moving the printer 125
- multiple pages on one sheet 55

N

- Network 130
- Network <x> 130
- Network <x> menu 106
- Network Card menu 108
- Network Reports menu 107
- network setup page 22
- Networking Guide 127
- noise emission levels 166
- notices 165, 166, 167, 168, 174, 175, 176, 177, 178, 179

O

- options
 - fax 79, 80
 - scan to computer 79
- ordering
 - toner cartridges 119

P

- paper
 - capacities 37
 - characteristics 38
 - letterhead 39
 - preprinted forms 39
 - recommended print side 39
 - recycled 25, 40
 - selecting 39
 - setting size 30
 - setting type 30

- storing 40
- unacceptable 39
- Universal Paper Size 92
- Universal size setting 30
- paper feed troubleshooting
 - message remains after jam is cleared 153
- paper jams
 - avoiding 136
- paper jams, clearing
 - 200–201 137
 - 202 139
 - 241 141
 - 251 142
 - 290–294 133
- paper sizes
 - supported by the printer 41
- Paper Texture menu 89
- paper tray
 - loading 32
- paper types
 - supported by printer 41
 - where to load 41
- Paper Weight menu 90
- partial document or photo prints, copies, or scans 129
- pausing the current print job
 - to make copies 56
- PCL Emul menu 105
- photoconductor kit
 - ordering 119
 - replacing 122
- photos
 - copying 51
- PostScript menu 105
- Power Saver
 - adjusting 27
- print job
 - canceling from Macintosh 47
 - canceling from printer control panel 47
 - canceling from Windows 47
- print quality
 - cleaning the scanner glass 115
- print quality troubleshooting
 - blank pages 154
 - characters have jagged edges 154
 - clipped images 155
 - ghost images 155
 - gray background 155
 - poor transparency quality 163
 - print is too dark 157

- print is too light 158
- print quality test pages 153
- skewed print 159
- solid black streaks 159
- solid white streaks 159
- streaked horizontal lines 160
- streaked vertical lines 161
- toner fog or background shading 161
- toner rubs off 162
- toner specks 162
- print quality, poor
 - avoiding by selecting paper and specialty media 39
- print troubleshooting
 - incorrect characters print 144
 - incorrect margins 156
 - job takes longer than expected 144
 - jobs do not print 143
 - Large jobs do not collate 145
 - multiple-language PDFs do not print 144
 - paper curl 157
 - paper frequently jams 153
 - unexpected page breaks occur 145
- printer
 - basic model 13
 - configurations 13
 - minimum clearances 12
 - moving 125
 - selecting a location 12
 - shipping 126
- printer control panel
 - factory defaults, restoring 128
- printer messages
 - 200–250 paper jam 133
 - 30 Invalid refill, change toner cartridge 131
 - 31.yy Replace defective or missing cartridge 131
 - 32 Replace unsupported cartridge 131
 - 34 Short paper 131
 - 37 Insufficient memory to collate job 131
 - 38 Memory full 131
 - 39 Complex page, some data may not have printed 132
 - 54 Network <x> software error 132

- 54 Standard network software error 132
- 56 Standard USB port disabled 132
- 84 PC Kit life warning 132
- 84 Replace PC Kit 132
- 840.01 Scanner Disabled 135
- 840.02 Scanner Auto Disabled 135
- 88.yy Cartridge is low 132
- Cartridge Low 130
- Close front door 130
- Invalid Engine Code 130
- Load <src> with <x> 130
- Network 130
- Network <x> 130
- Programming Engine Code 130
- Programming System Code 130
- Waiting 131
- printer problems, unresponsive printer 129
- printing
 - font sample list 47
 - from Macintosh 43
 - from Windows 43
 - installing printer software 21
 - menu settings page 22
 - network setup page 22
 - on both sides of the paper (duplexing) 43
- Programming Engine Code 130
- Programming System Code 130
- publications, finding 11

Q

- Quality menu 104
- Quiet Mode 28

R

- recommended print side 39
- recycled paper using 40
- recycling
 - Lexmark packaging 27
 - Lexmark products 27
 - toner cartridges 28
 - WEEE statement 166
- reducing a copy 53
- reducing noise 28
- replacing
 - photoconductor kit 122

- toner cartridge 120
- reports
 - viewing 127
- Reports menu 93
- resolution, fax changing 78

S

- safety information 9, 10
- Scan Center features 85
- scan quality, improving 84
- scan to computer
 - options 79
- scan troubleshooting
 - cannot create a Scan Profile 149
 - cannot scan from a computer 148
 - scan was not successful 147
 - scanner unit does not close 145
 - scanning takes too long or freezes the computer 148
- scanner
 - Automatic Document Feeder (ADF) 16
 - functions 15
 - scanner glass 16
- scanner glass
 - cleaning 115
 - copying using 50
- scanning to a computer 82
 - improving scan quality 84
- Set Date and Time menu 111
- setting
 - paper size 30
 - paper type 30
 - TCP/IP address 108
 - Universal Paper Size 30
- setting up the printer
 - on a wired network (Macintosh) 23
 - on a wired network (Windows) 23
- Settings menu 94
- Setup menu 102
- shipping the printer 126
- shortcuts, creating
 - e-mail 59
 - fax destination 76
- Size/Type menu 87
- specialty media
 - recommended print side 39
 - selecting 39
- Standard Network menu 106
- Standard USB menu 110

- status of supplies, checking 118
- storing
 - paper 40
 - supplies 118
- supplies
 - conserving 25
 - status of 118
 - storing 118
 - using recycled paper 25
- supplies, ordering
 - photoconductor kit 119
 - toner cartridges 119

T

- TCP/IP menu 108
- telecommunication notices 174, 175, 176
- tips
 - card stock 46
 - envelopes 45
 - labels, paper 46
 - letterhead 44
 - transparencies 44
- toner cartridge
 - replacing 120
- toner cartridges
 - ordering 119
 - recycling 28
- transparencies
 - copying to 52
 - tips 44
- troubleshooting
 - checking an unresponsive printer 129
 - checking an unresponsive scanner 147
 - contacting Customer Support 163
 - partial document or photo prints, copies, or scans 129
- troubleshooting, copy
 - copier does not respond 145
 - poor copy quality 146
 - poor scanned image quality 148
 - scanner unit does not close 145
- troubleshooting, display
 - display is blank 129
 - display shows only diamonds 129
- troubleshooting, fax
 - blocking junk faxes 78
 - caller ID is not shown 149
 - can receive but not send faxes 151

- can send but not receive
 - faxes 151
- cannot send or receive a fax 149
- received fax has poor print quality 152
- troubleshooting, paper feed
 - message remains after jam is cleared 153
- troubleshooting, print
 - incorrect characters print 144
 - incorrect margins 156
 - job takes longer than expected 144
 - jobs do not print 143
 - Large jobs do not collate 145
 - multiple-language PDFs do not print 144
 - paper curl 157
 - paper frequently jams 153
 - unexpected page breaks occur 145
- troubleshooting, print quality
 - blank pages 154
 - characters have jagged edges 154
 - clipped images 155
 - ghost images 155
 - gray background 155
 - poor transparency quality 163
 - print is too dark 157
 - print is too light 158
 - print quality test pages 153
 - skewed print 159
 - solid black streaks 159
 - solid white streaks 159
 - streaked horizontal lines 160
 - streaked vertical lines 161
 - toner fog or background shading 161
 - toner rubs off 162
 - toner specks 162
- troubleshooting, scan
 - cannot create a Scan Profile 149
 - cannot scan from a computer 148
 - scan was not successful 147
 - scanner unit does not close 145
 - scanning takes too long or freezes the computer 148

U

- Universal Paper Size 92
 - setting 30
- Universal Setup menu 92

- USB port 21

V

- viewing
 - reports 127

W

- Waiting 131
- Web site
 - finding 11
- wired network setup
 - using Windows 23
- wired networking
 - using Macintosh 23