**Basic printing** 

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index


Using this Guide...



**Z54** 

**Color Jetprinter**<sup>™</sup>

Online User's Guide for Mac OS X 10.0.3 to 10.1





**Basic printing** 

## Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

#### Navigating

- Click the categories in the left pane to navigate the pages.
- Click the blue text to link to other parts of this Online User's Guide.
- Click the arrows at the bottom of the screen to move forward and backward through the pages.

#### Searching

- 1 From the Acrobat Edit menu, choose Find.
- 2 In the Find What: box, type the word or phrase you want to search for.
- 3 Click Find.

#### **Printing**

- 1 From the Acrobat File menu, choose Page Setup.
- **2** From the Format for pop-up menu, choose Lexmark Z54, select the Landscape orientation button, and then click OK.
- 3 From the Acrobat File menu, choose Print.
- **4** From the Printer pop-up menu, choose Lexmark Z54, specify the pages you want to print, and then click Print.



- Printer overview
- Basic printing
- Printing ideas
- Maintenance
- Troubleshooting
- Notices
- Index

- Understanding the printer software
- Understanding the printer parts





Basic printing

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

**Using this** Guide...

# Understanding the printer software

Your printer software includes the:

- Page Setup dialog
- **Print dialog**
- **Lexmark Z54 Utility**

To customize the settings for your document, use the Page Setup dialog and the Print dialog. For more information on which settings to select for your document, see **Printing** ideas. When you installed the printer software, the Page Setup and Print dialogs were set to these default settings:

Print Quality: Normal

Paper Type: Plain

Paper Size: A4 or U.S. Letter

Orientation: Portrait



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 


Index

Using this Guide...

## Page Setup dialog

While the document you want to print is open, use the Page Setup dialog to select settings such as paper size. To customize the settings in the Page Setup dialog:

1 From the File menu of your software application, choose Page Setup.





**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

**2** Change the settings as needed.

From this pop- up menu:	Select:	When you want to:	
Format for	Lexmark Z54	Format your page for printing with your Lexmark Z54 printer.	
Settings	Page Attributes	Choose a paper size, orientation, or scaling value for your document.	
	Summary	View a summary of the current page settings.	

For more information about these settings, click ? to view the OS X software Help.

3 Click OK to apply the settings and close the Page Setup dialog.

## **Print dialog**

While your document is open, you can use the Print dialog to select settings that affect the appearance of your document. To customize the settings in the Print dialog:



**Basic printing** 

Printing ideas

Maintenance


Troubleshooting

**Notices** 

Index

Using this Guide...

**1** From the software application File menu, choose Print.





- Printer overview
- **Basic printing**
- Printing ideas
- Maintenance
- Troubleshooting
- **Notices**
- Index

- **2** From the Printer pop-up menu, choose Lexmark Z54.
- **3** Change the settings as needed.

From the pop-up menu, choose:	Select:	When you want to:	
Copies &	Copies	Specify the number of copies you want to print.	
Pages	Collated	Sort multiple copy jobs.	
	All or From	Print all of the pages in a document or print a range of pages.	
Layout	Pages per Sheet	Print multiple pages of your document on a single shee of paper.	
	Layout Direction	Print the pages of your document in a specified order.	
	Border	Print a border around each page of your document.	
Output Options	Save as PDF File	Print your document to a PDF.	
Color Options	Document Color	Choose a color setting.	
	Halftone	Choose a halftone setting.	





Basic printing

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

From the pop-up menu, choose:	Select:	When you want to:			
Advanced	Print Last Page First	Print your document in reverse page order.			
Layout	Mirror	Print your document as a mirror image.			
Quality & Media	Paper Type	Choose the paper type for your document.			
	Print Quality	Choose a print quality. You can choose from Quick Print, Normal, Better, or Best.			
		Note: Normal print quality is recommended for most documents. Higher print quality settings result in better quality documents for some paper types, but take longer to print. For more information about the appropriate print quality for your document, see Printing ideas.			
Printer	Lexmark Z54 Utility	Open the Lexmark Z54 Utility.			
Services	Troubleshooting	View troubleshooting information in the printer software Help.			
	Order Supplies	View supplies information or order supplies on the Lexmark Web site.			
	Software Version	View printer software version information.			





Prii	nter	ovei	rview

**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

From the pop-up menu, choose:	Select:	When you want to:
Summary		View a summary of the current print settings.
Save Custom Setting		Save the current print settings for future use.

- 4 If you want more information about the settings in the Print dialog, click ? to view Help on these items. When you are finished, click the red close button.
- **5** Click Print to apply your settings and print your document.





Basic printing

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

**Using this** Guide...

## **Lexmark Z54 Utility**

Use the Lexmark Z54 Utility to monitor your printer and printer supplies. You can:

- Install cartridges
- Align cartridges
- Clean print nozzles
- Select a printer

- Print a test page
- Obtain information on ordering supplies
- Obtain software version information
- Configure a network printer

#### Using the Lexmark Z54 Utility

1 From a Finder window, click Computer and then, double-click the OS X disk icon > Library folder ▶ Printers folder ▶ Lexmark folder.



**Basic printing** 

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

**Using this** Guide...

2 Double-click the Lexmark Z54 Utility icon.

The Lexmark Z54 Utility appears.

Click the:	Select:	When you want to:
Cartridges tab	Install/Change Cartridge	Specify cartridge settings in the printer software when installing or changing a cartridge. For more information, see <b>Replacing the print cartridge</b> .
	Align Cartridges	Align the cartridges. For more information, see Aligning the print cartridges.
	Clean Print Nozzles	Improve print quality by cleaning clogged print nozzles. For more information, see Cleaning the print cartridge nozzles.
	Print Test Page	Print a test page to verify your printer is functioning properly.
	Order Supplies	Order supplies, such as print cartridges, from the Lexmark Web site. For more information, see Ordering supplies.
About tab		Obtain printer software version information.





_						
$\mathbf{P}$	rır	ገ† 🗅	$r \circ$	$\sim$	r\/I	iew
		100		, v C	1 V I	CVV

**Basic printing** 

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

Click the:	Select:	When you want to:
Advanced menu	Select Printer	Select a printer and make it the default printer.
		Find the IP address for the selected printer.
		<ul> <li>Add a printer located on a remote subnet. You can add a single printer or search the subnet for all available printers.</li> </ul>
		<ul> <li>View a list of all USB, USB print sharing, and network printers.</li> </ul>
	Network Printer Configuration	<ul><li>Configure an unconfigured network printer.</li><li>View a list of network printers.</li></ul>

- **3** To learn more about what you can do with your printer, click the **?** to view the printer software Help. When you are finished, click the red close button.
- **4** Click the red close button to close the Lexmark Z54 Utility.



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 


**Notices** 

Index

Using this Guide...

# **Understanding the printer parts**

The table on the next page describes each part.







15

Printer overview

**Basic printing** 

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

Use this:	When you want to:
Front cover	<ul><li>Install or change print cartridges.</li><li>Clear a paper jam.</li></ul>
Paper exit tray	Stack paper after printing.
Paper feed button	Eject paper from the printer.
Paper feed light	Check the printer status. For more information, see Understanding error messages and flashing lights.
Paper guide	Make sure paper feeds correctly into the printer.
Paper support	Keep paper straight in the printer.
Power button	Turn the printer on or off.
Power light	Check the printer status. For more information, see Understanding error messages and flashing lights.
Power supply connector	Connect the power supply to the printer.
USB cable connector	Connect the printer to the computer with a USB cable.





**Basic printing** 

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

Using this Guide...

# Basic printing is as easy as:

**Step 1: Load the paper** 

**Step 2: Customize the printer settings** 

**Step 3: Print your document** 

**Note:** For help printing on specialty paper (such as photo paper, banner paper, transparencies, or iron-on transfers), see **Printing ideas**.



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index


Using this Guide...

# Step 1: Load the paper

You can load up to 100 sheets of paper, depending on the thickness and weight of your paper.

- **1** Make sure the paper support is upright.
- 2 Place the paper against the right side of the paper support with the print side facing you.

**Note:** A4 and letter size paper should extend slightly beyond the top of the paper support. Do not force the paper too far into the printer.



**3** Squeeze and slide the paper guide to the left edge of the paper.

For information about loading specialty paper, see **Printing ideas**.



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

# **Step 2: Customize the printer settings**

If you are using plain A4 or letter size paper and you want normal print quality, you only need to adjust the paper size printer setting.

If you are using specialty paper, such as photo paper, card stock, envelopes, or banner paper, see **Printing ideas** to customize your printer settings.

For more information about the different printer settings, see **Understanding the printer software**.



**Basic printing** 

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

Using this Guide...

# **Step 3: Print your document**

After you load the paper and customize the printer settings (if necessary), you are ready to print:

- **1** From the software application File menu, choose Print.
- 2 Click Print.

**Note:** The paper exit tray holds 50 sheets of paper. If you want to print more than 50 sheets, make sure you remove the first 50 sheets before you continue printing.



- Printer overview
- Basic printing
- Printing ideas
- Maintenance
- Troubleshooting
- **Notices**
- Index

- Printing photos
- Printing on premium (coated) paper
- Printing cards
- Printing envelopes
- Printing color images in black and white
- Printing labels

- Printing handouts
- Printing iron-on transfers
- Printing transparencies
- Printing a banner





Basic printing

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

Using this Guide...

# **Printing photos**


You can load up to 25 sheets of coated, photo, or glossy paper, depending on the thickness of the paper. You may want to print your photos on plain paper before loading photo paper and changing your settings. This ensures that you do not waste photo paper perfecting the image you would like to print. To print on photo cards, see **Printing cards**.

## Step 1: Load the photo paper

- If your photo paper came with instructions, read them carefully.
- · Make sure your paper is not used or damaged.
- Make sure the glossy or coated side is facing you.
- Load the paper against the right side of the paper support.

**Note:** Do not push the paper too far into the printer.

Squeeze and slide the paper guide to the left edge of the paper.





## **Basic printing**

## Printing ideas

#### Maintenance

## Troubleshooting

#### **Notices**

#### Index

Using this Guide...

## **Step 2: Customize the print settings**

For help, see **Understanding the printer software**.

- **1** Choose a paper size and orientation:
  - **a** From the software application File menu, choose Page Setup.
  - **b** From the Format for pop-up menu, choose Lexmark Z54.
  - **c** From the Settings pop-up menu, choose Page Attributes.
  - **d** From the Paper Size pop-up menu, choose the paper size for your photo.
  - e Choose Portrait, Landscape, or Reverse Landscape orientation.
  - f Click OK.
- **2** Choose a paper type, print quality, and color setting:
  - **a** From the software application File menu, choose Print.
  - **b** From the Printer pop-up menu, choose Lexmark Z54.
  - **c** From the pop-up menu in the upper left, choose Color Options.
  - **d** From the Document Color pop-up menu, choose Natural.
  - **e** From the Halftone pop-up menu, select Airbrush.



- Printer overview
- Basic printing
- Printing ideas
- Maintenance
- Troubleshooting
- **Notices**
- Index

Using this Guide...

- **f** From the pop-up menu in the upper left, choose Quality & Media.
- **g** From the Paper Type pop-up menu, choose Glossy/Photo.
- **h** From the Print Quality area, click Better or Best for the print quality.

**Note:** Higher print quality settings result in better quality documents, but may take longer to print.

## **Step 3: Print your photos**

Click Print.

**Note:** To prevent smearing, remove each photo as it exits the printer and let it dry before stacking.



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

# Printing on premium (coated) paper


You can load up to 100 pages of premium (coated) paper, depending on the thickness of the paper.

# Step 1: Load the premium (coated) paper

- If your paper came with instructions, read them carefully.
- Make sure your paper is not used or damaged.
- Make sure the print side is facing you.
- Load the paper vertically against the right side of the paper support.

**Note:** Do not push the paper too far into the printer.

• Squeeze and slide the paper guide to the left edge of the paper.





## **Basic printing**

## Printing ideas

#### Maintenance

## Troubleshooting

#### **Notices**

#### Index

Using this Guide...

## **Step 2: Customize the print settings**

For help, see **Understanding the printer software**.

- **1** Choose a paper size and orientation:
  - **a** From the software application File menu, choose Page Setup.
  - **b** From the Format for pop-up menu, choose Lexmark Z54.
  - **c** From the Settings pop-up menu, choose Page Attributes.
  - **d** From the Paper Size pop-up menu, choose the paper size for your document.
  - **e** Choose Portrait, Landscape, or Reverse Landscape orientation.
  - f Click OK.
- **2** Choose a paper type and print quality:
  - **a** From the software application File menu, choose Print.
  - **b** From the printer pop-up menu, choose Lexmark Z54.
  - **c** From the pop-up menu in the upper left, choose Quality & Media.
  - **d** From the Paper Type pop-up menu, choose Plain.
  - e From the Print Quality area, choose Better or Best.



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

**Note:** Higher print quality settings result in better quality documents, but may take longer to print.

## **Step 3: Print your document**

Click Print.

**Note:** The paper exit tray holds up to 50 sheets of premium paper. To print more than 50 pages, remove the first 50 sheets from the paper exit tray, and then continue printing.



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

# **Printing cards**


You can load up to 10 greeting cards, index cards, photo cards, or postcards into the paper support, depending on the thickness of the cards.

## **Step 1: Load the cards**

- If your cards came with instructions, read them carefully.
- Make sure your cards are not used or damaged.
- Make sure the print side is facing you.
- Load the cards vertically against the right side of the paper support.

Note: Do not push the cards too far into the printer.

Squeeze and slide the paper guide to the left edge of the cards.





Basic printing

## Printing ideas

Maintenance

## **Troubleshooting**

**Notices** 

Index

**Using this** Guide...

#### **Step 2: Customize the print settings**

For help, see Understanding the printer software.

- Choose a paper size and orientation:
  - **a** From the software application File menu, choose Page Setup.
  - From the Format for pop-up menu, choose Lexmark Z54.
  - From the Settings pop-up menu, choose Page Attributes.
  - From the Paper Size pop-up menu, choose the card size for your document.
  - Choose Portrait, Landscape, or Reverse Landscape orientation.
  - Click OK.
- **2** Choose a print quality and paper type:
  - **a** From the software application File menu, choose Print.
  - **b** From the Printer pop-up menu, choose Lexmark Z54.
  - From the pop-up menu in the upper left, choose Quality & Media.
  - d Choose:
    - Glossy/Photo Paper paper type for photo cards or Plain for other types of cards



**Basic printing** 

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

Using this Guide...

 Better or Best print quality for photo and greeting cards or Normal for other types of cards

**Note:** Higher print quality settings result in better quality documents, but may take longer to print.

#### **Step 3: Print your cards**

Click Print.

**Note:** Remove each card as it exits the printer and let it dry before stacking.



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index


Using this Guide...

# **Printing envelopes**

You can load up to 10 envelopes, depending on the thickness of the envelopes.

## **Step 1: Load the envelopes**

**Note:** Do not use envelopes with holes, windows, deep embossing, metal clasps, string ties, or metal folding bars.



- Make sure your envelopes are not used or damaged.
- Make sure the print side is facing you.
- Make sure the stamp location is in the upper left corner.
- Load the envelopes vertically against the right side of the paper support.

**Note:** Do not push the envelopes too far into the printer.

• Squeeze and slide the paper guide to the left edge of the envelopes.



## **Basic printing**

## Printing ideas

#### Maintenance

## Troubleshooting

#### **Notices**

#### Index

Using this Guide...

## **Step 2: Customize the print settings**

For help, see Understanding the printer software.

- **1** Choose an envelope size and orientation:
  - **a** From the software application File menu, choose Page Setup.
  - **b** From the Format for pop-up menu, choose Lexmark Z54.
  - **c** From the Settings pop-up menu, choose Page Attributes.
  - **d** Select Paper Size to choose the appropriate envelope size.
  - e Choose Landscape orientation.

**Note:** Many software applications are designed to override the envelope settings in Page Setup. Make sure Landscape orientation is also selected in your software application.

- f Click OK.
- 2 Choose a print quality and paper type:
  - a From the software application File menu, choose Print.
  - **b** From the Printer pop-up menu, choose Lexmark Z54.



- Printer overview
- Basic printing
- Printing ideas
- Maintenance
- Troubleshooting
- **Notices**
- Index

Using this Guide...

- **c** From the pop-up menu in the upper left, choose Quality & Media.
- **d** From the Print Quality area, choose Normal print quality.
- **e** Choose Plain for the paper type.

## **Step 3: Print your envelopes**

Click Print.

**Note:** The paper exit tray holds up to 10 envelopes. To print more than 10 envelopes, remove the first 10 envelopes from the paper exit tray before the others print.





**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...


# Printing color images in black and white


You can print color images in black ink.

## Step 1: Load the paper

- Make sure your paper is not used or damaged.
- Make sure the print side is facing you.
- Load the paper vertically against the right side of the paper support.

**Note:** Do not push the paper too far into the printer.







**Basic printing** 

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

Using this Guide...

## **Step 2: Customize the print settings**

For help, see Understanding the printer software.

- 1 From the software application File menu, choose Print.
- **2** From the Printer pop-up menu, choose Lexmark Z54.
- **3** From the pop-up menu in upper left, choose Color Options.
- 4 From the Document Color pop-up menu, choose Black Only.
- 5 Continue customizing your document following the steps in **Basic printing** or **Printing ideas** or continue with the next step.

#### **Step 3: Print your document**

Click Print.

**Note:** The paper exit tray holds up to 50 sheets of paper or 10 photo cards. To print more than 50 sheets of paper, remove the first 50 sheets from the paper exit tray before the others print. To print more than 10 photo cards, remove the first 10 cards from the paper exit tray before the others print.



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

# **Printing labels**


You can load up to 25 sheets of labels, depending on the thickness of the sheets.

## Step 1: Load the labels

- Use only labels designed for inkjet printers.
- If your labels came with instructions, read them carefully.
- Make sure your labels are not used or damaged.
- Do not print within 1 mm (0.04 in.) of the edge of a label.
- Make sure there are no missing or curled labels.
- Make sure the print side is facing you.
- Load the labels vertically against the right side of the paper support.

**Note:** Do not push the label sheets too far into the printer.

Squeeze and slide the paper guide to the left edge of the sheet of labels.







## **Basic printing**

## Printing ideas

#### Maintenance

## Troubleshooting

#### **Notices**

#### Index

Using this Guide...

## **Step 2: Customize the print settings**

For help, see **Understanding the printer software**.

- **1** Choose a paper size and orientation:
  - **a** From the software application File menu, choose Page Setup.
  - **b** From the Format for pop-up menu, choose Lexmark Z54.
  - **c** From the Settings pop-up menu, choose Page Attributes.
  - **d** Select Paper Size to choose A4 or U.S. Letter.
  - e Choose Portrait or Landscape orientation.
  - f Click OK.
- 2 Choose a print quality and paper type:
  - a From the software application File menu, choose Print.
  - **b** From the Printer pop-up menu, choose Lexmark Z54.
  - **c** From the pop-up menu in the upper left, choose Quality & Media.
  - **d** From the Print Quality area, select Normal.
  - e From the Paper Type area, choose Plain.





**Basic printing** 

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

Using this Guide...

**Note:** Higher print quality settings result in better quality documents, but may take longer to print.

### **Step 3: Print your labels**

Click Print.

**Note:** The paper exit tray holds up to 10 sheets of labels. To print more than 10 sheets, remove the first 10 sheets from the paper exit tray before the others print.



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

## **Printing handouts**


You can conserve paper by printing handouts. Handouts are multiple page images on a single sheet of paper. You can load up to 100 sheets of paper, depending on the thickness of the paper.

#### **Step 1: Load the paper**

- If your paper came with instructions, read them carefully.
- Make sure your paper is not used or damaged.
- Make sure the print side is facing you.
- Load the paper vertically against the right side of the paper support.

Note: Do not push the paper too far into the printer.

Squeeze and slide the paper guide to the left edge of the paper.





#### **Basic printing**

#### Printing ideas

#### Maintenance

#### Troubleshooting

#### **Notices**

#### Index

Using this Guide...

### **Step 2: Customize the print settings**

For help, see **Understanding the printer software**.

You can print your handouts on one side or on both sides of the paper.

- **1** Choose a paper size and orientation:
  - **a** From the software application File menu, choose Page Setup.
  - **b** From the Format for pop-up menu, choose Lexmark Z54.
  - **c** From the Settings pop-up menu, choose Page Attributes.
  - **d** Select Paper Size to choose the paper size of your document.
  - **e** Choose Portrait, Landscape, or Reverse Landscape orientation.
  - f Click OK.
- **2** Choose a print quality and paper type:
  - **a** From the software application File menu, choose Print.
  - **b** From the Printer pop-up menu, choose Lexmark Z54.
  - **c** From the pop-up menu in the upper left, choose Quality & Media.
  - **d** Select a paper type for your document.



- Printer overview
- Basic printing
- Printing ideas
- Maintenance
- **Troubleshooting**
- **Notices**
- Index

**Using this** Guide...

- Select a print quality for your document.
- From the pop-up menu in the upper left, select Layout.
- From the Pages per sheet pop-up menu, choose the number of pages you want to print on one sheet.
- **h** From the Layout Direction area, click the graphic that shows the order you want the pages to print on the sheet.
- If you want to print a border around each image, choose an option from the Border pop-up menu.

#### **Step 3: Print your handouts**

Click Print.



**Basic printing** 

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

Using this Guide...

## **Printing iron-on transfers**


You can load up to 25 iron-on transfers, depending on the thickness of the iron-on transfers. You may want to print your image on plain paper before printing it on an iron-on transfer. This ensures you do not waste iron-on transfers perfecting the image you would like to print. When the image prints to your satisfaction, load the iron-on transfers.

## Step 1: Load the iron-on transfers

- If your transfers came with instructions, read them carefully.
- Make sure your transfers are not used or damaged.
- Make sure the print (blank) side is facing you.
- Load the iron-on transfers vertically against the right side of the paper support.

Note: Do not push the iron-on transfers too far into the printer.

Squeeze and slide the paper guide to the left edge of the iron-on transfers.





**Basic printing** 

#### Printing ideas

Maintenance

Troubleshooting

**Notices** 


Index

Using this Guide...


## **Step 2: Customize the print settings**

For help, see **Understanding the printer software**.

- 1 Choose a paper size:
  - **a** From the software application File menu, choose Page Setup.
  - **b** From the Format for pop-up menu, choose Lexmark Z54.



- **d** Select Paper Size to choose a paper size.
- **e** Choose Portrait, Landscape, or Reverse Landscape orientation.
- f Click OK.
- **2** Choose a paper type and print quality:
  - **a** From the software application File menu, choose Print.
  - **b** From the Printer pop-up menu, choose Lexmark Z54.
  - **c** From the pop-up menu in the upper left, choose Quality & Media.
  - d Click Normal for the print quality.







Basic printing

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

**Using this** Guide...

**e** From the Paper Type pop-up menu, choose Iron-On Transfer.

Note: Choosing Iron-On Transfer automatically mirrors the image you want to print. Make sure you do not select an option from your software application that will mirror your image.

- If your software application also mirrors the image, follow these steps:
  - From the pop-up menu in the upper left, choose Advanced Layout.
  - Make sure Mirror is not checked.

#### **Step 3: Print your iron-on transfers**

Click Print.

Note: To prevent smudging, remove each iron-on transfer as it exits the printer and let it dry before stacking.



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

## **Printing transparencies**

You can load up to 10 transparencies, depending on the thickness of the transparencies.

## **Step 1: Load the transparencies**


- Use transparencies designed for inkjet printers.
- If the transparencies have paper backing sheets, make sure you separate the paper from the transparencies before you load them.
- Make sure your transparencies are not used or damaged.



- Make sure the rough (print) side of the transparencies is facing you. If the transparencies have a removable strip, make sure each strip faces away from you and down.
- Load the transparencies vertically against the right side of the paper support.

**Note:** Do not push the transparencies too far into the printer.

Squeeze and slide the paper guide to the left edge of the transparencies.





Basic printing

#### Printing ideas

Maintenance

#### **Troubleshooting**

**Notices** 

Index

**Using this** Guide...

#### **Step 2: Customize the print settings**

For help, see **Understanding the printer software**.

- Choose a paper size:
  - **a** From the software application File menu, choose Page Setup.
  - **b** From the Format for pop-up menu, choose Lexmark Z54.
  - From the Settings pop-up menu, choose Page Attributes.
  - **d** Choose a paper size.
  - e Click OK.
- Choose a paper type and print quality:
  - **a** From the software application File menu, choose Print.
  - **b** From the Printer pop-up menu, choose Lexmark Z54.
  - From the pop-up menu, choose Quality & Media.
  - From the Paper Type pop-up menu, choose Transparency.
  - Click Normal or Better for the print quality.



**Basic printing** 

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

Using this Guide...

**Note:** Higher print quality settings result in better quality documents, but may take longer to print.

### **Step 3: Print your transparencies**

Click Print.

**Note:** To prevent smudging, remove each transparency as it exits the printer and let it dry before stacking. Transparencies may require up to 15 minutes to dry.



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

## Printing a banner


**Note:** Some software applications and some operating systems do not support banner printing.


### Step 1: Load the banner paper

Make sure your banner paper is not used or damaged.

- **1** Remove any paper from the paper support.
- **2** Tear off enough pages for the banner including one extra sheet, and then place them behind the printer.
- **3** Load the unattached leading edge of the first page into the printer, with the right side against the paper support.

Note: Forcing the paper too far into the printer may cause a paper jam. For help, see Clearing paper misfeeds or jams.







Basic printing

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

**Using this** Guide...

4 Squeeze and slide the paper guide to the left edge of the banner paper.

#### **Step 2: Customize the print settings**

For help, see **Understanding the printer software**.

- 1 Choose a paper size and orientation:
  - **a** From the software application File menu, choose Page Setup.
  - **b** From the Format for pop-up menu, choose Lexmark Z54.
  - **c** From the Settings pop-up menu, choose Page Attributes.
  - **d** Choose a paper size, either Banner A4 or Banner Letter.

Note: If you do not choose the correct paper size, the banner paper may cause a paper jam. For help, see Clearing paper misfeeds or jams.

- Choose Portrait or Landscape orientation.
- Click OK.
- Choose a paper type and print quality:
  - **a** From the software application File menu, choose Print.
  - **b** From the printer pop-up menu, choose Lexmark Z54.



- Printer overview
- Basic printing
- Printing ideas
- Maintenance
- **Troubleshooting**
- **Notices**
- Index

**Using this** Guide...

- From the pop-up menu in the upper left, choose Quality & Media.
- Select Plain for the paper type.
- Select Normal for the print quality.

### **Step 3: Print your banner**

- Click Print.
- When the banner is finished printing:
  - **a** Press the paper feed button to feed any extra paper through the printer.
  - Tear the banner paper on the perforated line (if there is any extra paper).



**50** 

- Printer overview
- **Basic printing**
- Printing ideas
- Maintenance
- **Troubleshooting**
- **Notices**
- Index

**Using this** Guide...

- Replacing the print cartridge
- Aligning the print cartridges
- Cleaning the print cartridge nozzles
- Wiping the print cartridge nozzles and contacts
- **Preserving the print cartridges**
- **Ordering supplies**





**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

## Replacing the print cartridge


Before you install a new or replacement print cartridge, remove the used one.

### Removing the used cartridge

- **1** Make sure the power light is on.
- 2 Raise the front cover.

The cartridge carrier moves to the loading position, unless the printer is busy.

**3** Remove the used cartridge. Store it in an airtight container or dispose of it properly.





**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

### Installing a cartridge

For best results, use Lexmark supplies. Refilling print cartridges can affect print quality and cause damage to the printer.

Your printer came with:	You can print with:
Color cartridge (P/N 15M0120)	<ul> <li>A black cartridge in the right carrier and a color cartridge in the left carrier.</li> </ul>
Black cartridge (P/N 12A1970)	A photo cartridge* in the right carrier and a color cartridge in the left carrier.

- \* You can purchase a photo cartridge (P/N 12A1990) separately.
  - 1 If you are installing a new cartridge, remove the sticker and transparent tape from the back and bottom of the cartridge.

**Warning:** Do **not** touch or remove the gold contact areas on the back and bottom of the cartridge.







**53** 

Printer overview

**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 


Index

Using this Guide...

**2** Open the front cover.

**Note:** The cartridge carrier moves to the loading position.


- 3 Insert the color cartridge in the left carrier. Insert the black cartridge in the right carrier.
- **4** Snap the cartridges into place.




5 Close the front cover.

**Note:** The front cover must be closed to start a new print job.











**Basic printing** 

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

Using this Guide...

## Specifying cartridge settings in the printer software

Before you specify the print cartridge settings in the printer software, install the cartridges. For help, see **Installing a cartridge**.

- 1 After you install the cartridge, from a Finder window, click Computer, and then double-click the OS X disk icon ▶ Library folder ▶ Printers folder ▶ Lexmark folder.
- 2 Double-click the Lexmark Z54 Utility icon.
- 3 Click the Install/Change Cartridge button.
- **4** Choose the type of cartridge you installed.
- **5 Important:** For correct ink levels, specify whether the cartridge is a New Cartridge or an Old Cartridge.
- 6 Click OK.
- **7** Choose to automatically or manually align the cartridges.
- 8 Click Continue to print an alignment page.
- **9** Follow the instructions on the screen to complete cartridge alignment. For help, see **Aligning the print cartridges**.



### **Basic printing**

#### Printing ideas

#### Maintenance

### Troubleshooting

#### **Notices**

#### Index

Using this Guide...

## Aligning the print cartridges

Typically, you only align print cartridges after installing or replacing a cartridge. However, you may also need to align cartridges when:

- Characters are improperly formed or are misaligned at the left margin.
- Vertical, straight lines are wavy.

#### To align the cartridges:

- 1 Load plain paper. For help, see Load the paper.
- 2 From a Finder window, click Computer, and then double-click the OS X disk icon ► Library folder ► Printers folder ► Lexmark folder.
- 3 Double-click the Lexmark Z54 Utility icon.
- 4 From the Cartridges tab, click Align Cartridges.
  - The Cartridge Alignment dialog appears.
- **5** Decide how you want to align the cartridges:
  - If you choose Automatic Alignment (recommended), the printer determines the best alignment and automatically aligns the cartridges.
  - If you choose Manual Alignment, you must select the best alignment values from the printed page.



- Printer overview
- **Basic printing**
- Printing ideas
- Maintenance
- **Troubleshooting**
- **Notices**
- Index

**Using this** Guide...

- a If you chose to manually align the cartridges, find the number under the darkest arrow for each alignment group.
- **b** Use the arrows in the Align Cartridges dialog to select the number that matches the darkest arrow on the printed page for each alignment group, and then click OK. If the alignment page does not print, make sure you have completely removed the sticker and transparent tape from both cartridges. For help, see Installing a cartridge.





**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

## Cleaning the print cartridge nozzles

To improve print quality, you may need to clean the print cartridge nozzles. Clean the nozzles when:

- Characters are not printing completely.
- White dashes appear in graphics or printed text.
- Print is smudged or too dark.

- Vertical, straight lines are not smooth.
- Colors on print jobs are faded or they differ from the colors on the screen.

To clean the nozzles:

- 1 Load paper. For help, see Load the paper.
- 2 Open the Lexmark Z54 Utility.
- 3 On the Cartridges tab, click Clean Print Nozzles.
  A nozzle page prints, forcing ink through the nozzles to clean any that are clogged.
- 4 Print your document again to verify your print quality has improved.
- 5 To further improve print quality, try Wiping the print cartridge nozzles and contacts, and then print your document again. If the print quality has not improved, try Cleaning the print cartridge nozzles up to two more times.



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 


Index


Using this Guide...

## Wiping the print cartridge nozzles and contacts

If the print quality does not improve after **Cleaning the print cartridge nozzles**, there may be dried ink on the nozzles or contacts.

- 1 Remove the print cartridge. For help, see Replacing the print cartridge.
- 2 Dampen a clean, lint-free cloth with water.
- a Hold the damp cloth against the nozzles for about three seconds. Gently blot and wipe dry in one direction.
- b Hold a clean section of cloth against the contacts for about three seconds. Gently blot and wipe dry in one direction.





- 3 Allow the nozzles and contacts to dry completely.
- **4** Reinstall the print cartridges, and then print your document again.





- Printer overview
- **Basic printing**
- Printing ideas
- Maintenance
  - **Troubleshooting**
  - **Notices**
  - Index

**Using this** Guide...

- 5 If the print quality has not improved, try Cleaning the print cartridge nozzles up to two more times.
- If print quality is still unsatisfactory, replace your print cartridges. For help, see Replacing the print cartridge.





60

Printer overview

Basic printing

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

**Using this** Guide...

## Preserving the print cartridges

To ensure the longest life from your print cartridges and optimum performance from your printer:

- Keep a new cartridge in its packaging until you are ready to install it.
- Do not remove a cartridge from the printer except to replace it, clean it, or store it in an airtight container. The cartridge will not print correctly if left exposed for an extended period of time.

Lexmark's printer warranty does not cover repair of failures or damage caused by a refilled cartridge. Lexmark does not recommend use of refilled cartridges. Refilling cartridges can affect print quality and cause damage to the printer. For best results, use Lexmark supplies.



61

Printer overview

**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

**Using this** Guide...

# **Ordering supplies**

To order supplies or locate a dealer near you, contact the Lexmark Web site at www.lexmark.com.

Item:	Part number:
Color cartridge	15M0120 or 15M0125
Black cartridge	12A1970 or 12A1975
Photo cartridge (optional)	12A1990
USB cable	12A2405



- Printer overview
- Basic printing
- Printing ideas
- Maintenance
- Troubleshooting
  - **Notices**
  - Index

Using this Guide...

- Solving general printing problems
- Solving printer software installation problems
- Solving network printing problems
- Understanding error messages and flashing lights
- Resolving unsuccessful or slow printing
- Clearing paper misfeeds or jams
- Improving print quality
- Solving specialty paper problems
- Alignment page does not print



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

## Solving general printing problems

When you have a printing problem, first make sure:

- The power supply is plugged into the printer and a properly grounded electrical outlet.
- Both the computer and the printer are on. If you are using your printer on a network, make sure your computer is connected to the network, your Lexmark adapter is on, and all indicator lights are on. For more information, refer to the adapter documentation.
- No printer lights are blinking. For help, see Understanding error messages and flashing lights.
- The printer software is installed correctly:
  - a From a Finder window, click Computer ▶ OS X disk ▶ Library ▶ Printers ▶ Lexmark.
  - **b** If there is not a Lexmark Z54 Utility, install the printer software.
- The paper is loaded correctly. For help, see **Load the paper**.
- You installed the cartridges correctly. For help, see **Replacing the print cartridge**.
- The printer is set as the default or current printer.

To set the printer to be the default printer:





**Basic printing** 

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

Using this Guide...

- a From the Finder, click the Applications icon.
- **b** From the Applications folder, double-click the Utilities folder, and then double-click Print Center.
- **c** If necessary, from the Printer menu, click View Printer List.
- d Highlight the Lexmark Z54 in the list.
- e In the Printers menu, select Make Default.

To set the printer to be the current printer:

- **a** From the software application File menu, choose Print.
- **b** From the Format for pop-up menu, choose Lexmark Z54.
- The printer is connected directly to your computer, a network connection, or through a Lexmark adapter.

After you check all of the previous items, try **Printing a test page**.



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

#### Printing a test page

- 1 From a Finder window, click Computer, and then double-click the OS X disk icon ▶ Library folder ▶ Printers folder ▶ Lexmark folder.
- **2** Double-click the Lexmark Z54 Utility icon.
- From the Cartridges tab, click Print Test Page to make sure the printer is functioning properly.
  - If a test page prints, the printer is working properly. Check the documentation for the software application you used to create your document.
  - If the test page does not print, see Test page does not print.



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

## Solving printer software installation problems

If the printer software does not install properly, a communications error message appears when you try to print. You may need to uninstall the printer software, and then reinstall it.

## Uninstalling the printer software

1 Insert the printer software CD.

The Lexmark Installer screen appears.

- 2 Double-click the CD icon.
- 3 Double-click Install OS X.
- 4 Click Uninstall.
- **5** Follow the steps on your screen to uninstall the printer software.
- 6 Continue with Installing the printer software.

**Note:** If the installer did not automatically launch, double-click the Install icon to launch the installer.



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

#### Installing the printer software

You can install the printer software using the CD that came with your printer, or you can download it from the Lexmark Web site at www.lexmark.com.

To connect your printer to a network with a Lexmark adapter, refer to the documentation that came with your adapter.

#### Using the CD that came with your printer

- 1 Close all open software applications.
- **2** When your desktop appears, insert the printer software CD.
- 3 Double-click Lexmark Z54 CD.
- 4 Double-click Install OS X.
- 5 Click Install and Agree.

**Note:** If the Printer Selection or the New Network Printer Found dialog box appears, follow the instructions displayed. Click the ? on the screen or contact your network administrator for help.

- 6 Choose the country or region closest to you if your country is not listed.
- 7 Click Continue.



- Printer overview
- Basic printing
- Printing ideas
- Maintenance
- Troubleshooting
- **Notices**
- Index

Using this Guide...

- **8** Follow the instructions on your screen to complete printer software installation.
- **9** On the Printer Selection screen, click Open Print Center.

**Note:** The Lexmark Z54 should appear in the Print Center as added automatically. If it does not, click Add Printer.

- 10 Click the red close button to close the Print Center.
- 11 On the Printer Selection screen, click Continue.
- 12 Click Continue to print an alignment page, used to automatically align the cartridges.
  - If the alignment page does not print, make sure you installed the cartridges correctly. For help, see Installing a cartridge.
  - If the paper is jammed, make sure you follow the instructions on the error message that is displayed. For help, see Clearing paper misfeeds or jams.

#### Using the World Wide Web

- 1 Make sure Stuffit Expander is loaded on your system.
- **2** From the Lexmark Web site, **www.lexmark.com**, select the appropriate driver for your operating system.
- **3** Click the binhex (.hqx) file to download and install.



69

- Printer overview
- **Basic printing**
- Printing ideas
- Maintenance
- Troubleshooting
- **Notices**
- Index

**Using this** Guide...

- **4** Use Stuffit Expander to expand the file on your desktop.
- Double-click the folder to open it.
- Double-click Install.
- **7** Follow the instructions on your screen to install the printer software.





**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

# **Solving network printing problems**

For help, first see **Solving general printing problems**.

If one or more of the following conditions applies to your network printer, you must enter an IP address to set up your network printer:

- Your printer is listed as unconfigured in the Network Printer Configuration Dialog or in the Printer Selection dialog.
- Your printer is on a remote subnet.

If one or more of the conditions above applies to your network printer, continue with **Entering** an **IP** address. If none of these conditions apply, continue with **Troubleshooting your network printer**.



**Basic printing** 

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

Using this Guide...

### **Entering an IP address**

To enter an IP address and set up your network printer:

- 1 Open the Lexmark Z54 Utility.
- **2** From the Advanced menu, choose Network Printer Configuration.
- **3** From the dialog:

Click:	То:
A printer from the list of available network printers, and then click Configure	Enter an available IP address for the selected printer. For help selecting an IP address, refer to the documentation you used to set up your network or contact your network administrator.
Add Remote	Expand the printer list to include printers on a remote subnet.
	<ul> <li>If you choose Add Single Printer, enter the IP address for the printer you want to add.</li> </ul>
	<ul> <li>If you choose Search Subnet, enter the IP address of the subnet you want to scan. Any remote printers that are found will be added to the printer list. These printers are saved in the list if a printer is added in Print Center.</li> </ul>

The IP address of your network printer is set.

4 Click Done.



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

**5** Click the red close button to close the Lexmark Z54 Utility.

#### **Troubleshooting your network printer**

Try these solutions when you cannot print to your network printer:

- **1** Make sure your printer is connected to a working network connection.
- **2** If you are using a Lexmark adapter, make sure all of the indicator lights are on. For help locating these lights, refer to the adapter documentation.
- **3** Make sure the printer software is installed correctly:
  - **a** From a Finder window, click Computer ▶ OS X icon ▶ Library ▶ Printers ▶ Lexmark.
  - **b** If a Lexmark Z54 Utility for your printer does not appear, install the printer software. For help, see **Installing the printer software**.
- 4 Try Printing a test page.

If the test page does not print, see **Test page does not print**.



Basic printing

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

**Using this** Guide...

# Understanding error messages and flashing lights

Use this section to understand printer software error messages on your computer screen and blinking lights on your printer. For information about lights on a Lexmark adapter, refer to the adapter documentation.

# Paper Jam message

For help clearing a paper jam, see Clearing paper misfeeds or jams.

# Ink Low message

A print cartridge is running out of ink. To order a new cartridge or locate a dealer near you, contact the Lexmark Web site at www.lexmark.com. For help installing the cartridge, see Replacing the print cartridge.



Basic printing

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

# Paper feed light is blinking

If the printer is out of paper:


- 1 Load paper. For help, see Load the paper.
- **2** Press the paper feed button.


If the printer has a paper jam, see Clearing paper misfeeds or jams.

# Power light is flashing

The print cartridge carrier is stalled.

- 1 Check your computer screen for error messages.
- 2 Turn the printer off.
- **3** Wait a few seconds, and then turn the printer back on. For more help, see **Clearing paper misfeeds or jams**.







**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

# Resolving unsuccessful or slow printing

For help, first see **Solving general printing problems**.

If there is still a problem, click the topic that best describes it:

- Printer is plugged in, but does not print
- Test page does not print

- Printer ejects a blank page after appearing to print
- Printer prints very slowly



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

# Printer is plugged in, but does not print

#### Make sure:

- The printer is on and the printer cable is securely attached at both ends. If your printer
  is connected to a network, make sure the Lexmark adapter is on and all indicator
  lights are on. For help, refer to the adapter documentation.
- The paper is loaded correctly and not pushed too far into the printer. For help, see **Basic printing**. If the paper is jammed, see **Clearing paper misfeeds or jams**.
- The printer is not being held or paused. To check the printer status:
  - a From the Finder, click the Applications icon.
  - **b** From the Applications folder, double-click the Utilities icon, and then double-click the Print Center.
  - c If necessary, click View Printer List.
  - **d** Highlight the Lexmark Z54 in the list.
  - e From Queue menu, choose Start Queue, if available.
  - **f** From the Printers menu, choose Show Queue.
  - g Select your job from the list.
  - **h** Click Resume or Retry.



- Printer overview
- **Basic printing**
- Printing ideas
- Maintenance
- Troubleshooting
- **Notices**
- Index

Using this Guide...

- The printer is set as the default printer. To set the printer as the default:
  - **a** From the Finder, click the Applications icon.
  - **b** From the Applications folder, double-click the Utilities icon, and then double-click the Print Center.
  - c If necessary, click View Printer List.
  - d Highlight the Lexmark Z54 in the list.
  - e From the Printers menu, choose Make Default.

After you check these items, try **Printing a test page**.

If the test page prints, the printer is functioning properly. If it does not print, see **Test page does not print**.



**Basic printing** 

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

Using this Guide...

# Test page does not print

For help, first see **Solving general printing problems**, then:

- If the paper is jammed, see Clearing paper misfeeds or jams.
- Make sure the printer is not being held or paused. To check the printer status:
  - a From the Finder, click the Applications icon.
  - **b** From the Applications folder, double-click the Utilities icon, and then double-click the Print Center.
  - c If necessary, click View Printer List.
  - d Highlight the Lexmark Z54 in the list.
  - e From the Queue menu, choose Start Queue, if available.
  - f From the Printers menu, choose Show Queue.
  - g Select your job from the list.
  - **h** Click Resume or Retry.



- Printer overview
- **Basic printing**
- Printing ideas
- Maintenance
- Troubleshooting
- **Notices**
- Index

Using this Guide...

- i Try printing your test page again. If it still does not print, see:
  - Resolving unsuccessful or slow printing
  - Solving printer software installation problems
  - Solving network printing problems

# Printer ejects a blank page after appearing to print

#### Make sure:

- You remove the sticker and transparent tape from the back and bottom of the print cartridges. For help, see **Replacing the print cartridge**.
- Your cartridge does not have clogged nozzles. Try Cleaning the print cartridge nozzles.



80

Printer overview

Basic printing

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

**Using this** Guide...

# **Printer prints very slowly**

- If you are using a Mac OS X version prior to 10.1, consider upgrading to enhance print system performance.
- Close any software applications not in use.
- Check the document you are printing. Photos and graphics may take longer to print than regular text. Documents that are large or that contain background images may also take longer to print.
- Check the printer to see if another document is being printed. Print jobs are printed in the order the printer receives them. If other documents were sent to the printer before yours, your document is delayed until the other documents print.
- Decrease the print quality setting to Normal or Quick Print.

Note: Higher print quality settings result in better quality documents, but may take longer to print.



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

# Clearing paper misfeeds or jams

Click the topic that best describes your problem:

- Paper misfeeds or multiple sheets feed
- Printer does not feed envelopes or specialty paper

• Printer has a paper jam



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

# Paper misfeeds or multiple sheets feed

#### Make sure:

- The edges of your paper are not curled.
- Your paper is recommended for inkjet printers.
- A piece of paper from a previous print job is not jammed in the printer.
- You do not load too much paper. Depending on the weight of the paper, you can load up to 100 sheets of plain paper.
- You do not force the paper too far into the printer.
- The paper guide is against the left edge of the paper.
- The paper guide does not cause the paper to bow.
- The printer is on a flat, level surface.
- The printer settings you have chosen are correct for the type of document you are printing. For help, see Basic printing or Printing ideas.



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

# Printer does not feed envelopes or specialty paper

#### Make sure:

- Your printer feeds paper without problems. Load the envelopes or specialty paper vertically against the right side of the paper support. Squeeze and slide the paper guide to the left edge of the envelopes or specialty paper. For help, see **Printing** ideas.
- You select the appropriate envelope or specialty paper size in the Page Setup dialog and the appropriate paper type in the Print dialog.
- You are using a specialty paper or envelope size supported by your printer.
- Your software application is designed to print envelopes. For help, check your software application documentation.
- The envelope or specialty paper is not jammed. For help, see Printer has a paper jam.
- Your printer is not being held or paused. To check the printer status:
  - **a** From the Finder, click the Applications icon.
  - **b** From the Applications folder, double-click the Utilities icon, and then double-click the Print Center.
  - **c** If necessary, from the Printer menu, choose View Printer List.



- Printer overview
- **Basic printing**
- Printing ideas
- Maintenance
- Troubleshooting
- **Notices**
- Index

Using this Guide...

- **d** Highlight the Lexmark Z54 in the list.
- **e** From the Queue, choose Start Queue, if available.
- **f** From the Printers menu, choose Show Queue.
- **g** Select a job from the list.
- h Click Resume or Retry.

# Printer has a paper jam

If the paper is lodged too far into the printer and cannot be removed:

- 1 Turn the printer off.
- 2 Turn the printer back on.
- 3 If the printer does not automatically eject the page:
  - **a** Turn the printer off.
  - **b** Pull firmly on the paper to remove it.
    - If you cannot reach the paper, raise the front cover, pull the paper out, and then close the front cover.
  - **c** Turn the printer on.





**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

# Improving print quality

If print quality is unsatisfactory, you may need to adjust your margin settings, choose a higher print quality, align the print cartridges, or clean the nozzles.

Click one of the topics below for more information on how you can improve print quality:

- · Print is too dark or smudged
- · Vertical straight lines are not smooth
- · Print smears on the page
- Printed pages have alternating bands of light and dark print (intermittent printing)
- Print quality is poor at the edges

- Printed characters are improperly formed or misaligned
- Colors on the printout differ from the colors on the screen
- · Colors on the printout are faded
- Characters are missing or unexpected
- Photos do not print as expected





86

Printer overview

Basic printing

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

**Using this** Guide...

# Print is too dark or smudged

- Make sure the paper is straight and not wrinkled.
- Let the ink dry completely before handling the paper.
- Make sure the paper type and paper size settings in the printer software match the paper loaded in the printer. For help, see Understanding the printer software.
- Change the print quality setting to Quick Print.
- Try Cleaning the print cartridge nozzles.

# Vertical straight lines are not smooth

To improve the print quality of vertical straight lines in tables, borders, and graphs:

- Select a higher print quality.
- Try Aligning the print cartridges.
- Try Cleaning the print cartridge nozzles.



Basic printing

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

**Using this** Guide...

# Print smears on the page

- The next page exiting the printer may be smearing the ink. Remove each page as it exits the printer and let it dry completely before stacking.
- Try Cleaning the print cartridge nozzles.

# Printed pages have alternating bands of light and dark print (intermittent printing)

- From the Print Quality area, click Better or Best.
- If your printer is connected to your computer through a hub or peripheral device, such as a scanner or fax machine, connect the printer directly to your computer with a USB cable.
- If your printer is connected to your network, connect the printer directly to your computer with a USB cable.



**Basic printing** 

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

Using this Guide...

# Print quality is poor at the edges

Like other printers, your printer cannot print on the extreme edges of a page.

Margin:	Minimum setting:	
Left and right	<ul> <li>6.35 mm (0.25 in.) for U.S. Letter, U.S. Legal, Banner Letter, and custom paper sizes</li> </ul>	
	• 3.175 mm (0.125 in.) for envelopes	
	3.37 mm (0.13 in.) for most paper sizes	
Тор	• 1.7 mm (0.067 in.)	
Bottom	12.7 mm (0.5 in.) for black print jobs	
	19 mm (0.75 in.) recommended for color print jobs	



# **Basic printing**

# Printing ideas

## Maintenance

# Troubleshooting

## **Notices**

#### Index

Using this Guide...

# Printed characters are improperly formed or misaligned

- Cancel all print jobs and print your job again. To cancel all print jobs:
  - a From the Finder, click the Applications icon.
  - **b** From the Applications folder, double-click the Utilities icon, and then double-click the Print Center.
  - c If necessary, click View Printer List.
  - d Highlight the Lexmark Z54 in the list.
  - **e** From the Queue menu, choose Start Queue.
  - f From the Printers menu, choose Show Queue.
  - g Select the job you want to delete.
  - h Click Delete.
  - i Repeat step g and step h until all jobs are deleted.
- Try Aligning the print cartridges.
- Try Cleaning the print cartridge nozzles.



## **Basic printing**

# Printing ideas

## Maintenance

# Troubleshooting

## **Notices**

#### Index

Using this Guide...

# Colors on the printout differ from the colors on the screen

- A cartridge may be low on ink. For help, see Replacing the print cartridge.
- Use a different paper brand. Each paper brand accepts ink differently and prints with color variations.

#### Select Natural Color as the document color:

- 1 From the software application File menu, choose Print.
- 2 From the Printer pop-up menu, select Lexmark Z54.
- **3** From the pop-up menu in the upper left, choose Color Options.
- **4** From the Document Color pop-up menu, choose Natural.

# Colors on the printout are faded

Try the suggestions listed in the section Colors on the printout differ from the colors on the screen. If the colors still seem faded, try Cleaning the print cartridge nozzles.

# Characters are missing or unexpected

Try Cleaning the print cartridge nozzles.



**Basic printing** 

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

Using this Guide...

# Photos do not print as expected

To improve the quality of printed photos:

- Select a higher print quality.
- Select photo paper as the paper type.



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

# Solving specialty paper problems

Use this section to help solve problems with specialty paper.

# Glossy or photo papers or transparencies stick together

- Use a photo paper or transparency designed for an inkjet printer.
- Make sure you loaded the paper correctly (with print side facing you) and selected the
  appropriate settings in the printer software. For help, see Printing photos or
  Printing transparencies.
- Remove each page as it exits the printer and let it dry completely before stacking.

# Transparencies or photos contain white lines

- Make sure you loaded the paper correctly (with print side facing you) and selected the appropriate settings in the printer software. For help, see Printing transparencies or Printing photos.
- Choose a higher print quality, such as Better or Best. For help, see **Basic printing**.
- Try Cleaning the print cartridge nozzles.



**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

# Alignment page does not print

#### Make sure:

- You completely removed the transparent tape and sticker from the back and bottom of the print cartridges.
- You installed the cartridges correctly. For help, see Installing a cartridge.
- You loaded the paper correctly and did not push the paper too far into the printer. For help, see Basic printing.
- If you are connected to a network with a Lexmark adapter, the indicator lights are on. For more information, see the adapter documentation.



**Basic printing** 

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

Using this Guide...

This section contains information regarding legal notices.

- Edition notice
- Trademarks
- Warning





**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

# **Edition notice**

**Edition: January 2002** 

The following paragraph does not apply to any country where such provisions are inconsistent with local law: LEXMARK INTERNATIONAL, INC., PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions; therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time.

Comments about this publication may be addressed to Lexmark International, Inc., Department F95/032-2, 740 West New Circle Road, Lexington, Kentucky 40550, U.S.A. In the United Kingdom and Eire, send to Lexmark International Ltd., Marketing and Services Department, Westhorpe House, Westhorpe, Marlow, Bucks SL7 3RQ. Lexmark may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you. You can purchase additional copies of publications related to





Basic printing

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

**Using this** Guide...

this product by calling 1-800-553-9727. In the United Kingdom and Eire, call 0628-481500. In other countries, contact your point of purchase.

References in this publication to products, programs, or services do not imply that the manufacturer intends to make these available in all countries in which it operates. Any reference to a product, program, or service is not intended to state or imply that only that product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any existing intellectual property right may be used instead. Evaluation and verification of operation in conjunction with other products, programs, or services, except those expressly designated by the manufacturer, are the user's responsibility.

© Copyright 2002 Lexmark International, Inc. All rights reserved.

#### UNITED STATES GOVERNMENT RESTRICTED RIGHTS

This software and documentation are provided with RESTRICTED RIGHTS. Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 and in applicable FAR provisions: Lexmark International, Inc., Lexington, KY 40550.



**Basic printing** 

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

Using this Guide...

# **Trademarks**

Lexmark and Lexmark with diamond design are trademarks of Lexmark International, Inc., registered in the United States and/or other countries. Color Jetprinter is a trademark of Lexmark International, Inc.

Other trademarks are the property of their respective owners.





98

Printer overview

**Basic printing** 

Printing ideas

Maintenance

Troubleshooting

**Notices** 

Index

**Using this** Guide...

# Warning

Warning: A warning identifies something that might damage your printer hardware or software.





# Printer overview Basic printing

# Printing ideas

## Maintenance

# Troubleshooting

## **Notices**

#### Index

Using this Guide...

# Α aligning print cartridges 55 automatic cartridge alignment 55 B banding 87 banner paper 47 black cartridge part number 61 blinking lights 74 buttons paper feed 15 power 15 C cable, part numbers **USB 61** cards 27 cartridges, print aligning 55 cleaning 57 installing 52 ordering 61 part numbers 61

preserving 60

```
removing 51
    replacing 51
   wiping 58
characters, misformed 89
cleaning, print cartridge
   nozzles 57
coated paper 21
color cartridge part number 61
conserving color ink 33
contacts, wiping 58
customizing settings
    banners 48
    cards 28
    coated paper 22
   envelopes 31
   foils 45
    glossy paper 22
    greeting cards 28
   handouts 39
   index cards 28
   iron-on transfers 42
   labels 36
   n-up
        See handouts
    photo cards 28
    photo paper 22
    postcards 28
```

```
premium paper 25
printing color images in
black and white 34
transparencies 45
t-shirt transfers 42
```

# dark or smudged print 86 downloaded printer driver, installing 68

## edition notice 95 envelopes 30 error messages Ink Low 73 Paper Jam 73

D

E

```
F
flashing lights 73
foils
See transparencies
```



# **Basic printing**

# Printing ideas

## Maintenance

# Troubleshooting

## **Notices**

### Index

Using this Guide...

## G

glossy paper 21 greeting cards 27

## Н

handouts 38

improving print quality 85 index cards 27 Ink Low message 73 installing print cartridges 52 printer software 67 intermittent printing 87 iron-on transfers 41

## L

labels 35 Lexmark Utility 11 lights paper feed 74 power 74

## loading

banner paper 47 cards 27 coated paper 21 envelopes 30 foils 44 glossy paper 21 greeting cards 27 handouts 38 index cards 27 iron-on transfers 41 labels 35 photo cards 27 photo paper 21 plain paper 17 postcards 27 premium paper 24 transparencies 44 t-shirt transfers 41

## M

manual cartridge alignment 55 margins, minimum settings 88 messages, error Ink Low 73 Paper Jam 73

## N

navigating User's Guide 2
network, setting up printer 70
notices
edition notice 95
trademarks 97
warning 98
nozzles, print
wiping 58
n-up printing
See handouts

## 0

ordering supplies 61

## P

page settings, changing 4
Page Setup dialog 5
paper exit tray 15
paper feed button 15
paper guide 15
Paper Jam message 73
paper jam, clearing 84
paper loading 17
paper misfeeds 81





Printer overview	paper support 15 part numbers black cartridge 61	print nozzles, wiping 58 print quality, troubleshooting 85 printer driver	
Basic printing	color cartridge 61 photo cartridge 61 power supply 61	installing 67 uninstalling 66 printer overview 3	
Printing ideas	USB cable 61 photo cards 27 photo cartridge part number 61	printer overview 3 printer parts 14 printer settings customizing 18	
Maintenance	photo paper 21 postcards 27 power button 15	printer settings, customizing 4 printer software installing 67	
Troubleshooting	power light 15 power supply connector 15	Lexmark Utility 11 overview 4 Page Setup dialog 5	
Notices	premium paper 24 print cartridge aligning 55	Print dialog 6 understanding 4 uninstalling 66	prin
Index	cleaning 57 installing 52 ordering 61 part numbers 61	printer status 76 printing alignment page 55 banners 47	
Using this Guide	preserving 60 removing 51 replacing 51 wiping 58 Print dialog 6	cards 27 color images in black and white 33 envelopes 30 foils 44	

greeting cards 27 handouts 38 index cards 27 iron-on transfers 41 labels 35 multiple pages per sheet 38 n-up See handouts on premium paper 24 photo cards 27 photos 21 test page 65 transparencies 44 t-shirt transfers 41 nting problems blank pages 79 error messages 73 flashing lights 73 general 63 network 70 paper feeding 81 paper jams 84 print quality 85 software 66





# **Basic printing**

# Printing ideas

## Maintenance

# **Troubleshooting**

## **Notices**

#### Index

Using this Guide...

```
specialty paper 92
unsuccessful or slow
printing 75
printing User's Guide 2
```

## R

removing print cartridges 51 replacing the print cartridge 51

searching User's Guide 2

# S

```
setting recommendations
banner paper 48
cards 28
coated paper 22
color images in black and
white 34
envelopes 31
foils 45
glossy paper 22
greeting cards 28
handouts 39
index cards 28
iron-on transfers 42
labels 36
```

```
n-up
        See handouts
    photo cards 28
    photo paper 22
    postcards 28
    premium paper 25
    print color images in black
       and white 34
    transparencies 45
    t-shirt transfers 42
software, printer
    installing 67
    Lexmark Utility 11
    understanding 4
    uninstalling 66
specialty paper
    solving problems with 92
supplies, ordering 61
```

## Т

```
test page
does not print 78
printing 65
trademarks 97
transfers, iron-on 41
transparencies 44
```

```
troubleshooting
    alignment page 93
    blank pages 79
    error messages 73
    flashing lights 73
    general printing
       problems 63
    improving print quality 85
    margins 88
    network printing 70
    paper feeding 81
    paper jams 84
    paper misfeeds 81
    print quality 85
    printer not printing 75
    printer software
       installation 66
    software 66
    specialty paper 92
    unsuccessful or slow
       printing 75
```





**Basic printing** 

Printing ideas

Maintenance

**Troubleshooting** 

**Notices** 

Index

Using this Guide...

## U

uninstalling printer software 66
USB cable
 connector 15
 ordering 61
User's Guide
 navigating 2
 printing 2
 searching 2
Utility, Lexmark 11

## W

warning 98



