Lexmark[™] C752 Clearing Jams Guide

Avoiding jams

The following hints can help you avoid paper jams:

- Use only recommended paper. Refer to the Card Stock & Label Guide available on the Lexmark Web site at www.lexmark.com/ publications for more information about which paper provides optimum results for your printing environment.
- Do not remove paper trays while a job is printing. Wait for a Load Tray <x> or Ready message before you remove the tray.
- If you need detailed information before purchasing large quantities of customized paper, refer to the *Card Stock & Label Guide*.
- Do not load wrinkled, creased, or damp paper.
- Never mix media types within a tray.
- Flex, fan, and straighten paper before you load it.
- Do not overload the trays or the multipurpose feeder. Make sure the stack height does not exceed the maximum height indicated.
- Push all trays firmly into the printer after loading them.
- Make sure the guides in the trays are properly positioned for the size paper you have loaded.
- Do not send jobs to staple, hole punch, or offset for transparencies, labels, or card stock.
- We recommend that transparencies, labels, card stock, and envelopes not be sent to the optional mailbox or optional finisher. These specialty media types should be sent to the standard bin.
- If a jam should occur, clear the entire paper path.

Clearing jams

Understanding jam messages


Message	What to do
200 Paper Jam	Clear Area B and Area T1.
201 Paper Jam	Clear Area D, Area K, and Area L.
202 Paper Jam	Clear Area K and Area L.
230 Paper Jam	Clear Area E and Area J.
24 <x> Paper Jam</x>	Clear Area B, Area C, and Area T <x>.</x>
250 Paper Jam	Clear Area A and Area D.
27 <x> Paper Jam</x>	Clear Area M.

Area A

1 Release the levers on each side of the multipurpose feeder to lay it flat.




2 Press the pick assembly release lever, and remove all media and jams.



3 Return the feeder to its working position, and reload your paper.

Area B

1 Open the left access door until it clicks into place.



- **2** Remove all visible paper. Remove any torn paper from the printer.
- **3** Close the door.
- 4 Open Tray 1, and make sure the entire paper stack is pushed all the way down into the tray.

Area C


1 Open the 500-sheet drawer access door. Hold the door down while removing jams.



2 Make sure the entire paper stack is loaded correctly, and then close the door.

Area D

- 1 Open the front access door.
- **2** Hold down the front access door. Remove jams in the rollers under the image transfer unit.



Area T1

- **1** Open tray 1.
- 2 Remove any jams.
- **3** Make sure the paper is pushed all the way down into the tray, and then close tray 1.

Area E

1 Pull the duplex tray E completely out. Remove any paper caught in the rollers or inside the printer.



2 Reinstall the duplex mechanism in the printer.

Area T<x>

- **1** Carefully open trays 2 through 4 (all 500-sheet trays), and then remove jams.
- 2 Make sure the paper is pushed all the way down into the tray, and then close trays 2 through 4.

Area J

1 Remove the duplex tray J.



2 Remove any jams, and then reinstall the tray.

Area K


1 Open the lower right access door.



2 Remove any jams, and then close the door.

Area L

1 Open the upper right access door.



2 Remove jams from the rollers, and then close the door.

Clearing mailbox, finisher, or output expander jams (Area M)


1 Open the rear door of the 5-bin mailbox or output expander.



2 Pull the jam straight out, and then close the door.


Clearing fuser jams

- **1** Clear the paper path. If the jam error message persists, go to step 2.
- **2** Open both the upper right and the lower right access doors (Areas K and L).




CAUTION: The fuser assembly may be hot. Let it cool before continuing.


3 Pull down the latches. They slide toward the center to release the fuser.



- **4** Pull the fuser out, and set it on a clean, flat surface.
- **5** Unsnap the housing and set it aside.




6 Lift up the fuser roller cover and remove the jam.



- **7** Close the fuser roller cover.
- 8 Snap the housing back onto the fuser.
- **9** Insert the fuser back into the printer.
- **10** Slide the latches out, and then pull up to refasten them.
- 11 Close the doors.

Clearing image transfer unit jams

1 Open the front access door and the left access door.




2 While holding down the front access door, insert a folded piece of paper as shown to clear the paper sensors under the image transfer unit. Make sure to clear the entire width of the paper path.




3 Close the left access door and the front access door. If the jam persists, continue with step Turn the printer off. Open the front cover..


4 Turn the printer off. Open the front cover.




- **5** Remove all the print cartridges.
 - a Pull up slightly on the cartridge handhold.
 - **b** Pull the cartridge straight out and use the handle to lift it off the guides.
 - **c** Place the cartridges on a clean, flat surface out of direct light.




6 Release the latches to open the multipurpose feeder (area A) all the way.



- **7** Remove the image transfer unit.
 - **a** Raise the lever to unlock the image transfer unit.




b Pull down on the handle.




c Slide the image transfer unit out and place it on a clean, flat surface.

Warning: Do not touch the transfer belt.

Touching the belt will damage the image transfer unit.




8 Look inside the printer. Remove all torn paper or other jams.




9 Insert the image transfer unit back into the printer.


a Align the guides with the insertion grooves and gently slide the unit in.



b Rotate the handle up, and push gently to lock the unit in place.




c Lower the lever to lock the image transfer unit into place.



10 Return the multipurpose feeder to its working position.

Reinstall all the print cartridges.



- **11** Close the printer door.
- **12** Turn the printer on. The printer returns to a Ready state.

If you still need help

- 1 Turn the printer off and then back on.
- **2** Contact your administrator or Help desk if you need more assistance.