



# Printer, Option, and Stand Compatibility Guide

---

## Laser Printers

## **Edition notice**

January 2012

**The following paragraph does not apply to any country where such provisions are inconsistent with local law:** LEXMARK INTERNATIONAL, INC., PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions; therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time.

References in this publication to products, programs, or services do not imply that the manufacturer intends to make these available in all countries in which it operates. Any reference to a product, program, or service is not intended to state or imply that only that product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any existing intellectual property right may be used instead. Evaluation and verification of operation in conjunction with other products, programs, or services, except those expressly designated by the manufacturer, are the user's responsibility.

For Lexmark technical support, visit <http://support.lexmark.com>.

For information on supplies and downloads, visit [www.lexmark.com](http://www.lexmark.com).

If you don't have access to the Internet, you can contact Lexmark by mail:

Lexmark International, Inc.  
Bldg 004-2/CSC  
740 New Circle Road NW  
Lexington, KY 40550  
USA

© 2011 Lexmark International, Inc.

**All rights reserved.**

## **Trademarks**

Lexmark and Lexmark with diamond design are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

All other trademarks are the property of their respective owners.

## **UNITED STATES GOVERNMENT RIGHTS**

This software and any accompanying documentation provided under this agreement are commercial computer software and documentation developed exclusively at private expense.

# Contents

- Edition notice.....2**
- Introduction.....5**
  - Understanding this guide.....5
- Supported maximum configurations.....6**
  - Lexmark C546dtn and X546dtn with desktop or swivel cabinet.....6
  - Lexmark C73x.....7
  - Lexmark C792.....8
  - Lexmark C925.....10
  - Lexmark C950.....11
  - Lexmark T65x with caster base 39V3588.....15
  - Lexmark X792.....17
  - Lexmark X925.....19
  - Lexmark X95x.....21
  - Lexmark X65x.....25
    - Lexmark X651e, X652e, X654e, and X656e with caster base 16M1216 .....25
    - Lexmark X651, X652, X654, and X656 MFPs with desktop and swivel cabinet.....26
    - Lexmark X658e .....27
  - Lexmark X73x.....28
    - Lexmark X73x with caster base 16M1210 .....28
    - Lexmark X73x with desktop and swivel cabinet .....29
  - Caster base 10G0080.....30
    - Caster base 10G0080 with scanner.....30
    - Caster base 10G0080 without scanner .....31
  - Caster base 22G0544.....32
    - Caster base 22G0544 for MFPs .....32
    - Caster base 22G0544 with scanner.....33
    - Caster base 22G0544 with scanner and shelf 21J0050 .....34
    - Caster base 22G0544 without scanner .....34
  - Desktop.....35
  - Furniture stand 16C0389.....36
  - Furniture stand 16C0369 and 16C0379.....37
  - Printer stand 16N1708.....39
    - Printer stand 16N1708 with or without scanner shelf 10B1755.....39
    - Printer stand 16N1708 with or without scanner shelf 21J0055.....39
  - Scanner shelf.....40

**Swivel cabinet 3052765.....41**

**Index.....43**

# Introduction

## Understanding this guide

The following sample table provides information on how to read the tables found in this guide:

**Supported printers:** T630, T630n, T632, T632n, T634, and T634n—*This section identifies the printers supported by this furniture or option.*

**Supported scanners:** 3100, 3200, and X4500—*This section identifies the scanners supported by this furniture or option.*

Printer configuration	Option	Duplex unit	250-sheet drawers				Optional 500-sheet drawers				Optional 2,000-sheet drawer
			1	2	3	4	1	2	3	4	
A	✓	✓	✓	✓	✓	✓					
B	✓	✓	✓	✓	✓		✓				
C	✓	✓	✓	✓			✓	✓			
D	✓	✓	✓				✓	✓	✓		
E	✓						✓	✓	✓	✓	
F	✓		✓				✓				✓
G	✓	✓									✓

Each row represents a supported maximum configuration. If an option is removed from a particular row, then the information would still indicate an acceptable configuration.

For example, in the printer configuration B, the supported configuration shows that:

- A printer with a duplex unit, one option, three 250-sheet drawers, and one 500-sheet drawer is one of the maximum configurations possible on this particular furniture.
- The configuration is acceptable with the removal of one or more of the options (scanner, duplex unit, 250-sheet drawer, or 500-sheet drawer).
- The configuration is not acceptable with any additional options listed in the chart.

## Supported maximum configurations

The following tables provide information about the maximum possible configurations for each printer, option, and furniture stand.

### Lexmark C546dtn and X546dtn with desktop or swivel cabinet



**Supported printer:** C546dtn

**Supported MFP:** X546dtn

The printers can support one optional tray with *part number 3051710* with this configuration.

## Lexmark C73x

Lexmark C73x with caster base:



Swivel cabinet 3052765:



**Supported printers:** C734 and C736

Placement	Optional caster base 39V3425	Optional 550-sheet drawers or 4.8-inch spacers				Optional 2,000-sheet drawer
		1	2	3	4	
Floor	✓	✓	✓	✓		✓
		✓	✓	✓	✓	
Floor	✓*					✓
		✓	✓	✓		

\* An optional caster base may be used, but is not required for a safe operation.

Placement	Optional caster base 39V3425	Optional 550-sheet drawers or 4.8-inch spacers				Optional 2,000-sheet drawer
		1	2	3	4	
Desktop or swivel cabinet		✓	✓	✓		✓
		✓	✓	✓	✓	

\* An optional caster base may be used, but is not required for a safe operation.

## Lexmark C792

Base printer:



Lexmark C792 with extra drawers and caster base:



**Supported printer: C792**

Placement	Optional caster base	Optional 550-sheet drawers				Optional 2000-sheet drawer	Optional output option
		1	2	3	4	1	1
Desktop <sup>1</sup>		✓	✓	✓		✓	✓
		✓	✓	✓	✓		✓
Floor	✓	✓	✓	✓			✓
		✓				✓	✓
Floor	✓ <sup>2</sup>	✓	✓				✓

**Notes:**

- <sup>1</sup> The maximum recommended height is 1.3 m (51.18 in.).
- <sup>2</sup> May be used but not required for safe operation

## Lexmark C925

Lexmark C925 with extra drawers:



Lexmark C925 with extra drawers and printer stand converted to caster base 24Z0031:



Printer stand 39V4339:



**Supported printer: C925**

Placement	Printer stand 24Z0031	Printer stand converted to caster base 24Z0031	Optional 550-sheet drawers		
			1	2	3
Desktop			✓		
Floor		✓	✓		
			✓	✓	
			✓	✓	✓
Floor	✓		✓		

## Lexmark C950

Lexmark C950 with tandem-tray module, high-capacity feeder, and booklet finisher:



Optional three-tray module:



Optional one-tray module:



Optional finisher:



**Supported printer model:** C950de

Placement	One-tray module	Three-tray module	Tandem-tray module	Optional high-capacity feeder	Optional booklet finisher	Optional finisher
Floor	✓					
	✓			✓		
	✓				✓	
	✓					✓
	✓			✓	✓	
	✓			✓		✓
		✓				
		✓		✓		
		✓			✓	
		✓				✓
		✓		✓	✓	
		✓		✓		✓
				✓		
				✓	✓	
				✓		✓
				✓	✓	✓
				✓		✓

## Lexmark T65x with caster base 39V3588

Lexmark T65x with caster base:



**Supported printers:** T650, T652, T654, and T656

Printer models	Placement	Optional 2,000-sheet drawer	Duplex Unit	Optional 250-sheet drawers				Optional 550-sheet drawers or 5.1-inch spacers				Optional caster base 39V3588
				1	2	3	4	1	2	3	4	
T650, T652, T654, T656	Desktop or swivel cabinet		Yes <sup>2</sup> or No <sup>1</sup>	✓	✓	✓	✓					✓
				✓	✓	✓		✓				
				✓	✓			✓	✓			
				✓				✓	✓	✓		
								✓	✓	✓	✓	

<sup>1</sup> The optional duplex unit is available only on Lexmark T650n. <sup>2</sup>An internal duplex unit is a standard feature on the Lexmark T652dn, T654dn, and T656.

<sup>3</sup> An optional caster base may be used, but is not required for a safe operation.

Printer models	Placement	Optional 2,000-sheet drawer	Duplex Unit	Optional 250-sheet drawers				Optional 550-sheet drawers or 5.1-inch spacers				Optional caster base 39V3588
				1	2	3	4	1	2	3	4	
T650	Floor		Yes <sup>1</sup>	✓	✓	✓						✓ <sup>3</sup>
				✓				✓				
								✓	✓			
			No <sup>1</sup>	✓	✓	✓	✓					
				✓	✓			✓				
								✓	✓			
T652, T654, T656	Floor		Included <sup>1</sup>	✓	✓	✓					✓ <sup>3</sup>	
				✓	✓			✓				
								✓	✓			
T650, T652, T654, T656	Floor		Yes <sup>2</sup> or No <sup>1</sup>	✓	✓	✓	✓					✓
				✓	✓	✓		✓				
				✓	✓			✓	✓			
				✓				✓	✓	✓		
								✓	✓	✓	✓	
		✓	✓	✓								
		✓	✓			✓						
		✓				✓	✓					
						✓	✓	✓				
		✓										

<sup>1</sup> The optional duplex unit is available only on Lexmark T650n. <sup>2</sup>An internal duplex unit is a standard feature on the Lexmark T652dn, T654dn, and T656.

<sup>3</sup> An optional caster base may be used, but is not required for a safe operation.

## Lexmark X792

Lexmark X792 with extra drawer



Lexmark X792 with extra drawer and caster base

**Supported printer: X792**

Placement	Optional caster base	Optional 550-sheet drawers				Optional 2000-sheet drawer	Optional output option
		1	2	3	4	1	1
Desktop <sup>3</sup>		✓	✓			✓	✓
		✓	✓	✓	✓		✓
Floor	✓ <sub>1</sub>	✓	✓	✓			✓
		✓	✓	✓	✓		✓ <sub>1</sub>
						✓	✓
		✓				✓	✓ <sub>1</sub>

Placement	Optional caster base	Optional 550-sheet drawers				Optional 2000-sheet drawer	Optional output option
		1	2	3	4	1	1
Floor	√ <sup>2</sup>	√					√
		√	√				√ <sup>1</sup>
<b>Notes:</b> <ul style="list-style-type: none"> <li><sup>1</sup> Required</li> <li><sup>2</sup> May be used but not required for safe operation</li> <li><sup>3</sup> The maximum recommended height is 1.3 m (51.18 in.).</li> </ul>							

## Lexmark X925

Lexmark X925 with extra drawers and printer stand converted to caster base 24Z0031:



Printer stand 24Z0031:



**Supported printer: X925**

Placement	Printer stand 24Z0031	Printer stand converted to caster base 24Z0031	Optional 550-sheet drawers		
			1	2	3
Desktop			✓		
Floor		✓	✓		
			✓	✓	
			✓	✓	✓
Floor	✓		✓		

## Lexmark X95x

Lexmark X950de with tandem-tray module, high-capacity feeder, and booklet finisher:



Optional three-tray module:



Optional one-tray module:



Optional finisher:



**Supported printer model:** X950de

Placement	One-tray module	Three-tray module	Tandem-tray module	Optional high-capacity feeder	Optional booklet finisher	Optional finisher
Floor	✓					
	✓			✓		
	✓				✓	
	✓					✓
	✓			✓	✓	
	✓			✓		✓
		✓				
		✓		✓		
		✓			✓	
		✓				✓
		✓		✓	✓	
		✓		✓		✓
				✓		
				✓	✓	
				✓		✓
				✓	✓	✓

**Supported printer models: X952dte and X954dhe**

Placement	Optional high-capacity feeder	Optional booklet finisher	Optional finisher
Floor	✓		
		✓	
			✓
	✓	✓	
	✓		✓

## Lexmark X65x

### Lexmark X651e, X652e, X654e, and X656e with caster base 16M1216



**Supported printers:** X651e, X652e, X654e, and X656e

Printer configuration	Optional 250-sheet drawers				Optional 500-sheet drawers or 5.1-inch spacers			Optional 2,000-sheet drawer
	1	2	3	4	1	2	3	
A	✓	✓	✓	✓				
B	✓	✓	✓		✓			
C	✓	✓			✓	✓		
D					✓	✓	✓	
E	✓							✓
F					✓			✓

**Notes:**

- The spacer must be under the 250- and 500-sheet drawers and cannot be used with the 2,000-sheet drawer.
- The optional 2,000-sheet drawer must be installed under any of the other drawers.
- At least one input drawer or spacer is required with this caster base.

## Lexmark X651, X652, X654, and X656 MFPs with desktop and swivel cabinet



Swivel cabinet 3052765:



**Supported MFPs:** X651e, X652e, X654e, and X656e

Printer configuration	Optional 250-sheet drawers				Optional 550-sheet drawers or 5.1-inch spacers		
	1	2	3	4	1	2	3
A	✓	✓	✓	✓			
B	✓	✓	✓		✓		

Printer configuration	Optional 250-sheet drawers				Optional 550-sheet drawers or 5.1-inch spacers		
	1	2	3	4	1	2	3
C	✓				✓	✓	
D					✓	✓	✓

**Note:** Make sure the total height of the selected configuration suits for your office environment.

## Lexmark X658e



**Supported printer:** Lexmark X658e

A maximum of four 550-sheet drawers are supported. Since one of the 550-sheet drawers is part of the base unit, only up to three additional optional drawers are allowed when configuring the printer.

**Note:** The caster base is standard.

## Lexmark X73x

### Lexmark X73x with caster base 16M1210



**Supported printers:** X734de, X736de, and X738de

Printer configuration	Optional 550-sheet drawers or 4.8-inch spacers			Optional 2,000-sheet drawer
	1	2	3	
A	✓	✓	✓	
B	✓			✓

- The spacers can be installed under the optional 550-sheet drawers and cannot be used with the 2,000-sheet drawer.
- The optional 2,000-sheet drawer can be installed under any other drawers.
- At least one input drawer or spacer is required with this caster base.

## Lexmark X73x with desktop and swivel cabinet

### Floor standing



Swivel cabinet 3052765



**Supported MFPs:** X734de, X736de, and X738de

Printer configuration	Placement	Optional 550-sheet drawers or 4.8-inch spacers				Optional 2,000-sheet drawer
		1	2	3	4	
A	Desktop or swivel cabinet	✓	✓	✓	✓	
B	Desktop or swivel cabinet	✓	✓	✓		✓
C	Floor	✓				

**Note:** Make sure the total height of the selected configuration suits your office environment.

## Caster base 10G0080

### Caster base 10G0080 with scanner



**Supported printers:** T630, T630n, T632, T632n, T634, and T634n

**Supported MFPs:** X630, X632, X632e, X632s, and X634e

**Supported scanners:** 3100, 3200, and X4500

Printer configuration	MFP option	Duplex unit	Optional 250-sheet drawers				Optional 500-sheet drawers			Optional 2,000-sheet drawer
			1	2	3	4	1	2	3	
A	✓	✓	✓	✓	✓	✓				
B	✓	✓	✓	✓	✓		✓			
C	✓	✓	✓				✓	✓		
D	✓		✓	✓			✓	✓		
E	✓	✓					✓	✓	✓	
F	✓	✓								✓

- If an optional duplex unit is installed, then:
  - The duplex unit must always be installed directly under the printer.
  - All paper-handling options must be installed below the duplex unit.
- The optional 2,000-sheet drawer must be at the bottom of the stack of drawers.
- At least one optional input drawer is required with this caster base.

## Caster base 10G0080 without scanner



**Supported printers:** T630, T630n, T632, T632n, T634, T634n, T640, T640n, T642, T642n, T644, and T644n

Printer configuration	Duplex unit	Optional 250-sheet drawers				Optional 500-sheet drawers				Optional 2,000-sheet drawer
		1	2	3	4	1	2	3	4	
A	✓	✓	✓	✓	✓					
B	✓	✓	✓	✓		✓				
C	✓	✓	✓			✓	✓			
D	✓	✓				✓	✓	✓		
E	✓					✓	✓	✓	✓	
F	✓	✓	✓	✓						✓
G	✓	✓				✓				✓
H	✓					✓	✓			✓

- If an optional duplex unit is installed, then:
  - The duplex unit must always be installed directly under the printer.
  - All paper-handling options must be installed below the duplex unit.
- The optional 2,000-sheet drawer must be at the bottom of the stack of drawers.
- At least one optional input drawer is required with this caster base.

## Caster base 22G0544

### Caster base 22G0544 for MFPs



**Supported MFPs:** X646e, X644e, and X642e

Printer configuration	Duplex unit	Optional 250-sheet drawers				Optional 500-sheet drawers				Optional 10-inch cabinet	Optional 2,000-sheet drawer
		1	2	3	4	1	2	3	4		
A	✓	✓	✓	✓	✓						
B	✓	✓	✓	✓		✓					
C	✓	✓	✓			✓	✓				
D	✓	✓				✓	✓	✓			
E	✓					✓	✓	✓	✓		
F	✓	✓	✓							✓	
G	✓					✓	✓			✓	
H	✓	✓								✓	
I	✓	✓									✓
J	✓					✓					✓

- If an optional duplex unit is installed, then:
  - The duplex unit must always be installed directly under the printer.
  - All paper-handling options must be installed below the duplex unit.
- The optional 2,000-sheet drawer must be at the bottom of the stack of drawers.
- The optional 10-inch cabinet must be at the bottom of the stack of drawers.
- At least one input drawer or optional 10-inch cabinet is required with this caster base.

## Caster base 22G0544 with scanner



**Supported printers:** T630, T630n, T632, T632n, T634, and T634n

**Supported MFPs:** X630, X632, X632e, X632s, and X634e

**Supported scanners:** 3100, 3200, and X4500

Printer configuration	MFP option	Duplex unit	Optional 250-sheet drawers				Optional 500-sheet drawers			Optional 2,000-sheet drawer
			1	2	3	4	1	2	3	
A	✓	✓	✓	✓	✓	✓				
B	✓	✓	✓	✓	✓		✓			
C	✓	✓	✓				✓	✓		
D	✓		✓	✓			✓	✓		
E	✓	✓	✓				✓	✓	✓	
F	✓	✓	✓							✓

- If an optional duplex unit is installed, then:
  - The duplex unit must always be directly under the printer.
  - All paper-handling options must be installed below the duplex unit.
- The optional 2,000-sheet drawer must be at the bottom of the stack of drawers.
- At least one optional input drawer is required with this caster base.

## Caster base 22G0544 with scanner and shelf 21J0050



**Supported printers:** T642, T642n, T644, and T644

**Supported scanner:** 4600

Printer configuration	MFP option	Duplex unit	Optional 250-sheet drawers				Optional 500-sheet drawers			Optional 10-inch cabinet	Optional 2,000-sheet drawer
			1	2	3	4	1	2	3		
A	✓	✓	✓	✓	✓	✓					
B	✓	✓	✓	✓	✓		✓				
C	✓	✓	✓				✓	✓			
D	✓	✓	✓	✓			✓	✓			
E	✓	✓					✓	✓	✓		
F	✓	✓									✓
G	✓	✓					✓			✓	

- If an optional duplex unit is installed, then:
  - The duplex unit must always be installed directly under the printer.
  - All paper-handling options must be installed below the duplex unit.
- The optional 2,000-sheet drawer must be at the bottom of the stack of drawers.
- The optional 10-inch cabinet must be at the bottom of the stack of drawers.
- At least one input drawer or optional 10-inch cabinet is required with this caster base.

## Caster base 22G0544 without scanner



**Supported printers:** T630, T630n, T632, T632n, T634, T634n, T640, T640n, T642, T642n, T644, and T644n

Printer configuration	Duplex unit	Optional 250-sheet drawers				Optional 500-sheet drawers				Optional 2,000-sheet drawer
		1	2	3	4	1	2	3	4	
A	✓	✓	✓	✓	✓					
B	✓	✓	✓	✓		✓				
C	✓	✓	✓			✓	✓			
D	✓	✓				✓	✓	✓		
E	✓					✓	✓	✓	✓	
F	✓	✓	✓	✓		✓	✓	✓	✓	✓
G	✓	✓				✓				✓
H	✓					✓	✓			

- If an optional duplex unit is installed, then:
  - The duplex unit must always be installed directly under the printer.
  - All paper-handling options must be installed below the duplex unit.
- The optional 2,000-sheet drawer unit must be at the bottom of the stack of drawers.
- At least one optional input drawer is required with this caster base.

## Desktop



**Supported printers:** T630, T630n, T632, T632n, T634, T634n, T640, T640n, T642, T642n, T644, and T644n

**Supported MFPs:** X630, X632, X632e, X632s, X634e, X644e, X646e, and X642e

**Supported scanners:** 3100, 3200, and X4500

MFP or MFP option configuration	MFP option	Duplex unit	Optional 250-sheet drawers				Optional 500-sheet drawers			Optional 2,000-sheet drawer
			1	2	3	4	1	2	3	
A	✓	✓	✓							
B	✓		✓	✓						
C	✓	✓					✓			
D	✓		✓				✓			
E		✓	✓	✓	✓					
F			✓	✓	✓	✓				
G		✓	✓	✓			✓			
H			✓	✓	✓		✓			
I		✓					✓	✓		
J			✓				✓	✓		
K							✓	✓	✓	
L		✓								✓

- Make sure the total height of the selected configuration suits to your office environment.
- If an optional duplex unit is installed, then:
  - The duplex unit must always be installed directly under the printer.
  - All paper-handling options must be installed below the duplex unit.

## Furniture stand 16C0389



**Supported printers:** T630, T630n, T632, T632n, T634, T634n, T640, T640n, T642, T642n, T644, and T644n

**Supported MFPs:** X630, X632, X632e, X632s, X634e, X644e, X646e, and X642e

**Supported scanners:** 3100, 3200, X4500, and 4600

Printer configuration	MFP option	Duplex unit	Optional 250-sheet drawers				Optional 500-sheet drawers				Optional 2,000-sheet drawer
			1	2	3	4	1	2	3	4	
A	✓	✓	✓	✓	✓	✓					
B	✓	✓	✓	✓	✓		✓				
C	✓	✓	✓	✓			✓	✓			
D	✓	✓	✓				✓	✓	✓		
E	✓	✓					✓	✓	✓	✓	
F	✓	✓	✓	✓	✓						✓
G	✓	✓	✓	✓			✓				✓
H	✓	✓	✓				✓	✓			✓
I	✓	✓					✓	✓	✓		✓

- The bottom of the printer should not reside more than 1.5 inches above the top surface of the printer furniture side shelves after installation.
- If an optional duplex unit is installed, then:
  - The bottom of the optional duplex unit should not reside more than 1.5 inches above the top surface of the printer furniture's side shelves after installation.
  - The duplex unit must always be installed directly under the printer.
  - All paper-handling options must be installed below the duplex unit.
- The optional 2,000-sheet drawer must be at the bottom of the stack of drawers.



**CAUTION—TIPPING HAZARD:** Stability tabs that came with the furniture must be installed to meet safety requirements.

## Furniture stand 16C0369 and 16C0379

Furniture stand 16C0369:



Furniture stand 16C0379:



**Supported printers:** T630, T630n, T632, T632n, T634, T634n, T640, T640n, T642, T642n, T644, and T644n

**Supported MFPs:** X630, X632, X632e, X632s, X634e, X646e, X644e, and X642e

**Supported scanners:** 3100, 3200, X4500, and 4600

Printer configuration	MFP option	Duplex unit	Optional 250-sheet drawers				Optional 500-sheet drawers				Optional 2,000-sheet drawer
			1	2	3	4	1	2	3	4	
A	✓	✓	✓	✓	✓	✓					
B	✓	✓	✓	✓	✓		✓				
C	✓	✓	✓	✓			✓	✓			
D	✓	✓	✓				✓	✓	✓		
E	✓	✓					✓	✓	✓	✓	
F	✓	✓	✓	✓							✓
G	✓	✓					✓				✓

- The bottom of the printer should not reside more than 1.5 inches above the top surface of the printer furniture side shelves after installation.
- If an optional duplex unit is installed, then:
  - The bottom of the optional duplex unit should not reside more than 1.5 inches above the top surface of the printer furniture side shelves after installation.
  - The duplex unit must always be installed directly under the printer.
  - All paper-handling options must be installed below the duplex unit.
- The optional 2,000-sheet drawer must be at the bottom of the stack of drawers.

## Printer stand 16N1708

### Printer stand 16N1708 with or without scanner shelf 10B1755



**Supported printers:** C760 and C762

**Supported MFP:** X762e

**Supported scanner:** X4500

Printer configuration	MFP option	Duplex unit	Optional 500-sheet drawers		
			1	2	3
A	✓	✓	✓		
B	✓		✓	✓	
C		✓	✓	✓	✓

- If an optional duplex unit is installed, then:
  - The duplex unit must always be installed directly under the printer.
  - All paper-handling options must be installed under the duplex unit.
  - A printer without MFP option can also support a maximum combination of one optional 2,000-sheet drawer and one optional 500-sheet drawer without a printer stand.
  - An optional 500-sheet drawer is required when using a 2,000-sheet drawer and duplex unit configuration.

### Printer stand 16N1708 with or without scanner shelf 21J0055



**Supported printers:** C772 and C782

**Supported MFPs:** X772e and X782e

**Supported scanner:** 4600

Printer configuration	MFP option	Duplex unit	Optional 500-sheet drawers		
			1	2	3
A	✓	✓	✓	✓	
B	✓	x	✓	✓	
C	x	✓	✓	✓	✓

- If an optional duplex unit is installed, then:
  - The duplex unit must be directly under the printer for any of the listed configurations.
  - All paper-handling options must be installed under the duplex unit.
- A printer without MFP option can also support a maximum combination of one optional 2,000-sheet drawer and one optional 500-sheet drawer without a printer stand. An optional 500-sheet drawer, as the first option under the duplex unit, is required when using a 2,000-sheet drawer and duplex unit configuration.

## Scanner shelf

Use the following shelves to place an MFP option on top of a supported mono printer:

Scanner shelf part number	Supported MFP option	Supported printer
16A0503	X242 X443	T5XX T61X T62X
	3100 3200	T63X
	X630 X632 X632s	
10G1000	X4500	T632 T634
	X632e* X634e*	
21J0050	4600	T642n T644n
* The scanner shelf is already included.		

**Notes:**

- If an MFP option and scanner shelf are installed, then no output options are allowed in the configuration.
- If an MFP option and scanner shelf are not installed, then all output options are supported.
- Scanner shelves must be attached directly to the printer.

**Swivel cabinet 3052765**

For more information, see the supported configurations for each printer:

- “Lexmark T65x with caster base 39V3588” on page 15
- “Lexmark X651, X652, X654, and X656 MFPs with desktop and swivel cabinet” on page 26
- “Lexmark C73x” on page 7

- “Lexmark X73x with desktop and swivel cabinet” on page 29
- “Lexmark X651, X652, X654, and X656 MFPs with desktop and swivel cabinet” on page 26

# Index

## Numerics

10B1755, part number 39  
 10G0080, part number 31  
   with scanner 30  
 10G1000, part number 40  
 16A0503, part number 40  
 16C0369, part number 37  
 16C0379, part number 37  
 16C0389, part number 36  
 16M1216, part number 25  
 16N1708, part number 39  
 21J0050, part number 34, 40  
 21J0055, part number 39  
 22G0544, part number 32  
   caster base 34  
   caster base with scanner 34  
   with scanner, without shelf 33  
 24Z0031, part number 10, 19  
 3051710, part number 6  
 3052765, part number 7, 26, 41  
 39V3588, part number 15

## C

caster base  
   part number 10G0080 30, 31  
   part number 16M1216 25  
   part number 22G0544 32, 33, 34  
   part number 39V3588 15

## D

desktop 35

## F

furniture stand  
   part number 16C0369 37  
   part number 16C0379 37  
   part number 16C0389 36

## G

guide, understanding 5

## H

how to use the guide 5

## L

Lexmark C546dtn 6

Lexmark C73x 7  
 Lexmark C760 39  
 Lexmark C762 39  
 Lexmark C772 39  
 Lexmark C782 39  
 Lexmark C925 10  
 Lexmark T65x 15  
 Lexmark X546dtn 6  
 Lexmark X651, X652, X654, and  
 X656 26  
 Lexmark X658e 27  
 Lexmark X762e 39  
 Lexmark X772e 39  
 Lexmark X782e 39  
 Lexmark X925 19

## N

notices 2

## O

optional tray  
   part number 3051710 6

## P

printer  
   Lexmark C546dtn 6  
   Lexmark C73x 7  
   Lexmark C760 39  
   Lexmark C762 39  
   Lexmark C772 39  
   Lexmark C925 10  
   Lexmark T65x 15  
   Lexmark X546dtn 6  
   Lexmark X651, X652, X654, and  
   X656 26  
   Lexmark X658e 27  
   Lexmark X762e 39  
   Lexmark X772e 39  
   Lexmark X782e 39  
   Lexmark X925 19  
 printer stand  
   part number 16N1708 39  
   part number 24Z0031 10, 19  
 printers  
   Lexmark C782 39

## S

scanner shelf  
   part number 10B1755 39  
   part number 10G1000 40  
   part number 16A0503 40  
   part number 21J0050 34, 40  
   part number 21J0055 39  
 swivel cabinet  
   part number 3052765 26, 41  
   part number 3052765 7

## T

tables, understanding 5