

# Information guide

## Help menu

The Help menu consists of a series of Help pages that are stored in the printer as PDFs. They contain information about using the printer and performing printing tasks.

English, French, German, and Spanish translations are stored in the printer. Other translations are available at <http://support.lexmark.com>.

Menu item	Description
Print All Guides	Prints all the guides
Media Guide	Provides a list of the paper sizes supported in trays and feeders
Menu Map	Provides a list of the printer control panel menus and settings
Printing Guide	Provides information about loading paper and other specialty media
Color Quality Guide	Provides information about solving color quality issues
Print Quality	Provides information about solving print quality issues
Supplies Guide	Provides part numbers for ordering supplies
Moving Guide	Provides instructions for safely moving the printer
Connection Guide	Provides information about connecting the printer locally (USB) or to a network
Print Defects Guide	Provides information about resolving print defects

## Setup sheet

The *Setup* sheet that comes with the printer provides information about setting up the printer.

## Software and Documentation CD

The *Software and Documentation* CD that comes with the printer includes a *User's Guide*. The *User's Guide* provides information about loading paper, printing, ordering supplies, troubleshooting, clearing jams, maintaining the printer, customizing the home screen, and using solutions.

For updates, check our Web site at <http://support.lexmark.com>.

## Home screen customization and using solutions

For information about customizing your home screen and using solutions, see the "Setting up and using the home screen applications" section in the *User's Guide*.

## Additional language support

The *User's Guide*, *Quick Reference*, and *Networking Guide* are available in other languages on the *Software and Documentation* CD.