

# Menu Map

## Menus list

### Paper Menu

Default Source  
Paper Size/Type  
Configure MP  
Substitute Size  
Paper Texture  
Paper Weight  
Paper Loading  
Custom Types  
Universal Setup

### Security

Confidential Print  
Security Audit Log  
Set Date and Time

### Reports

Menu Settings Page  
Device Statistics  
Network Setup Page<sup>1</sup>  
Print Fonts  
Print Directory  
Print Demo  
Asset Report  
Event Log Summary

### Settings

General Settings  
Print Settings

### Network/Ports

Active NIC  
Standard Network<sup>2</sup>  
Standard USB  
Standard Parallel  
SMTP Setup


### Help

Print All Guides  
Print Quality  
Printing Guide  
Media Guide  
Print Defects Guide  
Menu Map  
Information Guide  
Connection Guide  
Moving Guide  
Supplies Guide

<sup>1</sup> Depending on the printer setup, this menu item appears as Network Setup Page or Network [x] Setup Page.

<sup>2</sup> Depending on the printer setup, this menu item appears as Standard Network or Network [x].

## Using the control panel



	Use the	To
1	Display	View the printer status and messages. Set up and operate the printer.
2	Left arrow button	Scroll to the left.
3	Select button	Select menu options. Save settings.
4	Up arrow button	Scroll up.
5	Right arrow button	Scroll to the right.
6	Keypad	Enter numbers, letters, or symbols.
7	Sleep button	Enable Sleep mode or Hibernate mode. The following actions wake the printer from Sleep mode: <ul style="list-style-type: none"> <li>• Pressing any hard button</li> <li>• Sending a print job from the computer</li> <li>• Performing a power-on reset using the main power switch</li> </ul> The following actions wake the printer from Hibernate mode: <ul style="list-style-type: none"> <li>• Pressing the Sleep button until the printer wakes</li> <li>• Performing a power-on reset using the main power switch</li> </ul>
8	Stop or cancel button	Stop all printer activities.
9	Back button	Return to the previous screen.
10	Down arrow button	Scroll down.
11	Home button	Go to the home screen.
12	Indicator light	Check the status of the printer.

## Understanding the colors of the Sleep button and indicator lights

The colors of the Sleep button and indicator lights on the printer control panel signify a certain printer status or condition.

Indicator light	Printer status
Off	The printer is off or in Hibernate mode.
Blinking green	The printer is warming up, processing data, or printing.
Solid green	The printer is on, but idle.
Blinking red	The printer requires user intervention.

Sleep button light	Printer status
Off	The printer is off, idle or in Ready state.
Solid amber	The printer is in Sleep mode.
Blinking amber	The printer is entering or waking from Hibernate mode.
Blinking amber for 0.1 second, then goes completely off for 1.9 seconds in a slow, pulsing pattern	The printer is in Hibernate mode.