## Paper sizes 1

Using color

Printing

Paper handling

Maintenance

Troubleshooting

Administration

Your printer supports a wide variety of paper sizes. See **Media guidelines** for illustrations of proper paper orientation.

The printer determines the size paper loaded in the trays by the position of the paper guides. Make sure you adjust the guides each time you change paper sizes. The following tables list the paper and envelope sizes your printer supports.

Size	Dimensions	Print speed in black and white/color <sup>1</sup> (ppm)
A4	210 x 297 mm (8.3 x 11.7 in.)	24/6
Letter	215 x 279 mm (8.5 x 11 in.)	24/6
Executive	184 x 266 mm (7.25 x 10.5 in.)	24/6
B5	182 x 257 mm (7.2 x 10.1 in.)	24/6
Legal <sup>2</sup>	216 x 356 mm (8.5 x 14 in.)	23/3
A5	148 x 210 mm (5.8 x 8.2 in.)	24/6
<sup>1</sup> Simplex printing speeds at factory default settings.		

<sup>2</sup> Can only be placed in the optional legal tray.



Index



### Paper sizes 2

## Printing

Using color

Paper handling

Maintenance

Troubleshooting



Size	Dimensions (h/w)	Print speed in black and white/color (ppm)
DL Envelope	110 x 220 mm (4.3 x 8.7 in.)	12/4
C5 Envelope	162 x 229 mm (6.4 x 9 in.)	12/4
B5 Envelope	176 x 250 mm (6.9 x 9.9 in.)	12/4
9 Envelope	99 x 226 mm (3.9 x 8.9 in. )	12/4
10 Envelope	103 x 241 mm (4.125 x 9.5 in.)	12/4
* Simplex printing speeds at factory default settings.		

2

Index



## Paper size sensing

Your printer can automatically sense when A4, letter, legal, executive media or B5, DL, and #10 envelopes are loaded in tray1. To do this, the Auto Size Sense setting must be set to **On**. Your printer default was set at the factory to either the US or Non-US default with the Auto Size Sense setting **On**. The US or Non-US default setting affects the auto sensing ability of the printer. In the US mode, the tray sensing recognizes the #10 envelope and not the DL envelope. In the Non-US mode, it recognizes the DL envelope, but not the #10 envelope. Refer to the *Technical Reference* for more information on US and Non-US defaults.

The printer determines the size of the media loaded in the trays by the position of the front paper guide. The optional 500-sheet tray is always set to Auto Size Sense On. Since tray 2 is for plain paper only, and cannot be used for legal paper or envelopes, tray 2 auto sensing only recognizes A4, letter, or executive size paper. Tray 2 sensing cannot be turned off.

When **Auto Size Sense** is **On** you cannot select paper sizes at the operator panel, in MarkVision or in your software application. Since the printer is automatically detecting the paper size from the tray, it does not let you override the paper size menu.



Index

Printing

Using color

Paper handling

Maintenance

Troubleshooting

Administration



## Paper sizes 4

# Printing Using color Paper handling Maintenance Troubleshooting Administration Index

If you want to use paper sizes that are not recognized when Auto size sense is **On** you must change Auto size sense to **Off.** 

To change the Auto Size Sense setting to Off:

- **1** Turn the printer off.
- 2 Press and hold the Go and Stop buttons and turn the printer on.
- 3 Release both buttons when **Performing Self Test** appears.
- 4 Press Menu> or <Menu, until the Tray 1 Auto Size message appears.
- 5 Press Select.
- 6 Press Menu> or <Menu, until Off appears on the display.
- 7 Press Select.

To return the Auto Size Sense setting to **On**, repeat steps 1 through 7 but, select **On** during step 6.



