

How to Set-up AS/400 with the Forms Printer 2500 Series

- In the AS/400 platform, create the device description (DEVD) by typing CRTDEVPRT in the command line.

```

MAIN                               System i Main Menu                               System:  MANGO
Select one of the following:

1. User tasks
2. Office tasks
3. General system tasks
4. Files, libraries, and folders
5. Programming
6. Communications
7. Define or change the system
8. Problem handling
9. Display a menu
10. Information Assistant options
11. System i Access tasks

90. Sign off

Selection or command
==> crtdevprt

F3=Exit  F4=Prompt  F9=Retrieve  F12=Cancel  F13=Information Assistant
F23=Set initial menu
  
```

- Type the following values:

Type choices, press Enter.

Device description	> <u>DEVNAME</u>	Name
Device class	> <u>*LAN</u>	*LCL, *RMT, *VRT, *SNPT, *LAN
Device type	> <u>3812</u>	3287, 3812, 4019, 4201...
Device model	> <u>1</u>	0, 1, 2, 3, 4, 10, 13, 301...
LAN attachment	> <u>*IP</u>	*LEXLINK, *IP, *USRDFN
Port number	> <u>9100</u>	0-65535
Online at IPL	> <u>*YES</u>	*YES, *NO
Font:		
Identifier	> <u>11</u>	3, 5, 11, 12, 13, 18, 19...
Point size	> <u>*NONE</u>	000.1-999.9, *NONE
Form feed	> <u>*CONT</u>	*TYPE, *CONT, *CONT2, *CUT...
Separator drawer	> <u>*FILE</u>	1-255, *FILE
Separator program	> <u>*NONE</u>	Name, *NONE
Library	> _____	Name, *LIBL, *CURLIB
Printer error message	> <u>*INFO</u>	*INQ, *INFO
Message queue	> <u>*CTLD</u>	Name, *CTLD, *SYSOPR, QSYSOPR
Library	> _____	Name, *LIBL, *CURLIB
Activation timer	> <u>170</u>	1-2550, *NOMAX
Inactivity timer	> <u>*SEC15</u>	1-30, *ATTACH, *NOMAX...
Host print transform	> <u>*YES</u>	*NO, *YES
Manufacturer type and model	> <u>*LEX2391</u>	
Paper source 1	> <u>*LETTER</u>	*MFRTYPMDL, *LETTER...
Paper source 2	> <u>*LETTER</u>	*MFRTYPMDL, *LETTER...
Envelope source	> <u>*NONE</u>	*MFRTYPMDL, *MONARCH...
ASCII code page 899 support	> <u>*NO</u>	*NO, *YES
Image configuration	> <u>*NONE</u>	*NONE, *IMGA01, *IMGA02...
Character identifier:		
Graphic character set	> <u>*SYSVAL</u>	1-32767, *SYSVAL
Code page	> _____	1-32767
Remote location:		
Name or address	> <u>'10.194.14.152'</u>	
User-defined options	> <u>*IBMSHRCNN</u>	Character value, *NONE
+ for more values	> _____	
User-defined object:		
Object	> <u>*NONE</u>	Name, *NONE

```

Library . . . . . _____ Name, *LIBL, *CURLIB
Object type . . . . . _____ *DTAARA, *DTAQ, *FILE...
Data transform program . . . . . *NONE _____ Name, *NONE
Library . . . . . _____ Name, *LIBL, *CURLIB
System driver program . . . . . > *IBMSNMPDRV _____
Secure connection . . . . . *NO _____ *NO, *YES
Validation list . . . . . *NONE _____ Name, *NONE
Library . . . . . _____ Name, *LIBL, *CURLIB
Publishing information:
Support duplex . . . . . *UNKNOWN _____ *UNKNOWN, *SIMPLEX, *DUPLEX
Support color . . . . . *UNKNOWN _____ *UNKNOWN, *NOCOLOR, *COLOR
Pages per minute black . . . . . *UNKNOWN _____ 1-32767, *UNKNOWN
Pages per minute color . . . . . *UNKNOWN _____ 1-32767, *UNKNOWN
Location . . . . . *BLANK _____
Data streams supported . . . . . *UNKNOWN _____ *UNKNOWN, *PCL, *PS, *PDF...
+ for more values
Text 'description' . . . . . > '*LAN 3812 SNMP DEVD for IBM IP40' _____

```

Additional Parameters

```

Remote network identifier . . . . . *NETATR _____ Name, *NETATR, *NONE
Workstation customizing object . . . . . *NONE _____ Name, *NONE
Library . . . . . _____ Name, *LIBL, *CURLIB
Authority . . . . . *CHANGE _____ Name, *CHANGE, *ALL, *USE...

```

After filling out all these values, press enter to create the DEVD.

3. Vary ON the DEVD object and turn ON the WTR. You are now ready to print.