

# Instalacija

**1** Unboxing and initial assembly. The printer is removed from the shipping container. A warning icon indicates that the printer should be handled by two people.

**2** Initial setup. The printer is shown next to a computer. The text 'dn' and 'dtn' indicates the printer model.

**3** Paper tray assembly. The paper tray is attached to the printer.

**4** Paper tray installation. The paper tray is inserted into the printer.

**5** Paper tray adjustment. The paper tray is adjusted to the correct position.

**6** Paper tray warning. A warning icon indicates that the paper tray should not be touched.

**7** Paper tray removal. The paper tray is removed from the printer.

**8** Paper tray removal. The paper tray is removed from the printer.

**9** Paper tray removal. The paper tray is removed from the printer.

**10** Paper tray removal. The paper tray is removed from the printer.

**11** Software installation. The software is installed on the computer. The text 'Lokalno' indicates local installation.

**12** Software installation. The software is installed on the computer. The text 'Mreža' indicates network installation.

**iii** Network connection. The printer is connected to the network.



PIN 2081955 E.C. 980171  
© 2006 Lexmark International, Inc. Sva prava zašćena.



12