

Print defects guide

Identifying supplies or parts for replacement

Match a set of repeating defects on a printed page to the marks on one of the vertical lines. The line that best matches the defects on the page indicates which particular part is causing the defect.

Notes:

- There are four additional color pages and a blank page that prints with this guide. Use these pages for assistance in determining which part is defective.
- The photoconductor unit and developer unit are customer replaceable parts. If the transfer module or fuser needs replacement, then contact customer support at <http://support.lexmark.com> or your Lexmark service representative.

Replace the photoconductor unit

Replace the developer unit






25.1 mm
(0.99 in.)

29.8 mm
(1.17 in.)

94.2 mm
(3.70 in.)


43.9 mm
(1.72 in.)

45.5 mm
(1.79 in.)




Replace the transfer module

37.7 mm
(1.48 in.)



55.0 mm
(2.17 in.)



78.5 mm
(3.09 in.)



Replace the fuser

95 mm
(3.74 in.)



