

# Anleitung für Druckdefekte

## Erkennen auszutauschender Verbrauchsmaterialien oder Teile

Ordnen Sie eine Reihe von Wiederholungsfehlern auf einer gedruckten Seite einer der vertikalen Linien zu. Die Linie, die den Fehlern auf der Seite am ehesten entspricht, zeigt an, welches Teil den Fehler verursacht.

### Hinweise:

- Mit diesen Anweisungen werden zusätzlich vier Farbseiten und eine leere Seite gedruckt. Benutzen Sie diese Seiten als Hilfe, um herauszufinden, welches Teil fehlerhaft ist.
- Das Belichtungskit kann vom Kunden ausgetauscht werden. Wenn das Transfermodul oder die Fixierstation ausgetauscht werden muss, wenden Sie sich an den Kundendienst unter <http://support.lexmark.com> oder an den zuständigen Lexmark Kundendienstvertreter.

**Tauschen Sie das Belichtungskit aus**    **Tauschen Sie die Entwicklereinheit aus**

25,1 mm    29,8 mm    94,2 mm                      43,9 mm                      45,5 mm  
(0,99 Zoll)    (1,17 Zoll)    (3,70 Zoll)                      (1,72 Zoll)                      (1,79 Zoll)

The form consists of five vertical lines, each representing a different component. The lines are of varying heights and are intended for matching with printing errors. The first line is the tallest, followed by the second, third, fourth, and fifth lines in descending order of height.

Tauschen Sie das Transfermodul aus. Tauschen Sie die Fixierstation aus.

37.7 mm	55,0 mm	78.5 mm	95 mm
(1,48 Zoll)	(2,17 Zoll)	(3,09 Zoll)	(3,74 Zoll)











