

**Setup**  
**Installation**  
**Instalación**

**Installazione**  
**Instalação**  
**Installatie**

**Asennus**  
**Installasjon**  
**Instalacija**

**Руководство  
по установке**  
**설치**



设置  
假倪

**Local**  
**Lokal**  
**Locale**




**Lokalt**  
**Lokaal**  
**Paikallinen**

**Lokalne**  
**Локальный**  
**로컬**


**本地连接**  
**本端連接**





- Lift printer by side handholds only.  
Soulevez l'imprimante par les poignées situées sur les côtés uniquement.
- Zum Anheben des Druckers nur die seitlichen Griffmulden verwenden.
- Levante la impresora sólo por las agarraderas laterales.
- Sollevare la stampante utilizzando solo i punti di presa laterali.
- Levante a impressora apenas pelos suportes para mãos laterais.
- Lyft endast skriven i handtagen på sidorna.
- Lyft kun printeren i håndtagene.
- Gebruik alleen de handgrepen aan de zijkant om de printer op te tillen.
- Nosta tulostinta ainoastaan kädensijoista.
- Lyft skriven bare med håndtakene på siden.
- Drukarkę podnosić można tylko za jej boczne uchwyty.
- Поднимайте принтер только за боковые выемки.
- 프린터를 들어올릴 때는 반드시 양쪽을 잡으십시오.
- 只用侧把手抬起打印机。
- 只能從側邊把手抬起印表機。





2






3




5



8



10



11



P/N 13N1350 E.C. 3N0059  
© 2005 Lexmark International, Inc. All rights reserved.  
Printed in USA