Connection Guide

Installing an attached printer locally (Windows)

Note: If the Software and Documentation CD does not support the operating system, you must use the Add Printer Wizard.

Updates for the printer software may be available on the Lexmark Web site at www.lexmark.com.

What is local printing?

Local printing is printing to a locally attached printer (a printer that is connected directly to your computer with a USB cable). When setting up this type of printer, you should install the printer software *before* connecting the USB cable. For more information, see the setup documentation that came with the printer.

The Software and Documentation CD can be used to install the necessary printer software on most Windows operating systems.

Installing the printer using the Software and Documentation CD

Using the Software and Documentation CD, you can install printer software for the following operating systems:

- Windows Vista and Windows Vista x64 Edition
- Windows Server 2003 and Windows Server 2003 x64 Edition
- Windows XP and Windows XP x64 Edition
- Mac OS X
- Red Hat Enterprise Linux WS 4 and Red Hat Enterprise Linux WS 5
- openSUSE Linux 11.2 and openSUSE Linux 11.3
- SUSE Linux Enterprise Desktop 10 and SUSE Linux Enterprise Desktop 11
- SUSE Linux Enterprise Server 10 and SUSE Linux Enterprise Server 11
- Debian GNU/Linux 5.0
- Ubuntu 10.04, Ubuntu 9.10, and Ubuntu 9.04
- Linpus Linux Desktop 9.6
- Red Flag Linux Desktop 6.0
- **1** Close all open applications.
- 2 Insert the Software and Documentation CD.

If the install screen does not appear after a minute, then launch the CD manually:

- a Click 🗐, or click Start and then click Run.
- **b** In the Start Search or Run box, type D:\setup.exe, where D is the letter of your CD or DVD drive.
- **3** Click **Recommended Install**, and then follow the instructions on the computer screen.

Installing the printer using the Add Printer Wizard (Windows)

Note: Installing the printer using the Add Printer Wizard is supported for Windows XP and later.

- **1** Close all open software programs.
- 2 Insert the Software and Documentation CD.
- **3** Close the installation software.

Connection Guide Page 2 of 5

- **4** Add the printer:
 - a Click 🧐, or click Start and then click Run.
 - **b** In the Start Search or Run box, type **control printers**.
 - c Press Enter, or click OK.
 - **d** From the Printer Tasks area, click **Add a printer**.
- 5 When prompted, select to install a local printer, and then click Have Disk.
- **6** Specify the location of the printer software.

Note: The path should be similar to D: \Drivers\Print\GDI\, where D is the letter of your CD or DVD drive.

7 Click OK.

Installing the attached printers on a network (Windows)

What is network printing?

In Windows environments, network printers can be configured for direct printing or shared printing. Both network printing methods require the installation of printer software and the creation of a network port.

Printing method	Example
 IP printing Printer is connected directly to the network using a network cable, such as an Ethernet cable. Printer software is typically installed on each network computer. 	
 Shared printing Printer is connected to one of the computers on the network using a local cable, such as a USB or parallel cable. Printer software is installed on the computer attached to the printer. During software installation, the printer is set up to be "shared" so that other network computers can print to it. 	

Installing the printer on an Ethernet network

Before you install the printer on a wired network, make sure that you have completed the initial setup of the printer, and that the printer is connected to your active Ethernet network with an Ethernet cable.

- 1 Close all open software programs.
- 2 Insert the installation software CD.

If the Welcome screen does not appear after a minute, then launch the CD manually:

- a Click 🧐, or click Start and then click Run.
- **b** In the Start Search or Run box, type **D**: \setup.exe, where **D** is the letter of your CD or DVD drive.

3 Click **Recommended Install**, and then follow the instructions on the computer screen.

Note: To configure the printer using a static IP address, using IPv6, or to configure printers using scripts, select **Custom Install**, and then follow the instructions on the computer screen.

- **4** When prompted to choose a connection type, select **Ethernet connection**.
- **5** Follow the instructions on the computer screen.

Sharing the printer on a network

- 1 Close all open software programs.
- **2** Insert the installation software CD.

If the Welcome screen does not appear after a minute, then launch the CD manually:

- a Click 🧐, or click Start and then click Run.
- **b** In the Start Search or Run box, type **D**: \setup.exe, where **D** is the letter of your CD or DVD drive.
- 3 Click Recommended Install, and then follow the instructions on the Welcome screen.
- **4** When prompted, select the printer you want to install, and then click **Add Printer**.
- 5 In the left-hand pane, under Selected Components, click the + next to the printer model you just added.
- 6 Click Port.

In the right-hand pane, select the port where the printer is physically connected. LPT1 is selected by default.

- 7 Click the + next to Shared, and then select Shared.
- 8 Click Share Name, and then type the name of the shared printer in the Share Name field in the right-hand pane.
- **9** If appropriate for your network, select **Publish Printer in Active Directory** and enter the associated information in the right-hand pane.
- 10 If you want the driver to be the default driver, select **Default Driver**.
- 11 If you want to associate a driver profile with the printer, click **Driver Profile**, and then select the configuration in the right-hand pane.
- **12** To include any notes or specific location information for the printer, click **Comments** > **Location**.
- 13 Select any other components you want to install, and then click Finish.
- 14 Follow the instructions on the computer screen.

Installing the attached printer locally (Macintosh)

Before installing the printer locally (Macintosh)

The printer can be connected to a local network using a USB cable. When setting up the printer this way, install the printer software *first* before connecting the USB cable. For more information, see the documentation that came with the printer.

The Software and Documentation CD can be used to install the necessary printer software.

Note: You can also download the printer driver from the Web site at www.lexmark.com.

Creating a queue in the Printer Setup Utility or Print Center (Macintosh)

For local printing from a Macintosh computer, you will need to create a print queue:

- 1 Install a printer driver file on the computer.
 - a Insert the Software and Documentation CD, and then double-click the installer package for the printer.
 - **b** Follow the instructions on the computer screen.
 - c Select a destination, and then click Continue.
 - **d** From the Easy Install screen, click **Install**.
 - e Type the user password, and then click **OK**. All necessary software is installed on the computer.
 - **f** Click **Close** when installation is complete.
- **2** From the Finder, navigate to:

Applications > **Utilities**

- 3 Double-click Printer Setup Utility or Print Center.
- **4** Verify that the print queue was created:
 - If the USB-attached printer appears in the Printer list, then quit the Printer Setup Utility or Print Center.
 - If the USB-attached printer does not appear in the Printer list, then make sure the USB cable is properly connected and the printer is turned on. After the printer appears in the Printer list, quit the Printer Setup Utility or Print Center.

Installing the attached printers to a network (Macintosh)

Installing the printer on a wired network (Macintosh)

- 1 Install the driver file on the computer:
 - **a** Insert the Software and Documentation CD, and then double-click the installer package for the printer.
 - **b** Follow the instructions on the computer screen.
 - c Select a destination, and then click Continue.
 - **d** From the Standard Install screen, click **Install**.
 - e Type the user password, and then click **OK**. All the necessary software is installed on the computer.
 - **f** Click **Close** when installation is complete.
- **2** Add the printer:
 - For IP printing:

In Mac OS X version 10.5 or later

- a From the Apple menu, navigate to:System Preferences > Print & Fax
- **b** Click +, and then click the **IP** tab.
- **c** Type the IP address of your printer in the Address field, and then click **Add**.

Connection Guide Page 5 of 5

In Mac OS X version 10.4 or earlier

- a From the Finder, navigate to: Applications > Utilities
- **b** Double-click **Printer Setup Utility** or **Print Center**.
- c From the Printer List, click Add, and then click IP Printer.
- **d** Type the IP address of your printer in the Address field, and then click **Add**.
- For AppleTalk printing:

Note: Make sure AppleTalk is activated on your printer.

In Mac OS X version 10.5

- a From the Apple menu, navigate to: System Preferences > Print & Fax
- b Click +, and then navigate to: AppleTalk > select the printer from the list > Add

In Mac OS X version 10.4 or earlier

- a From the Finder, navigate to: Applications > Utilities
- **b** Double-click **Printer Setup Utility** or **Print Center**.
- c From the Printer List, click Add.
- **d** Click **Default Browser** tab > **More Printers**.
- e From the first pop-up menu, select AppleTalk.
- f From the second pop-up menu, select Local AppleTalk Zone.
- **g** Select the printer from the list, and then click **Add**.

Note: If the printer does not show up in the list, you may need to add it using the IP address. For more information, contact your system support person.

Installing other software for a Macintosh computer

The following utilities can be found on the Macintosh partition of the Software and Documentation CD:

- Printer File Loader (OS X)
- Printer Status (OS X)

The contents of the Software and Documentation CD are copied on the computer hard disk during the initial printer setup.